
AC100V/200V AC Servo Motor
SV-NET Driver

TAD8811 Series

Installation/Operation Instruction Manual

EU RoHS Directive compliant product

 **TAMAGAWA SEIKI CO.,LTD**

Contents

| | | | |
|---|-----------|--|-----------|
| Contents | 3 | 7.1. Connecting the Power Supply | 45 |
| Safety Precautions | 7 | 7.2. Connecting the USB | 47 |
| 1. Before You Begin | 14 | 7.3. Connection by SV-NET/RS485 | 48 |
| 1.1. Overview of the Product | 14 | 7.4. Connecting the Motor | 50 |
| 1.2. Specifications..... | 22 | 7.5. Example of SV-NET Motion Controller and Motor/Driver (3-Axis) Connection | 56 |
| 1.3. Standard Functions..... | 25 | 7.6. Connecting the I/O cable | 57 |
| 1.4. SV-NET | 26 | 7.7. Wiring the I/O Connector | 59 |
| 1.5. SV-NET Motion Controller | 27 | 7.8. Connecting the Analog Monitor Output Connector | 68 |
| 1.6. Operating from a Personal Computer | 27 | 7.9. Connecting External Resistors | 69 |
| 1.7. Maintenance and Inspection of Servo Driver.. | 28 | 7.10. Mechanical Brake | 70 |
| 2. Names and Functions of Parts | 29 | 7.11. Other Considerations for Wiring | 70 |
| 2.1. Names of Parts | 29 | 8. How to Control the Driver | 71 |
| 2.2. Block Diagram..... | 30 | 9. Establishing Communication with Host Equipment | 72 |
| 2.3. Functions of Parts..... | 31 | 9.1. Procedure for Specifying Communication Specifications | 72 |
| (1) I/O connector | 31 | 9.2. Procedure for Setting a MAC-ID | 73 |
| (2) Sensor connector..... | 32 | 9.3. Procedure for Setting the Communication Speed | 74 |
| (3) Manufacturer maintenance connector | 32 | 10. Trial Run | 76 |
| (4) SV-NET/RS485 connector | 33 | 10.1. Trial Run from Settings Panel..... | 76 |
| (5) USB connector..... | 33 | 10.2. Speed Control Trial Run | 77 |
| (6) Analog monitor output connector(debugging connector)..... | 33 | 10.3. Position Control Trial Run..... | 78 |
| (7) Drive power supply connector..... | 34 | 11. Servo Gain Adjustment | 79 |
| (8) Motor/external resistor connector | 34 | 11.1. Servo Block Diagram | 79 |
| (9) Grounding terminal (Frame ground) | 34 | 12. Tuning-Free Function | 81 |
| (10) Settings panel | 35 | 12.1. Precautions for Use | 81 |
| (11) CHARGE lamp..... | 35 | 12.2. Settings of Tuning-Free Function..... | 81 |
| 3. Connection Example | 36 | 13. Manual Gain Tuning (Basic) | 85 |
| 4. Conformance to Standards | 37 | 13.1. Servo Gain..... | 85 |
| 4.1. Conformance to Standards..... | 38 | | |
| 4.2. EMC Installation Environment..... | 39 | | |
| 5. Process Flow | 41 | | |
| 6. Installation (Installing to Equipment) ... | 42 | | |
| 7. Connection Method | 45 | | |

| | | | |
|---|------------|--|------------|
| 13.2. Setting the Load Inertia | 86 | 15.4.2. Homing with an origin signal (origin detection by I/O) | 130 |
| 13.3. Adjusting the Basic Gains | 87 | 15.4.3. Homing with an origin signal (origin detection by communication commands)..... | 131 |
| 13.4. Filter Adjustment | 89 | 15.4.4. Homing by mechanical stopper | 132 |
| 13.5. Confirming the Set Gains | 91 | 15.5. The Driver Operation Status | 133 |
| 13.6. Gain-switch Function | 92 | 15.6. Control Mode Switch Function | 134 |
| 13.7. Saving Parameters | 94 | 15.7. Simplified Control Mode | 136 |
| 14. Manual Gain Tuning (Advanced) | 95 | 16. Supplementary Explanation about Functions | 138 |
| 14.1. Position Command Damping Filter | 95 | 16.1. Saving Parameters..... | 138 |
| 14.2. Speed Stabilization Control | 97 | 16.2. Initializing Parameters..... | 138 |
| 14.3. Feed-forward Functions..... | 98 | 16.3. Servo Command..... | 138 |
| 14.4. Disturbance Observer..... | 99 | 16.4. Servo OFF Delay Function | 143 |
| 14.5. Correction for Friction and Gravity..... | 100 | 16.5. Defining the Forward Rotation Direction | 143 |
| 14.5.1. Auto-configuration..... | 101 | 16.6. Setting the Position Soft Limit | 144 |
| 14.5.2. Manual Configuration..... | 102 | 16.7. Servo OFF Using Communication Stop..... | 144 |
| 15. Operation | 105 | 17. Alarm Detection | 145 |
| 15.1. Position Control Mode..... | 105 | 17.1. How to Detect an Alarm | 145 |
| 15.1.1. Pulse Input Signal Types | 108 | 17.2. List of Alarm | 147 |
| 15.1.2. Pulse Command Software Filter Function | 109 | 17.3. List of Sensor Alarm | 150 |
| 15.1.3. Setting the Pulse Input Signal Resolution (Setting the Electronic Gear) | 110 | 17.4. Resetting Alarm..... | 152 |
| 15.1.4. Deviation Reset..... | 111 | 17.5. Clearing a Sensor Alarm..... | 152 |
| 15.1.5. Pulse Input Disable Function | 111 | 17.6. Checking the Alarm History | 152 |
| 15.1.6. Smoothing Time Setting Function..... | 112 | 17.7. Checking Detailed Alarm Occurrence Information | 153 |
| 15.1.7. Positioning Completion Signal (In-position) Function..... | 113 | 17.8. Setting the Calendar Function | 154 |
| 15.2. Speed Control Mode..... | 113 | 17.9. Characteristics of Overload Alarm Detection | 155 |
| 15.2.1. Analog Input Zero Clamp Function | 116 | 17.10. Alarm Detection Disabling Settings and Warning Status Display | 156 |
| 15.2.2. Analog Input Filtering Function | 116 | 18. Troubleshooting | 157 |
| 15.2.3. Analog Input Forced-0 Command Function | 116 | 19. List of Parameters | 167 |
| 15.2.4. Speed Command Acceleration and Deceleration Setting Function..... | 116 | 19.1. Communication Parameters..... | 167 |
| 15.3. Current Control Mode..... | 117 | 19.2. Parameters for Initializing and Saving Parameters | 168 |
| 15.3.1. Analog Input Zero Clamp Function | 119 | | |
| 15.3.2. Analog Input Filtering Function | 119 | | |
| 15.3.3. Analog Input Forced-0 Command Function | 119 | | |
| 15.3.4. Speed Limit Function | 120 | | |
| 15.4. Homing Mode | 121 | | |
| 15.4.1. Rotation Start Direction in Homing Mode..... | 129 | | |

| | | | |
|---|------------|---|------------|
| 19.3. Status Parameters..... | 168 | 20.7. Operations in Alarm Display Mode..... | 206 |
| 19.4. Control Command Parameters..... | 170 | 20.8. Operations in Supplementary Functions Mode | 207 |
| 19.5. Servo Feedback Parameters..... | 172 | 20.9. Operations in JOG Operation Mode..... | 208 |
| 19.6. Servo Gain Parameters..... | 174 | 20.10. List of Status Display Mode..... | 209 |
| 19.7. Parameters for Setting Control Functions | 175 | 21. After-Sales Service..... | 210 |
| 19.8. Parameters for Setting Homing Operation | 181 | 21.1. Repair and Inquiry | 210 |
| 19.9. Control Mode Switching Parameters..... | 181 | 21.2. Guarantee..... | 210 |
| 19.10. Parameters for Setting I/O | 182 | 21.3. Exemption from Responsibility for Compensation for Opportunity Loss, Etc. | 210 |
| 19.11. Parameters for Setting Analog Monitor | 184 | 21.4. Period of Repair after Production Discontinuation..... | 210 |
| 19.12. Parameters for Setting Pulses | 184 | 21.5. Delivery Conditions | 211 |
| 19.13. Parameters for Setting Analog Input..... | 186 | 21.6. Appropriate Use of This Product..... | 211 |
| 19.14. Special Servo Parameters | 187 | 22. Appendices | 212 |
| 19.15. Parameters for Setting Error Detection | 190 | 22.1. Optional Parts | 212 |
| 19.16. Parameters for Internal Monitoring | 192 | 22.2. External Connection Diagram..... | 216 |
| 19.17. Extension Parameters | 193 | 22.3. Usable Parameters by Software Revision..... | 218 |
| 20. Settings Panel Operation | 200 | 22.4. Settings Panel Function Extension | 225 |
| 20.1. Settings Panel Names and Functions | 200 | Revision History..... | 226 |
| 20.2. Display Mode Functions and Selection | 201 | | |
| 20.3. Operations in Status Display Mode..... | 202 | | |
| 20.4. Operations in Parameter Operations Mode ... | 203 | | |
| 20.5. Parameter Value Display Examples | 204 | | |
| 20.6. Operations in Parameter Save Mode..... | 205 | | |

Memo:

Safety Precautions

- Warning indications regarding safety

This document uses the following terms to describe items that must be observed in order to prevent personal injury and equipment damage. Examples of misuse that could result in bodily harm or material damage are shown as follows and classified according to the degree of potential harm or damage. The matters described here are important for safety. Please be sure to comply with these warnings.

Danger

- This indication signifies a hazardous situation that could result in death, serious injury, or fire if not avoided.

Caution

- The heat sink might become hot. Do not touch the heat sink. Failure to observe this instruction could result in burns.

Caution

- Failure to observe this instruction could result in an electrical shock. This indication signifies a hazardous state that could result in death, serious injury, or fire if not avoided.

Caution

- This indication signifies a hazardous situation that could result in a medium-level injury, light injury, fire, or property damage if not avoided.

Important

- This indication signifies a precaution that you are required to observe without fail. The precaution is on a level that is not expected to lead to equipment damage. This level includes issue of alarms, etc.

- Icon Indications

The following icons are provided to clarify the contents.

Supplement

shows information, operation, or example of settings in order to deepen understanding.

- Please make sure to observe the following matters for safety purposes.

General Precautions

Danger

- You are required to read this manual in order to use this product safely.
- Please keep this manual at hand and make sure that it will be delivered to the end user of this product.
- Do not remove covers, cables, connectors, or optional equipment while the driver is energized.
Otherwise, an electrical shock and/or stoppage or burning of the product might occur.
- Use the product at the power supply specifications (number of phases, voltage, frequency, and current) appropriate for the product.
Failure to observe this instruction could result in burning, electrical shocks, and/or fire.
- Be sure to connect the grounding terminal (frame ground) of the driver to the grounding electrode (earth (PE)).
Failure to observe this instruction could result in electrical shocks and/or a fire.
- Do not disassemble, repair, or modify the product.
Failure to observe this instruction could result in a fire or a failure. Disassembled, repaired, or modified products are not covered under the warranty.

Caution

- Do not touch the heat sink of the driver while it is energized.
Failure to observe this instruction could result in burns.

Caution

- Do not touch the terminal while the product is energized, and for one minute after the power is turned off.
Failure to observe this instruction could result in an electric shock.

Caution

- **Do not damage the cables, pull strongly on them, exert excessively large force on them, place a heavy object on them or crimp them.**
Failure to observe this instruction could result in a failure, damage, or electrical shock.
- **Never use the product in a place where water might get in or on it, in a corrosive atmosphere, in a combustible-gas atmosphere, or in an atmosphere where an electrically conductive foreign object such as a metal piece might penetrate into the product or near a combustible material.**
Failure to observe this instruction could result in an electrical shock and/or fire.

Precautions for Storage

Caution

- **For a storage location, select an environment that meets the following conditions.**
 - Locations not subject to direct sunlight
 - Ambient temperature: -10 to 65°C (non-condensing)
 - Relative humidity: 90%RH or less (non-condensing)
 - Locations with no condensation from rapid temperature fluctuations
 - Locations with no corrosive gases and/or combustible gases
 - Locations with no combustible materials nearby
 - Locations where there is little dust, dirt, salt, and metal powder
 - Locations in which the product will not be subject to water, oil, chemicals, etc.
 - Locations in which the product will not be subject to vibrations and mechanical shocks (product specifications must not be exceeded.)

If the product is stored in an environment that does not meet the above conditions, it may suffer a failure and/or damage.

Precautions for Transportation

Caution

- **Transport the product appropriately according to its mass without damaging it.**
- **This product is precision equipment. Do not drop it or subject it to strong impacts.**
Failure to observe this instruction could result in a failure or damage.
- **Do not exert impacts on the connectors.**
Failure to observe this instruction could result in poor connections or device failures.

Precautions for Mounting (Installation)

Caution

- **Install the product in a place that can support its weight.**
- **Attach the driver and the regenerative resistor to a non-combustible article.**
Attaching them directly to or near a combustible article could result in a fire.
- **Leave a specified mounting distance between the driver and the internal face of the control panel or other devices.**
Failure to observe this instruction could result in a fire or a device failure.
- **Mount the driver in the specified orientation.**
Failure to observe this instruction could result in a fire or a device failure.
- **Do not place a heavy object on the product.**
Failure to observe this instruction could result in a device failure, damage, and/or injury.
- **Make sure of installing the driver within the control panel.**
- **Install the product appropriately so that shocks and vibrations exerted on it will not exceed the product specifications.**

Precautions for Wiring

Danger

- **Do not change wiring while the product is energized.**
Failure to observe this instruction could result in an electrical shock and/or injury.
- **Wiring and inspections must be made by a qualified engineer.**
Failure to observe this instruction could result in an electrical shock and/or a failure of the product.

Caution

- **Wiring and inspections must be made when the CHARGE lamp is off after at least one or more minutes have passed since power-off of the product. Since high voltage may remain in the driver after the power-off, do not touch the power terminal while the CHARGE lamp is on.**
Failure to observe this instruction could result in an electrical shock.

Caution

- **During wiring and trial run, observe the precautions described in this manual.**
Failure to observe this instruction could result in a failure of the driver due to wrong wiring, applying an incorrect voltage, etc. leading to device damage and physical injury.
- **Be sure to use an AWG14 (2.5 sq) wire rod as an electric wire for establishing a connection to the grounding terminal (frame ground). Firmly tighten the terminal at the specified torque.**
Insufficient tightening could cause heating of the wire and the terminal block due to a poor contact, leading to a fire.
- **For wiring, use the cables we specify, whenever possible.**
If you need to use a cable other than those we specify, select an appropriate one by considering usage conditions such as the rated current of the relevant model and its operating environment.
- **When wiring, use only wire rods with temperature rating of 75°C or higher.**
- **Use copper conductor electrical wires for the wiring.**
- **Firmly tighten the lockscrews and locking mechanisms of cable connectors.**
Insufficient tightening could result in disconnection of a cable connector during operation.
- **Do not run a heavy-current line (a main circuit cable) and a light-current line (an input/output cable and a sensor cable) in the same duct or bundle them together. If a heavy-current line and a light-current line cannot be placed in separate ducts, leave a wiring distance of 30 cm or more between them.**
Wiring that is too close together could result in malfunctions due to noise on the low-current line.

Precautions for Operation and Running

Danger

- **Implement a trial run while the product is isolated from the machine with the servo motor fixed in place.**
Failure to observe this instruction could result in injury.
- **Before operating the product while it is attached to the machine, correctly set the input and output signals and those of parameters appropriately for the machine.**
Running the product without making appropriate settings could result in unexpected machine movement or failure and/or physical injury.
- **Do not assign extreme values to any parameter.**
Assigning an extreme parameter value could cause unstable motion, resulting in machine damage and/or injury.
- **To prevent unexpected accidents, implement safety measures such as installing limit switches at the end point of movement sections of the machine.**
Failure to observe this instruction could result in machine damage and/or injury.

Important

- **In gain adjustment at system start-up, confirm by observing the torque waveform and speed waveform that no vibration occurs.**
Vibration generated due to high gain could result in early damage to the servo motor.
- **Do not frequently turn the power supply on and off. After the start of actual operation (ordinary operation), allow at least one hour or more between turn-on and turn-off of the power supply. Do not use this product in applications that require frequent turn-on and turn-off of the relevant power supply.**
Failure to observe this instruction could result in early deterioration of driver components.
- **After completion of trial runs of the machine and equipment, create a backup file of driver parameters by using a PC application software. This backup file will be used for making parameter settings after driver replacement.**
If backed-up parameter values are not copied, a driver replaced due to a failure and so on cannot operate normally. In such cases, the machine and/or equipment could suffer failures and/or damage.

Precautions for Maintenance and Inspection

Danger

- **Do not change wiring while the product is energized.**
Failure to observe this instruction could result in an electrical shocks and/or injury.
- **Wiring and inspection must be implemented by a specialized engineer.**
Failure to observe this instruction could result in an electrical shock and/or a failure of the product.
- **Wiring and inspections must be made when the CHARGE lamp is off after at least one or more minutes have passed since power-off of the product. Since high voltage may remain in the driver after the power-off, do not touch the power terminal while the CHARGE lamp is on.**
Failure to observe this instruction could result in an electrical shock.
- **When it is necessary to replace the driver, back up the parameter values of the driver before its replacement. Copy the backed-up parameter values into the new driver and confirm that the values have been correctly copied.**
If backed-up parameter values are not copied, or if the copying operation is not correct, the replaced driver cannot operate normally. In such a case, the machine and/or equipment could suffer failure and/or damage.
- **If the safety device (a circuit breaker) installed in the power supply is activated, eliminate the cause of the activation, and then energize the driver. Securely eliminate the cause of the activation of the safety device by implementing repair, replacement, and wiring check related to the driver.**
Failure to observe this instruction could result in a fire, an electric shock, and/or injury.

Caution

- **If an alarm is issued, first eliminate the cause of the alarm to ensure safety. After that, reset the alarm or turn on the power supply again to restart operation.**
Failure to observe this instruction could result in injury and/or machine damage.

1. Before You Begin

Thank you very much for purchasing the SV-NET Driver.


After you receive and unpack the product, please check to see if it is the same model you ordered and for any damage that may have occurred during transportation. Should your product have any problems, please contact the dealer from whom you purchased the product.

1.1. Overview of the Product


The SV-NET Driver TAD8811 Series is the latest servo driver with the fastest speed and most advanced functions.

It has a compact main unit and auto-tuning function that works in combination with a personal computer to ensure easy and convenient use. It uses our own original fieldbus SV-NET as a network. Combined with the SV-NET controller (TA8441), it allows multi-axis interpolation. In spite of its compact dimensions, the driver supports I/O control with pulse and analog commands in addition to communication commands through SV-NET. The sensor can be selected from a wire-saving incremental encoder, a serial encoder, or a brushless resolver, or an external encoder may be used.

• 400W




• 750W



■ Model check

When you receive the product, check the model of the driver.



Details of described model

TAD8811 N 3 4 3 E 2 39
 (1) (2) (3)(4) (5) (6)

- (1) Basic model TAD8811 Series
- (2) Sensor type 1: Wire-saving incremental encoder(INC-SE)
 3: Serial encoder(Smart-ABS/INC)
 7: Brushless resolver (Smartsyn)
- (3) I/F voltage, drive voltage
- 1: 5V (I/F) / AC100V
 2: 5V (I/F) / AC200V
 3: 24V (I/F) / AC100V
 4: 24V (I/F) / AC200V
- (4) Driver rated output current (maximum current)
- 1: 1 Arms (3.4 Arms)
 2: 2 Arms (5.9 Arms)
 3: 4 Arms (11.3 Arms)
 4: 6 Arms (15.0 Arms)
- (5) Sensor specifications Refer to Table 1 (differs by sensor type)
- (6) Motor model Refer to Table 2 Standard Motor Models

Table 1 Sensor Specifications

| N No. / E No. | N1□□ | N3□□ | N7□□ |
|---------------|--|----------------------------|-------------------------|
| E0△△ | — | — | — |
| E1△△ | 2000 C/T wire-saving incremental encoder | 17-bit absolute encoder | 1X brushless resolver |
| E2△△ | 2048 C/T wire-saving incremental encoder | 17-bit incremental encoder | (2X brushless resolver) |
| E3△△ | 2500 C/T wire-saving incremental encoder | — | (4X brushless resolver) |
| E4△△ | — | — | — |
| E5△△ | — | 23-bit absolute encoder | — |
| E6△△ | — | 23-bit incremental encoder | — |
| E7△△ | — | — | — |

- Note:
- Those in () will be supported in the future.
 - "Wire-saving incremental encoder" is shown as "wire-saving INC" hereafter.
 - "17-/23-bit absolute encoder" is shown as "17-/23-bit-ABS" hereafter.
 - "17-/23-bit incremental encoder" is shown as "17-/23-bit-INC" hereafter.
 - "Brushless resolver" is shown as "BRX" hereafter.
 - In the driver format, the format after E900 is a special specification, please see the dedicated product specifications.

Table 2 Standard Motor Models

| TBL-i II Series | |
|----------------------|----------------------|
| Motor model | E No. $\Delta\Delta$ |
| TS4601 (30W – 200V) | E*31 |
| TS4602 (50W – 200V) | E*32 |
| TS4603 (100W – 200V) | E*33 |
| TS4604 (150W – 200V) | E*34 |
| TS4606 (100W – 200V) | E*36 |
| TS4607 (200W – 200V) | E*37 |
| TS4609 (400W – 200V) | E*39 |
| TS4610 (600W – 200V) | E*40 |
| TS4611 (200W – 200V) | E*41 |
| TS4612 (400W – 200V) | E*42 |
| TS4613 (600W – 200V) | E*43 |
| TS4614 (750W – 200V) | E*44 |
| | |
| TS4601 (30W – 100V) | E*51 |
| TS4602 (50W – 100V) | E*52 |
| TS4603 (100W – 100V) | E*53 |
| TS4604 (150W – 100V) | E*54 |
| TS4606 (100W – 100V) | E*56 |
| TS4607 (200W – 100V) | E*57 |
| TS4609 (400W – 100V) | E*59 |
| TS4611 (200W – 100V) | E*58 |

| TBL-i IV Series | |
|-----------------------|----------------------|
| Motor model | E No. $\Delta\Delta$ |
| TSM3101 (30W – 200V) | E*70 |
| TSM3102 (50W – 200V) | E*71 |
| TSM3104 (100W – 200V) | E*72 |
| TSM3201 (100W – 200V) | E*73 |
| TSM3202 (200W – 200V) | E*74 |
| TSM3204 (400W – 200V) | E*75 |
| TSM3301 (200W – 200V) | E*76 |
| TSM3302 (400W – 200V) | E*77 |
| TSM3303 (600W – 200V) | E*78 |
| TSM3304 (672W – 200V) | E*79 |
| | |
| TSM3101 (30W – 100V) | E*90 |
| TSM3102 (50W – 100V) | E*91 |
| TSM3104 (100W – 100V) | E*92 |
| TSM3201 (100W – 100V) | E*93 |
| TSM3202 (200W – 100V) | E*94 |
| TSM3301 (200W – 100V) | E*96 |
| | |

| TBL-i4s Series | |
|-----------------------|----------|
| Motor model | E No. △△ |
| TSM4102 (50W – 200V) | E*61 |
| TSM4104 (100W – 200V) | E*62 |
| TSM4202 (200W – 200V) | E*64 |
| TSM4204 (400W – 200V) | E*65 |
| TSM4303 (600W – 200V) | E*68 |
| TSM4304 (750W – 200V) | E*69 |

Product No. (Serial No.)

Example: C00015

Consecutive number

C: Safety standards conformance test qualified product

A: Safety standards conformance test non-qualified product

Model

Production year and month

Example: 2016, 11

Production month

Production year
(the Christian era of year)

| | |
|--|------------------------------------|
| SV-NET DRIVER | |
| TYPE | TAD8811N 344E144 |
| S/N | C00015 |
| DATE | 2016.11 |
| INPUT | AC200-230V 3Φ 5.6A/1Φ 9.7A 50/60Hz |
| OUTPUT | AC0-230V 750W 3Φ 5.0A 0-333Hz |
| TAMAGAWA SEIKI CO.,LTD. MADE IN TAIWAN | |

Output

Output voltage; Rated output of conforming motors; Number of phase of output;
Rated output current of conforming motors; Output frequency

Input

Input voltage; Rated input current corresponding to three-phase input/Rated
input current corresponding to single-phase input; Input frequency

■ Contents of nameplate

■ **Check if the Driver Model Is Compatible with the Combined Motor**

Use the tables below to check if the driver model is compatible with the motor you use.

Please specify based on the model appearance for combinations other than those listed below.


The current settings for each supported motor are as follows. These are the same regardless of resolution or sensor type.

(Ir: Rated current setting, Is: Stall current setting,
Ip: Instantaneous maximum current setting)

- TBL-i II Series (I/F voltage 24 V)

| Power supply specifications | Motor | | Current setting | | | Compatible driver |
|-----------------------------|--------------|-------------------|-----------------|-----------|-----------|-------------------|
| | Rated output | Model | Ir (Arms) | Is (Arms) | Ip (Arms) | Model |
| AC200V | 30W | TS4601 N**** E200 | 0.4 | 0.3 | 0.9 | TAD8811 N*41 E*31 |
| | 50W | TS4602 N**** E200 | 0.6 | 0.5 | 1.6 | TAD8811 N*41 E*32 |
| | 100W | TS4603 N**** E200 | 1.1 | 1.0 | 3.0 | TAD8811 N*41 E*33 |
| | 150W | TS4604 N**** E200 | 1.5 | 1.4 | 4.3 | TAD8811 N*42 E*34 |
| | 100W | TS4606 N**** E200 | 0.9 | 0.8 | 2.6 | TAD8811 N*41 E*36 |
| | 200W | TS4607 N**** E200 | 1.7 | 1.6 | 4.9 | TAD8811 N*42 E*37 |
| | 400W | TS4609 N**** E200 | 3.3 | 3.2 | 9.7 | TAD8811 N*43 E*39 |
| | 600W | TS4610 N**** E200 | 5.1 | 4.9 | 14.9 | TAD8811 N*44 E*40 |
| | 200W | TS4611 N**** E200 | 1.5 | 1.4 | 4.2 | TAD8811 N*42 E*41 |
| | 400W | TS4612 N**** E200 | 2.8 | 2.6 | 8.0 | TAD8811 N*43 E*42 |
| | 600W | TS4613 N**** E200 | 4.4 | 4.3 | 12.8 | TAD8811 N*44 E*43 |
| | 750W | TS4614 N**** E200 | 5.0 | 4.8 | 14.5 | TAD8811 N*44 E*44 |
| AC100V | 30W | TS4601 N**** E100 | 0.7 | 0.5 | 1.6 | TAD8811 N*31 E*51 |
| | 50W | TS4602 N**** E100 | 1.1 | 1.0 | 3.0 | TAD8811 N*31 E*52 |
| | 100W | TS4603 N**** E100 | 1.8 | 1.7 | 5.3 | TAD8811 N*32 E*53 |
| | 150W | TS4604 N**** E100 | 3.0 | 2.9 | 8.8 | TAD8811 N*33 E*54 |
| | 100W | TS4606 N**** E100 | 1.8 | 1.7 | 5.1 | TAD8811 N*32 E*56 |
| | 200W | TS4607 N**** E100 | 3.5 | 3.3 | 9.8 | TAD8811 N*33 E*57 |
| | 400W | TS4609 N**** E100 | 5.6 | 5.4 | 15.0 | TAD8811 N*34 E*59 |
| | 200W | TS4611 N**** E100 | 3.1 | 2.8 | 8.7 | TAD8811 N*33 E*58 |

Note: Items with an asterisk differ by motor or sensor specifications.



Danger


Running the equipment with a driver whose model is incompatible with the motor may result in damage not only to the driver and motor but also to the installed equipment. Such use may also result in unexpected machine movement and/or physical injury. Always use a driver compatible with the motor.

(I_r: Rated current setting, I_s: Stall current setting,
I_p: Instantaneous maximum current setting)

■ TBL-i IV Series (I/F voltage 24 V)

| Power supply specifications | Motor | | Current setting | | | Compatible driver |
|-----------------------------|--------------------|--------------------|-----------------------|-----------------------|-----------------------|-------------------|
| | Rated output | Model | I _r (Arms) | I _s (Arms) | I _p (Arms) | Model |
| AC200V | 30W | TSM3101 N**** E200 | 1.1 | 0.8 | 3.4 | TAD8811 N*41 E*70 |
| | 50W | TSM3102 N**** E200 | 1.1 | 0.9 | 3.4 | TAD8811 N*41 E*71 |
| | 100W | TSM3104 N**** E200 | 1.4 | 1.3 | 4.7 | TAD8811 N*42 E*72 |
| | 100W | TSM3201 N**** E200 | 1.4 | 1.2 | 4.6 | TAD8811 N*42 E*73 |
| | 200W | TSM3202 N**** E200 | 2.2 | 2.0 | 7.3 | TAD8811 N*43 E*74 |
| | 400W | TSM3204 N**** E200 | 3.5 | 3.4 | 11.3 | TAD8811 N*43 E*75 |
| | 200W | TSM3301 N**** E200 | 2.1 | 1.9 | 6.9 | TAD8811 N*43 E*76 |
| | 400W | TSM3302 N**** E200 | 3.7 | 3.5 | 11.3 | TAD8811 N*43 E*77 |
| | 600W | TSM3303 N**** E200 | 4.8 | 4.6 | 15.0 | TAD8811 N*44 E*78 |
| 672W | TSM3304 N**** E200 | 6.0 | 6.0 | 15.0 | TAD8811 N*44 E*79 | |
| AC100V | 30W | TSM3101 N**** E100 | 2.2 | 1.9 | 6.9 | TAD8811 N*33 E*90 |
| | 50W | TSM3102 N**** E100 | 2.1 | 1.9 | 6.8 | TAD8811 N*33 E*91 |
| | 100W | TSM3104 N**** E100 | 2.1 | 2.0 | 7.3 | TAD8811 N*33 E*92 |
| | 100W | TSM3201 N**** E100 | 2.5 | 2.2 | 8.1 | TAD8811 N*33 E*93 |
| | 200W | TSM3202 N**** E100 | 4.4 | 4.1 | 14.6 | TAD8811 N*34 E*94 |
| | 200W | TSM3301 N**** E100 | 4.2 | 3.8 | 13.7 | TAD8811 N*34 E*96 |

Note: Items with an asterisk differ by motor or sensor specifications.



Danger


Running the equipment with a driver whose model is incompatible with the motor may result in damage not only to the driver and motor but also to the installed equipment. Such use may also result in unexpected machine movement and/or physical injury. Always use a driver compatible with the motor.

(I_r: Rated current setting, I_s: Stall current setting,
I_p: Instantaneous maximum current setting)

■ TBL-i4s Series (I/F voltage 24 V)

| Motor | | | Current setting | | | Compatible driver |
|-----------------------------|--------------|--------------------|--------------------------|--------------------------|--------------------------|-------------------|
| Power supply specifications | Rated output | Model | I _r (Arms) | I _s (Arms) | I _p (Arms) | Model |
| AC200V | 50W | TSM4102 N**** E205 | 0.8 | 0.7 | 2.5 | TAD8811 N*41 E*61 |
| | 100W | TSM4104 N**** E205 | 0.9 | 0.8 | 3.0 | TAD8811 N*41 E*62 |
| | 200W | TSM4202 N**** E205 | 1.7 | 1.6 | 5.9 | TAD8811 N*42 E*64 |
| | 400W | TSM4204 N**** E205 | 2.8 | 2.7 | 9.5 | TAD8811 N*43 E*65 |
| | 600W | TSM4303 N**** E205 | 4.4 | 4.3 | 15.0 | TAD8811 N*44 E*68 |
| | 750W | TSM4304 N**** E205 | 4.9 | 4.7 | 15.0 | TAD8811 N*44 E*69 |

Note: Items with an asterisk differ by motor or sensor specifications.


Danger

Running the equipment with a driver whose model is incompatible with the motor may result in damage not only to the driver and motor but also to the installed equipment. Such use may also result in unexpected machine movement and/or physical injury. Always use a driver compatible with the motor.

1.2. Specifications

| Item | | Specifications | | | | | | | |
|-----------------------------|--|--|---|--|-----------|--|--------------------------------|-----------|-----------|
| Power supply specifications | Model | N*1*/N*3* | | | | N*2*/N*4* | | | |
| | | 100 VAC drive power supply | | | | 200 VAC drive power supply | | | |
| | | Single-phase: 100-115 VAC±10%, 50/60 Hz | | | | Single-phase/three-phase: 200-230 VAC±10%, 50/60 Hz | | | |
| | Model | N**1 | N**2 | N**3 | N**4 | N**1 | N**2 | N**3 | N**4 |
| | Rated continuous output current (Maximum value) | 1.1 Arms | 2.0 Arms | 4.0 Arms | 5.6 Arms | 1.1 Arms | 2.0 Arms | 4.0 Arms | 6.0 Arms |
| | Maximum momentary output current (Maximum value) | 3.4 Arms | 5.9 Arms | 11.3 Arms | 15.0 Arms | 3.4 Arms | 5.9 Arms | 11.3 Arms | 15.0 Arms |
| | Input current | Differs depending on the motor combination. See the next page. | | | | | | | |
| Environmental condition | Operating temperature | 0 to +40°C | | | | | | | |
| | Storage temperature | -10 to +65°C (no freezing and no condensation) | | | | | | | |
| | Operating humidity | 90%RH or less (no freezing and no condensation) | | | | | | | |
| | Storage humidity | 90%RH or less (no freezing and no condensation) | | | | | | | |
| | Vibration resistance | 4.9 m/s ² or less | | | | | | | |
| | Shock resistance | 19.6 m/s ² or less | | | | | | | |
| | Pollution degree | 2 or 1 | | | | | | | |
| | Elevation | 1,000 m or less above sea level | | | | | | | |
| Conformance to standards | Euro EC Directives (*1) | EMC Directive | EN55011 group1 classA EN61000-6-2 EN61800-3 (category C3) | | | | | | |
| | | Low Voltage Directive | EN61800-5-1:2007 | | | | | | |
| | UL standards (*2) | UL508C | | | | | | | |
| | Short-circuit current rating (SCCR) | 5,000 A | | | | | | | |
| | Overvoltage category | III | | | | | | | |
| | USB communication specifications | USB 2.0 CDC Class original protocol | | | | | | | |
| | SV-NET communication specifications | Communication protocol: SV-NET Physical layer: CAN Maximum number of connections: 63 | | | | | | | |
| | Sensor | Wire-saving incremental encoder INC-SE | | Serial encoder Smart-ABS/INC | | | Brushless resolver Smartsyn | | |
| | Position resolution | 4x sensor resolution (*3) | | 2 ¹⁷ 2 ²³ (1/rev) (*5) | | | (*4) | | |
| | LEAD/LAG/Z output | Yes | | | | | | | |
| | Monitor output | Yes | | | | | | | |
| | Combined motor | TBL-i II, TBL-i IV, TBL-i4s Series | | | | | | | |
| | Maximum output of motor combination | 400W | | | | 750W | | | |
| | Mechanical brake control output | No (control signal output is possible) | | | | | | | |
| | Dynamic brake circuit | Yes | | | | | | | |
| | Regeneration circuit | Yes (resistor externally installed) | | | | | | | |
| | Number of control rotations | 6000 rpm max (*5) | | | | | | | |
| | Rotation direction definition | CCW rotation as seen from the motor shaft end shall be the forward direction. (*6) | | | | | | | |
| | Recommended load inertia | Not more than 30 times the motor inertia | | | | | | | |
| | External dimensions (mm) | N**1 to N**3: 145 x 43 x 160 (height x width x depth) N**4: 145 x 63 x 160 (height x width x depth) (Excluding connector dimensions) | | | | | | | |
| | Mass | N**1 to N**3: Approx. 0.8 kg N**4: Approx. 1.0 kg | | | | | | | |

- (*1) Products produced in 2016 or earlier (first letter of Serial No. is "A") do not conform to this standards test.
- (*2) Products produced in 2016 or earlier (first letter of Serial No. is "A") and products other than the standard types described in this instruction manual do not conform to this standards test.
- (*3) In wire-saving incremental encoders, the position resolution is four times the number of sensor C/Ts.
Example: In the 2048C/T wire-saving incremental encoder, the position resolution is 8192 (1/rev).
- (*4) In brushless resolvers, the position resolution is [the number of shaft angle multipliers] × 2048 (1/rev).
Example: 1X resolver: 2048 (1/rev)
- (*5) Differs depending on the motor combination.
- (*6) The rotation direction definition can be changed by altering the parameters.

▪ **Input current and loss (I/F voltage 24V)**

| Model | Motor combination models | Rated motor output (W) | Input current | | Driver loss (W) |
|-----------------|--------------------------|------------------------|--------------------------|---------------------------|-----------------|
| | | | Three-phase input (Arms) | Single-phase input (Arms) | |
| TAD8811N*41E*31 | TS4601N****E200 | 30 | 0.6 | 0.8 | 10.4 |
| TAD8811N*41E*32 | TS4602N****E200 | 50 | 0.7 | 1.1 | 11.3 |
| TAD8811N*41E*33 | TS4603N****E200 | 100 | 1.2 | 2.0 | 17.3 |
| TAD8811N*42E*34 | TS4604N****E200 | 150 | 1.5 | 2.6 | 17.1 |
| TAD8811N*41E*36 | TS4606N****E200 | 100 | 1.1 | 1.9 | 13.6 |
| TAD8811N*42E*37 | TS4607N****E200 | 200 | 1.7 | 3.0 | 19.0 |
| TAD8811N*43E*39 | TS4609N****E200 | 400 | 3.3 | 5.6 | 30.1 |
| TAD8811N*44E*40 | TS4610N****E200 | 600 | 4.2 | 7.7 | 40.8 |
| TAD8811N*42E*41 | TS4611N****E200 | 200 | 1.8 | 3.2 | 17.8 |
| TAD8811N*43E*42 | TS4612N****E200 | 400 | 3.1 | 5.3 | 25.4 |
| TAD8811N*44E*43 | TS4613N****E200 | 600 | 4.2 | 7.7 | 50.0 |
| TAD8811N*44E*44 | TS4614N****E200 | 750 | 5.6 | 9.7 | 53.9 |
| TAD8811N*41E*70 | TSM3101N***E200 | 30 | 0.7 | 1.1 | 11.6 |
| TAD8811N*41E*71 | TSM3102N***E200 | 50 | 0.9 | 1.3 | 12.7 |
| TAD8811N*42E*72 | TSM3104N***E200 | 100 | 1.2 | 2.1 | 19.4 |
| TAD8811N*42E*73 | TSM3201N***E200 | 100 | 1.2 | 1.9 | 15.9 |
| TAD8811N*43E*74 | TSM3202N***E200 | 200 | 1.9 | 3.3 | 18.1 |
| TAD8811N*43E*75 | TSM3204N***E200 | 400 | 3.0 | 5.4 | 35.1 |
| TAD8811N*43E*76 | TSM3301N***E200 | 200 | 1.9 | 3.2 | 21.4 |
| TAD8811N*43E*77 | TSM3302N***E200 | 400 | 3.0 | 5.4 | 32.7 |
| TAD8811N*44E*78 | TSM3303N***E200 | 600 | 4.0 | 7.6 | 46.7 |
| TAD8811N*44E*79 | TSM3304N***E200 | 672 | 4.7 | 8.8 | 64.0 |
| TAD8811N*31E*51 | TS4601N****E100 | 30 | — | 1.2 | 9.7 |
| TAD8811N*31E*52 | TS4602N****E100 | 50 | — | 1.6 | 12.0 |
| TAD8811N*32E*53 | TS4603N****E100 | 100 | — | 2.7 | 17.0 |
| TAD8811N*33E*54 | TS4604N****E100 | 150 | — | 3.6 | 21.4 |
| TAD8811N*32E*56 | TS4606N****E100 | 100 | — | 2.6 | 15.6 |
| TAD8811N*33E*57 | TS4607N****E100 | 200 | — | 4.4 | 27.0 |
| TAD8811N*34E*59 | TS4609N****E100 | 400 | — | 8.1 | 46.7 |
| TAD8811N*33E*58 | TS4611N****E100 | 200 | — | 4.4 | 23.3 |

The above-listed values are net values corresponding to the rated motor output.

▪ Input current and loss (I/F voltage 24V)

| Model | Motor combination models | Rated motor output (W) | Input current | | Driver loss (W) |
|-------------------|--------------------------|------------------------|--------------------------|---------------------------|-----------------|
| | | | Three-phase input (Arms) | Single-phase input (Arms) | |
| TAD8811 N*33 E*90 | TSM3101 N****E100 | 30W | — | 1.4 | 11.4 |
| TAD8811 N*33 E*91 | TSM3102 N****E100 | 50W | — | 1.8 | 13.1 |
| TAD8811 N*33 E*92 | TSM3104 N****E100 | 100W | — | 2.8 | 13.7 |
| TAD8811 N*33 E*93 | TSM3201 N****E100 | 100W | — | 2.7 | 13.9 |
| TAD8811 N*34 E*94 | TSM3202 N****E100 | 200W | — | 4.6 | 29.7 |
| TAD8811 N*34 E*96 | TSM3301 N****E100 | 200W | — | 4.5 | 27.5 |
| TAD8811N*41 E*61 | TSM4102N****E205 | 50W | 0.7 | 1.1 | 14.9 |
| TAD8811N*41 E*62 | TSM4104N****E205 | 100W | 1.1 | 1.9 | 16.4 |
| TAD8811N*42E*64 | TSM4202N****E205 | 200W | 1.8 | 3.1 | 18.2 |
| TAD8811N*43E*65 | TSM4204N****E205 | 400W | 3.0 | 5.3 | 28.7 |
| TAD8811N*44E*68 | TSM4303N****E205 | 600W | 4.2 | 7.8 | 39.4 |
| TAD8811N*44E*69 | TSM4304N****E205 | 750W | 5.1 | 9.2 | 48.6 |

The above-listed values are net values corresponding to the rated motor output.

1.3. Standard Functions

| | | |
|-------------------------------|--|---|
| Control mode | | Position, speed, current, and simplified control |
| Pulse command input | Pulse command input | <ul style="list-style-type: none"> ▪ Forward/reverse pulse ▪ Pulse/rotation direction |
| | Positioning accuracy | Within ± 1 pulse (regulated standard) (*1) |
| Analog command input | Speed command input Current command input | Command scale and polarity settable with parameters Factory settings: 5,000 rpm/10 V, 5 Arms/10 V |
| | Specified resolution | ± 11 bit |
| Electronic gear | | Increases specified pulse by (N/M) times and controls position N: Number of command pulses that are input to rotate the motor shaft by M turns (1 to 2^{30}) M: Number of turns of the motor shaft for the number of command pulses (N) (1 to 2^{14}) |
| Gain switch function | | Servo gain pattern switching possible with position deviation, speed command values. Also switchable with signals |
| External encoder input | | Load shaft encoder is fed back and allows control in the fully closed position. |
| Recommended load inertia | | Not more than 30 times the motor inertia |
| Rotation direction | | Variable using parameters (normal direction set as CCW in factory settings) |
| Parameters | | Parameters can be set using communication (USB, SV-NET, RS485, ModbusRTU) or the front settings panel. <ul style="list-style-type: none"> ▪ Control mode ▪ Position loop gain ▪ Speed loop gain ▪ Speed loop accumulated time ▪ Feed forward amount ▪ Resonance filter ▪ Speed limit ▪ Current limit ▪ In-position range ▪ Analog command scale ▪ Analog command offset ▪ Acceleration limit ▪ Encoder division output settings ▪ Electronic gear ratio ▪ Overspeed alarm level ▪ Overload alarm level Other |
| Sensor | | Wire-saving incremental encoder (wire-saving INC) Serial encoder (17bit-ABS, 17bit-INC, 23bit-ABS, 23bit-INC) Brushless resolver (1X-BRX) Sensor selectable from these |
| Regeneration function | | Built-in regeneration circuit Resistor installed externally (option) |
| Dynamic brake | | Built-in dynamic brake Operating conditions set using parameters |
| Mechanical brake drive output | | None (brake control signal settable in I/O output) |
| Sensor signal output | | LEAD, LAG, Z output |
| Monitor output | | Motor current, speed feedback, other monitor output |
| Protective functions | Hardware errors | Overspeed, power element error (overcurrent), sensor error, drive power error, EEPROM error, CPU error, etc. |
| | Software errors | Overload, excessive deviation, etc. |
| Alarm history | | Records the past 8 alarms, including present one Saving/viewing function for alarm details |
| Display, settings | | 5 rows for display LEDs 4 setting buttons Shows control mode, alarm, control signal input status, etc. |
| Communication | | USB $\times 1$ SV-NET(CAN) $\times 2$ RS-485 $\times 2$ ModbusRTU $\times 2$ |

(*1) Theoretical value for drivers. The actual positioning accuracy is determined depending on the motor load and the sensor accuracy.

1.4. SV-NET

SV-NET is a medium-speed field network that uses the CAN physical layer. It uses a simple protocol designed solely for motion control and with unnecessary functions eliminated to reduce transmission time.

■ MAC-ID

SV-NET uses master and slave relationships. A master is a host controller such as a motion controller or a PC. A slave is a driver or an I/O unit. There is one master device, but more than one slave device may be connected. Therefore media access control identifiers (MAC-IDs) unique within the network must be set for each slave. Setting non-unique identifiers causes data collision, leading to incorrect communication.

■ Host controller (master) MAC-ID


The MAC-ID for the host controller (master) is always "0."

■ Driver (slave) MAC-ID


The MAC-ID of a driver can be set to a value from 1 to 63. Any number can be set as long as it is unique.

■ Configuration of the SV-NET Motion Control System

Example: Connect three drivers to the host controller and set the servo ON for the driver (motor) of MAC-ID=2.



1.5. SV-NET Motion Controller



The SV-NET controller is the motion controller for SV-NET.

Up to eight axes of drivers can be connected, allowing for linear interpolation, circular interpolation, and sync control. Functions such as programming and real-time monitoring using a PC and stand-alone operations that use programming created by the user can be used. It comes equipped with I/O as standard, allowing you to build a compact motion control system using the SV-NET controller, driver, and motor.

(There are also models compatible with Ethernet and CC-Link.)

1.6. Operating from a Personal Computer

TAD8811 is capable of making parameter changes, auto-tuning, and simple operating tests directly from a personal computer via USB communication with the driver main unit.

We provide "Motion Designer Drive" and "Motion Adjuster" as dedicated applications (for free). When you first use this product, use "Motion Designer Drive."

•URL for downloading the dedicated applications:

http://sv-net.tamagawa-seiki.com/download/download_software.html

You can browse the instruction manual for each dedicated application by using the help function of the application.

1.7. Maintenance and Inspection of Servo Driver

The following explains the maintenance and inspection of the driver.

■ Inspection of driver

To safely use the driver, conduct the following inspections at least once a year.

| Inspection item | Inspection method |
|------------------------------|---|
| Appearance inspection | Check that there is no dirt, dust, or oil adhering. |
| Loosen screws and connectors | Check that terminals and connectors are not loose. |

■ Replacement of driver parts

The electric and electronic parts inside the driver deteriorate over time. To ensure preventive maintenance of those parts, contact us at the time of parts replacement by referring to the standard replacement periods shown in the table below as a guide.

| Part name | Standard replacement period |
|---------------------------------------|-----------------------------|
| Smoothing capacitors | 4 to 5 years |
| Other aluminum electrolyte capacitors | 4 to 5 years |
| Relays | - |
| Battery for calendar function backup | 4 to 5 years |

Note) The following usage conditions are assumed for the above replacement periods.

- Ambient temperature: annual average of 30°C
- Load factor: 80% or less
- Operation rate: 20 hours or less per day




Important

We will reset parameters of drivers that we receive for maintenance and inspection back to their factory settings.
We ask that customer always record the values they set.


2. Names and Functions of Parts

2.1. Names of Parts

● 400W




● 750W



- | | |
|--|---|
| (1) I/O connector (CN1) | (7) Drive power supply connector (TB1) |
| (2) Sensor connector (CN2) | (8) Motor/external resistor connector (TB2) |
| (3) Manufacturer maintenance connector (CN4) | (9) Grounding terminal (Frame ground) |
| (4) SV-NET/485 connector (CN5/6) | (10) Settings panel |
| (5) USB connector (CN7) | (11) CHARGE lamp |
| (6) Analog monitor output connector (CN8) | (12) Heat sink |

2.2. Block Diagram




TB1, TB2: Hazardous voltage DVC C (Decisive voltage class C)

CN1, CN2, CN4, CN5, CN6, CN7, CN8: Safe voltage DVC A (Decisive voltage class A)

2.3. Functions of Parts

(1) I/O connector

Connect in order to control using analog and pulse commands. This connector connects other input and output signals.

| | Pin No. | Signal Name | Function (factory settings) | I/O |
|----|---|-------------|---|---|
| |  <p>Header 10250-52A2PL (made by 3M)</p> | 1 | +CON | Common power supply for digital input |
| 2 | | +CON | Common power supply for digital input | |
| 3 | | IN1 | Input 1 (servo ON input) | General-purpose digital input |
| 4 | | IN2 | Input 2 (Forward-rotation drive disable input) | General-purpose digital input |
| 5 | | IN3 | Input 3 (Reverse-rotation drive disable input) | General-purpose digital input |
| 6 | | IN4 | Input 4 (alarm reset input) | General-purpose digital input |
| 7 | | IN5 | Input 5 (deviation reset input) | General-purpose digital input |
| 8 | | IN6 | Input 6 (external alarm input) | General-purpose digital input |
| 9 | | IN7 | Input 7 (origin point sensor input) | General-purpose digital input |
| 10 | | IN8 | Input 8 (pulse input disable command) | General-purpose digital input |
| 11 | | N•C | | Unconnectable |
| 12 | | N•C | | Unconnectable |
| 13 | | N•C | | Unconnectable |
| 14 | | N•C | | Unconnectable |
| 15 | | F-PLS1+ | Pulse input 1 (Forward-rotation command pulse) | Open collector input or line driver input |
| 16 | | F-PLS+ | | |
| 17 | | F-PLS- | | |
| 18 | | N•C | | Unconnectable |
| 19 | | R-PLS1+ | Pulse input 2 (Reverse-rotation command pulse) | Open collector input or line driver input |
| 20 | | R-PLS+ | | |
| 21 | | R-PLS- | | |
| 22 | | N•C | | Unconnectable |
| 23 | | +5V | Internal control supply power +5V | Unconnectable |
| 24 | | ANALOG-IN+ | Analog command input | Analog input |
| 25 | | ANALOG-IN- | Analog command GND | |
| 26 | | MONITOR2 | Analog monitor output 2 | |
| 27 | | MONITOR1 | Analog monitor output 1 | |
| 28 | | GND | Digital ground | |
| 29 | | GND | Digital ground | |
| 30 | | OUT1+ | Output 1 (alarm signal) | General-purpose digital output |
| 31 | | OUT1- | | |
| 32 | | OUT2+ | Output 2 (in-position signal) | General-purpose digital output |
| 33 | | OUT2- | | |
| 34 | | OUT3+ | Output 3 (servo ready signal) | General-purpose digital output |
| 35 | | OUT3- | | |
| 36 | | OUT4+ | Output 4 (brake control signal) | General-purpose digital output |
| 37 | | OUT4- | | |
| 38 | | OUT5+ | Output 5 (stop speed status signal) | General-purpose digital output |
| 39 | | OUT5- | | |
| 40 | | EX-LEAD+ | External encoder input | Line driver input |
| 41 | | EX-LEAD- | | |
| 42 | | EX-LAG+ | | |
| 43 | | EX-LAG- | | |

| Pin No. | Signal Name | Function (factory settings) | I/O |
|---------|-------------|-----------------------------|--------------------|
| 44 | LEAD+ | Sensor signal output | Line driver output |
| 45 | LEAD- | | |
| 46 | LAG+ | | |
| 47 | LAG- | | |
| 48 | Z+ | | |
| 49 | Z- | Digital ground | |
| 50 | GND | | |


■ Opposite connector
 Plug 10150-3000PE (made by 3M)
 Shell 10350-52F0-008 (made by 3M)

Tightening torque (M2.6 screws): 0.15 to 0.25 N·m

(2) Sensor connector

This connector connects the sensor cable of the motor.

| Pin No. | Smartsyn | Encoder 17-/23-Bit-INC/ABS | Encoder Wire-saving INC |
|---------|--------------------------|----------------------------|-------------------------|
| 1 | S2 (resolver output) | — | A, UE |
| 2 | S4 (resolver output) | — | A/, UE/ |
| 3 | S1 (resolver output) | — | B, VE |
| 4 | S3 (resolver output) | — | B/, VE/ |
| 5 | R1 (resolver excitation) | SD | Z, WE |
| 6 | R2 (resolver excitation) | SD/ | Z/, WE/ |
| 7 | — | — | — |
| 8 | — | — | — |
| 9 | — | +5V | +5V |
| 10 | — | GND | GND |
| 11 | — | — | — |
| 12 | — | — | — |
| 13 | — | — | — |
| 14 | — | — | — |
| 15 | — | — | — |
| 16 | — | — | — |
| 17 | — | — | — |
| 18 | — | — | — |
| 19 | Shield | Shield | Shield |
| 20 | — | — | — |



Header
10220-52A2PL
(made by 3M)

■ Opposite connector
 Plug 10120-3000PE (made by 3M)
 Shell 10320-52A0-008 (made by 3M)


Tightening torque (M2.6 screws): 0.15 to 0.25 N·m

(3) Manufacturer maintenance connector

This connector is used for manufacturer maintenance. It is not used in ordinary operation.

(4) SV-NET/RS485 connector


This connector is used to connect the SV-NET/RS485 cable.

|  <p>Header 1-1827876-3 (made by TE Connectivity)</p> | Pin No. | Function |
|--|---------|---------------------------------|
| | A1 | CAN H (+)/RS485(A) |
| | B1 | CAN L (-)/RS485(B) |
| | A2 | +5V |
| | B2 | GND |
| | A3 | * 120 Ω terminator resistor end |
| | B3 | GND |
| <p>■ Opposite connector Receptacle housing 1-1827864-3 (made by TE Connectivity) Receptacle contact 1827588-2 (made by TE Connectivity) AWG24-28</p> | | |

* The 120 Ω terminator resistor is internally wired to CAN (-).

(5) USB connector

This connector connects the USB cable.


|  <p>Header 8968-B04COORW (made by OUPIN)</p> | Pin No. | Function |
|---|---------|----------|
| | 1 | |
| | 2 | USB-DM |
| | 3 | USB-DP |
| | 4 | GND |

(6) Analog monitor output connector(debugging connector)

Output for the monitor is provided.

Analog monitor outputs 1 and 2 are shared with the I/O connector.

"OUT2" is the signal from "output 2" of the I/O connector. It is a source signal that is not photocoupler isolated.

|  <p>Header 2417RJ-04-PHD (made by Neltron)</p> | Pin No. | Function |
|---|---------|----------------------------|
| | 1 | Analog monitor output 1 |
| | 2 | Analog monitor output 2 |
| | 3 | OUT2/(in-position signal/) |
| | 4 | GND |
| <p>■ Opposite connector Terminal 2418TJ-PHD (made by Neltron) AWG24-28</p> | | |

(7) Drive power supply connector

This is the connector for inputting the driver power supply.

| <p>Connector 0135-39-6589-03 (made by DINKLE)</p> | Pin No. | Function |
|--|---------|----------|
| | 1 | L1 |
| | 2 | L2 |
| | 3 | L3 |
| <p>■ Opposite connector (accessory): Socket 0134-32-6588-03 (made by DINKLE)</p> | | |

* Connect to L1 and L3 for single-phase 100 VAC.

(8) Motor/external resistor connector

This connector connects the motor cable of the motor.

| <p>Connector 0135-1505 (made by DINKLE)</p> | Pin No. | Function |
|--|---------|----------|
| | 1 | B1 |
| | 2 | B2 |
| | 3 | U-phase |
| | 4 | V-phase |
| | 5 | W-phase |
| <p>■ Opposite connector (accessory): Socket 0134-1105 (made by DINKLE)</p> | | |


(9) Grounding terminal (Frame ground)

This is the ground terminal directly connected to the frame.

| | Remarks |
|--|--|
| | <p>Be sure to connect it to the grounding electrode (earth (PE)) by using M4 screws. Tightening torque: 0.7 to 0.8 N·m Use AWG14 (2.5 sq) as wire rod.</p> |

(10) Settings panel


This is the panel for making driver settings using the buttons.

|  | <table border="1"><thead><tr><th data-bbox="612 259 1212 344">Remarks</th></tr></thead><tbody><tr><td data-bbox="612 344 1212 546">Refer to □20 "Settings Panel Operation" for details.</td></tr></tbody></table> | Remarks | Refer to □20 "Settings Panel Operation" for details. |
|---|---|---------|--|
| Remarks | | | |
| Refer to □20 "Settings Panel Operation" for details. | | | |

(11) CHARGE lamp

This lamp indicates that the driver still contains an electrical charge.

3. Connection Example



4. Conformance to Standards

■ EC Directives

To facilitate the conformance of incorporated machines and equipment to EC Directives, we comply with standards related to the Low Voltage Directive.

- Equipment environment

Use the product under an environment at a pollution degree 2 or 1.

Make sure to connect the power supply to a circuit breaker that meets IEC standards and UL standards (rated voltage: 230 V; rated current: 15 A).

For wiring, use AWG14 (2.5 sq) copper conductor wires with a temperature rating of 75°C or higher.

- Short-circuit current rating (SCCR)

This servo driver is compatible with a power supply of 253 VAC or lower with symmetrical waveform current of 5,000 A or less.

- Grounding system

The grounding method for the power distribution system supports the TT/TN system.

- Grounding

Be sure to connect the grounding terminal (frame ground) of the servo driver to the grounding electrode (PE) by using a wire rod of AWG14 (2.5 sq) or higher.

- Installation

Be sure to mount the product within a metal case (control panel).

■ Conformance to European EMC Directives

Servo drivers are not intended for use in ordinary households and with low-voltage public communication lines. Connection to such circuits may cause radio frequency interference.

We use noise filters, surge protectors, and ferrite cores in the EMC Directive conformance tests. Machine and equipment conformance with EMC Directives needs to be confirmed by using the final machine and equipment into which a servo driver and a servo motor are incorporated.

■ Conformance to US UL Standards


- **Equipment environment**
 Use the product under an environment of pollution degree 2 or 1.
 Make sure to connect the power supply to a circuit breaker qualified by the IEC standards and the UL standards (rated voltage: 230 V; rated current: 15 A).
 For wiring, use AWG14 (2.5 sq) copper conductor wires with a temperature rating of 75°C or higher.
- **Short-circuit current rating (SCCR)**
 This servo driver is compatible with a power supply of 253 VAC or lower with symmetrical waveform current of 5,000 A or less.
- **Branch circuit protection**
 The short-circuit protection circuit within the product cannot be used for branch circuit protection.
 Implement branch circuit protection in accordance with the National Electrical Code (NEC) and relevant regional standards.
- **Overload protection and overheat protection**
 The servo driver is equipped with an overload protection function.
 The overload protection function works at 105% or more of the rated output current.
- **Grounding system**
 The grounding method for the power distribution system supports the TT/TN system.
- **Grounding**
 Be sure to connect the grounding terminal (frame ground) of the servo driver to the grounding electrode (PE) by using a wire rod of AWG14 (2.5 sq) or higher.
- **Installation**
 Be sure to mount the product within a metal case (control panel).

4.1. Conformance to Standards

| | | |
|--------------------|-----------------------|---|
| Euro EC Directives | EMC Directives | EN55011 group1 ClassA EN61000-6-2 EN61800-3 (Category C3) |
| | Low Voltage Directive | EN61800-5-1:2007 |
| UL standards | | UL508C |

4.2. EMC Installation Environment

The following diagrams illustrate installation conditions for EMC qualification tests.



| Symbol | Name | Our models and specifications |
|--------|--------------------------|-------------------------------|
| (1) | Power cable, ground wire | AWG14 wire, UL1015 |
| (2) | USB cable | EUA1459 (shielded wire) |
| (3) | I/O cable | EUA1424 (shielded wire) |
| (4) | SV-NET cable | EUA1354 (shielded wire) |
| (5) | Sensor cable | EUA1283 (shielded wire) |
| (6) | Motor cable | EUA1280 (shielded wire) |

*1. Dedicated application software: Motion Designer Drive

*2. Host controllers are not connected.


■ Conditions necessary for conforming to European EMC Directives

- The servo driver shall be installed within a metal case (control panel).
- A noise filter and a lightning surge protecting part (surge protector) shall be installed on the power line.
- Shield braid cables shall be used for input and output signal (I/O) cables and sensor cables.
- As illustrated in the connection diagram on p. 33, a ferrite core and a core filter shall be installed on each cable connected to the servo driver.

The above conditions are the installation conditions used in our EMC Directive qualification tests. In actual application with your equipment, the EMC level differs depending on the connected devices and the wiring status. Since this product is incorporated into other equipment, it is necessary to confirm its performance on your final machine and equipment for which EMC measures have been implemented.

- Ferrite core
NF1, NF2: E04SR200932 (Seiwa Electric Mfg. Co., Ltd.)
- Core filter
NF3: RN603620MD (FDK)
In installation of a core filter, collectively wind the U, V, and W lines on the core by several turns to ensure effective noise reduction (Do not pass the FG line through the core). If the required noise reduction is not achieved then increase the turns or implement some other measure.
- Circuit breaker
Install a circuit breaker that meets IEC standards and UL standards (rated voltage: 230 V; rated current: 15 A) between the power supply and the noise filter.
- Noise filter
3SUP-HU10-ER-6 (Okaya Electric Industries Co., Ltd.)
For detailed noise filter specifications, please contact the noise filter manufacturer.
- Surge protector
R•A•V-781BXZ-4 (Okaya Electric Industries Co., Ltd.)
For the detailed surge protector specifications, please contact the surge protector manufacturer.
- Grounding terminal
Be sure to connect the grounding terminal (frame ground) of the servo driver to the metal case (control panel) in order to prevent electrical shocks.
- Structure of the metal case (control panel)
In the metal case (control panel), openings made at the holes for cables, holes for mounting the console, the door, and so on might cause leakage and intrusion of radio waves. To prevent this, comply with the following items when designing and selecting a control panel.
 - Be sure to use a metal control panel (make sure it is electrically conductive).
 - Ground all units mounted within the case to it.


5. Process Flow




6. Installation (Installing to Equipment)

When mounting the driver (installation to the equipment), use the M4 screw mounting holes on the base chassis (two holes).

■ 400W (N No. Model: N**1 to N**3)



■ 750W (N No. Model: N**4)




■ **Installation place**

Mount the driver in a control panel (metal case) in an indoor location that is not subject to rainwater and direct sunlight and that is surrounded only by non-combustible objects.

■ **Installation gaps with other equipment**


The driver requires a surrounding air space for ventilation. Install the driver while maintaining the predetermined distances shown below from the other equipment.



■ Measures to cool the driver

Repeatedly running the driver close to its ratings results in more heat being generated. In such cases, the ambient temperature of the driver might increase under environments where the heat does not easily dissipate such as enclosed spaces. When the ambient temperature of the driver is expected to exceed its operating temperature range, implement the following cooling measures within the control panel and install the driver appropriately so that its ambient temperature will be within its operating temperature range. To find the steady loss of the driver (at the rated output) see "1.2 Specifications."

- Install a cooling fan or ventilation opening.
- Install the driver on a metal surface, which provides greater heat dissipation.
(Driver heat sink: Aluminum (ADC12))




7. Connection Method



Turn off the power before performing connection operations. After turning off the power, allow adequate time to check the voltage with a tool such as a tester before performing connection and wiring operations. Wiring errors may cause failures and/or fires.

7.1. Connecting the Power Supply

■ Example of power supply connection



○ **Power Supply Cable**


■ **Connection example**

| | |
|---------------------------------|---|
| Single-phase/three-phase AC200V | 1 |
| Single-phase AC100V | 2 |
| | 3 |

■ **Parts for power supply cable**


| Part name | Model or spec. | Maker | Remarks |
|-------------|----------------------|--------|---------|
| (1) Housing | 0134-3103 | DINKLE | |
| (2) Cable | AWG 14 or equivalent | - | |

⇒ □ Refer to 22.1 "Optional Parts"



■ Peripherals connection example

This information is for reference only. Set up peripherals according to the system to be built.



Power supply

- Applied voltage must be within the specification range.
- Symmetrical waveform current must be 5,000 Arms or less.

Circuit breaker

- Be sure to install a circuit breaker that meets IEC standards and the UL standards (rated current: 15 A) as an overcurrent protective device.

Noise filter (NF)

- The noise filter reduces high-frequency noise generated by the power supply to prevent malfunction. It also reduces effects from driver noise.

Electromagnetic contact (MC)

- Use the electromagnetic contact to shut off the power supply for safety purposes if an alarm or system error occurs.
- Wire it so that the power supply to the main circuit can be shut off and the servo turned off if an error occurs.
- Select an appropriate type for the output of the servo motor to be connected.

Power-factor improvement reactor

- The power-factor improvement reactor improves input power factors.
- It reduces the harmonic current of the power supply.


Surge protector

- The surge protector protects the system from sudden high voltage and high current such as from induced lightning.

Grounding

- Be sure to connect the grounding terminal (frame ground) of the driver to the grounding electrode (earth (PE)) by using an AWG14 (2.5 sq) wire.

7.2. Connecting the USB



Parameter management and running tests can easily be implemented by using a dedicated application (free application), "Motion Designer Drive" or "Motion Adjuster." (The SV-NET motion controller is not necessary.)

Supplement

To find methods for using the dedicated applications, see the relevant instruction manual by using the help function of each application.

USB cable

As a USB cable, use the specified cable (EUA1459) below. We do not guarantee operation with any cable other than the specified cable.

Personal computer

Since some types of personal computers are easily affected by noise, their USB connection tends to often disconnect. Note that this tendency is particularly strong when using a desktop computer or using in connection via a USB hub.

Successful connection to all USB communication devices is not guaranteed.

■ Specifications of designated cable

USB cable (between the personal computer and the driver) Model: EUA1459****

■ Connection

| | | | | | |
|-------|--------------|--|--|--|-------|
| 1 | 22AWG Red | | | | 1 |
| 2 | 28AWG White | | | | 2 |
| 3 | 28AWG Green | | | | 3 |
| 4 | 22AWG Black | | | | 4 |
| SHELL | Braid shield | | | | SHELL |

■ Parts for USB cable

| Part name | Model or spec. | Maker | Remarks |
|--------------------|-------------------------------|----------------------------------|-----------------------|
| (1) Shielded cable | USB2.0 A (male) - B (male) | | |
| (2) Ferrite core | E04SR211132 | Seiwa Electric Mfg. Co., Ltd. | Number of turns: 2 |

7.3. Connection by SV-NET/RS485


This driver is equipped with two connectors for SV-NET/RS485 communication. However, since these are daisy-chain connection connectors, their communication specifications are exclusive. Therefore, the two connectors cannot be used independently for different communication specifications. Select either SV-NET or RS485 by using ID141 "Special Function Switching."

The driver-driver connecting SV-NET cable (EU1287) and the SV-NET terminal connector (EUA1294) can also be used for RS485 communication.

⇒ The internal circuit is illustrated in □22.2 "External Connection Diagram."

■ SV-NET connector

| <p>Header 1-1827876-3 (made by TE Connectivity)</p> | Pin No. | Function |
|---|---------|-------------------------------|
| | A1 | CAN H (+)/RS485(A) |
| | B1 | CAN L (-)/RS485(B) |
| | A2 | +5V |
| | B2 | GND |
| | A3 | 120 Ω terminator resistor end |
| | B3 | GND |



■ Cable specifications

SV-NET Cable (between Controller and Driver) Model: EUA1354N****

■ Connection

1-1827864-3 734-105

CAN+ White 1 GND

CAN- Blue 2 CAN-

- Black 3 SHIELD

GND 4 CAN+

- Drain wire 5 +24V

SHIELD B3


■ Parts for SV-NET cable

| Part name | Model or spec. | Maker | Remarks |
|----------------------|----------------|-----------------|---------|
| (1) Connector | 734-105 | WAGO | |
| (2) Device net cable | | | |
| (3) Connector | 1-1827864-3 | TE Connectivity | |


⇒ Refer to □22.1 "Optional Parts."

SV-NET Cable (between Driver and Driver)

Model: EUA1287N****



■ Connection




■ Parts for SV-NET cable

| Part name | Model or spec. | Maker | Remarks |
|----------------------|----------------|-----------------|---------|
| (1) Connector | 1-1827864-3 | TE Connectivity | |
| (2) Device net cable | | | |
| (3) Connector | 1-1827864-3 | TE Connectivity | |


⇒ Refer to □22.1 "Optional Parts."

SV-NET terminal connector

Model: EUA1294



■ Connection




■ Parts for SV-NET cable

| Part name | Model or spec. | Maker | Remarks |
|---------------|----------------|-----------------|---------|
| (1) Connector | 1-1827864-3 | TE Connectivity | |

* The 120 Ω terminator resistor is wired to CAN (-) inside the driver.

⇒ Refer to □22.1 "Optional Parts."

7.4. Connecting the Motor



Motor cables and sensor cables will differ depending on the motor with which they are combined. The description in this section is made on the assumption of use of TBL-i II, TBL-i IV and TBL-i4s series AC servo motor.

You must meet the following requirements if a motor cable other than the motor cables we specify as illustrated on the next page is to be used.

- Wire size/voltage endurance: AWG18 wire (0.75 sq)/300 VAC or higher

■ Cable specifications(For i II ,iIV Motor)

Motor Cable (for brakeless) Model EUA1280N****

Motor side

U
V
W
FG

A1
A2
A3
B1
B2
B3

Red
White
Black
Green

Driver side

U (Red)
V (White)
W (Black)
FG (Green)

■ Connection

| Motor side | Color | Driver side |
|------------|-------|-------------|
| A1 | Red | U |
| A2 | White | V |
| A3 | Black | W |
| B1 | Green | FG |
| B2 | | |
| B3 | | |

■ Parts for motor cable

| Part name | Model or spec. | Maker | Remarks |
|-------------|----------------|-----------------|-----------|
| (1) Cable | | | |
| (2) Housing | 178289-3 | TE Connectivity | |
| (3) Contact | 175218-2 | TE Connectivity | For AWG16 |

⇒ Refer to □22.1 "Optional Parts."

Motor Cable (for braked) Model EUA1292N****

Motor side

U
V
W
FG
BK
BK

A1
A2
A3
B1
B2
B3

Red
White
Black
Green/Yellow
Yellow
Blue

Driver side

U (Red)
V (White)
W (Black)
FG (Green/Yellow)
BK (Yellow)
BK (Blue)

■ Connection

| Motor side | Color | Driver side |
|------------|--------------|-------------|
| A1 | Red | U |
| A2 | White | V |
| A3 | Black | W |
| B1 | Green/Yellow | FG |
| B2 | Yellow | BK |
| B3 | Blue | BK |

AWG#18
(114/0.1A)

 AWG#24
(40/0.08A)


■ Parts for motor cable

| Part name | Model or spec. | Maker | Remarks |
|-------------|----------------|-----------------|-----------------|
| (1) Cable | | | |
| (2) Housing | 178289-3 | TE Connectivity | |
| (3) Contact | 175218-2 | TE Connectivity | AWG18 For AWG24 |

⇒ Refer to □22.1 "Optional Parts."

Sensor Cable (For wire-saving INC, 17-/23-bit-INC, BRX)

Model EUA1281N****



■ Connection

| Pin No. Compliance Table | | |
|--------------------------|-----------------|----------|
| 17bit-INC | Wire-saving INC | SmartSyn |
| — | A/UE | S2 |
| — | I/DE | S4 |
| — | B/VE | S1 |
| — | B/VE | S3 |
| SD | Z/WE | R1 |
| SD | Z/WE | R2 |
| — | — | — |
| +5V | +5V | — |
| 0V | 0V | — |
| — | — | — |
| SHILD | SHILD | SHILD |

| Sensor side | | Driver side | |
|-------------|--------------|-------------|-----|
| A1 | Blue | 1 | 1 |
| B1 | Blue/Black | 2 | 2 |
| A2 | Green | 3 | 3 |
| B2 | Green/Black | 4 | 4 |
| A3 | Yellow | 5 | 5 |
| B3 | Yellow/Black | 6 | 6 |
| A4 | Brown | 8 | 8 |
| B4 | Brown/Black | 2.0 | 2.0 |
| A5 | Red | 9 | 9 |
| B5 | Black | 10 | 10 |
| B6 | Shield | 1.9 | 1.9 |

0.3mm²
(Other: 0.2 mm²)


■ Parts for sensor cable

| Part name | Model or spec. | Maker | Remarks |
|-------------|----------------|-----------------|----------------------------|
| (1) Plug | 10120-3000PE | 3M | |
| (2) Shell | 10320-52A0-008 | 3M | |
| (3) Cable | | | |
| (4) Housing | 1-1318118-6 | TE Connectivity | |
| (5) Contact | 1318107-1 | TE Connectivity | A5,B5,B6 |
| (5) Contact | 1318108-1 | TE Connectivity | A1,A2,A3,A4 B1,B2,B3,B4 |

⇒ Refer to □22.1 "Optional Parts."

Sensor Cable (for 17-/23-bit-ABS)

Model EUA1283N****



■ Connection

| Pin No. Compliance Table | | |
|--------------------------|---|---|
| 17bit-ABS | — | — |
| — | — | — |
| — | — | — |
| — | — | — |
| — | — | — |
| SD | — | — |
| SD | — | — |
| VB | — | — |
| GND-VB | — | — |
| +5V | — | — |
| 0V | — | — |
| — | — | — |
| SHILD | — | — |

| Sensor side | | Driver side | |
|-------------|-----|-------------|-----|
| A1 | 1 | 1 | 1 |
| B1 | 2 | 2 | 2 |
| A2 | 3 | 3 | 3 |
| B2 | 4 | 4 | 4 |
| A3 | 5 | 5 | 5 |
| B3 | 6 | 6 | 6 |
| A4 | 8 | 8 | 8 |
| B4 | 2.0 | 2.0 | 2.0 |
| A5 | 9 | 9 | 9 |
| B5 | 10 | 10 | 10 |
| B6 | 1.9 | 1.9 | 1.9 |


AUA3972

■ Parts for sensor cable


| Part name | Model or spec. | Maker | Remarks |
|------------------|----------------|-----------------|-----------------------------|
| (1) Plug | 10120-3000PE | 3M | |
| (2) Shell | 10320-52A0-008 | 3M | |
| (3) Cable | | | |
| (4) Housing | 1-1318118-6 | TE Connectivity | |
| (5) Contact | 1318107-1 | TE Connectivity | A5,B5,B6 |
| (5) Contact | 1318108-1 | TE Connectivity | A1,A2,A3,A4, B1,B2,B3,B4 |
| (6) Battery unit | AUA3972 | | |

⇒ Refer to □22.1 "Optional Parts."

■ Cable specifications (For i4s Motor)




⇒ Refer to □22.1 "Optional Parts."




⇒ Refer to □22.1 "Optional Parts."

Sensor Cable (For serial-ABS)

Model EUA9203N****



■ Connection




■ Parts for sensor cable

| Part name | Model or spec. | Maker | Remarks |
|------------------|------------------|-------|-----------|
| (1) Plug | 10120-3000PE | 3M | |
| (2) Shell | 10320-52A0-008 | 3M | |
| (3) Cable | | | |
| (4) Connector | JN6FR07SM1 | JAE | |
| (5) Contact | LY10-C1-A1-10000 | JAE | For AWG26 |
| (6) Battery unit | AUA3972 | | |


⇒ Refer to □22.1 "Optional Parts."

Sensor Cable (For serial-INC)

Model EUA9204N****



■ Connection



■ Parts for sensor cable


| Part name | Model or spec. | Maker | Remarks |
|---------------|------------------|-------|-----------|
| (1) Plug | 10120-3000PE | 3M | |
| (2) Shell | 10320-52A0-008 | 3M | |
| (3) Cable | | | |
| (4) Connector | JN6FR07SM1 | JAE | |
| (5) Contact | LY10-C1-A1-10000 | JAE | For AWG26 |

⇒ Refer to □22.1 "Optional Parts."

Sensor Cable (For resolver)

Motor side


Driver side



■ Connection

Pin No. Compliance Table

| Resolver |
|----------|
| S2 |
| S4 |
| S1 |
| S3 |
| R1 |
| R2 |




■ Parts for motor cable

| Part name | Model or spec. | Maker | Remarks |
|---------------|------------------|-------|-----------|
| (1) Plug | 10120-3000PE | 3M | |
| (2) Shell | 10320-52A0-008 | 3M | |
| (3) Cable | | | |
| (4) Connector | JN6FR07SM1 | JAE | |
| (5) Contact | LY10-C1-A1-10000 | JAE | For AWG26 |


⇒ Refer to □22.1 "Optional Parts."

7.5. Example of SV-NET Motion Controller and Motor/Driver (3-Axis) Connection




7.6. Connecting the I/O cable

■ I/O Cable connection




■ Cable specifications



■ I/O Cable (command pulse, open collector)


Model: EUA1425N****

- Driver side (1) Connector:10150-3000PE (3M)
 (2) Shell:10350-52F0-008 (3M)




■EUA1425 Connection

Connector side 10350-3000PE Crimp-contact side F0.3-3



■EUA1424 Connection

Connector side 10350-3000PE Crimp-contact side F0.3-3










Important

It is recommended that the shield of the I/O cable be connected to the signal ground of a higher-level device. ⇒ Refer to □22.2 "External Connection Diagram."

7.7. Wiring the I/O Connector


| Pin No. | Signal Name | Function (factory settings) | Remarks |
|---------|-------------|--|---|
| 1 | +CON | Common power supply for digital input | |
| 2 | +CON | Common power supply for digital input | |
| 3 | IN1 | Input 1 (servo ON input) | General-purpose digital input |
| 4 | IN2 | Input 2 (Forward-rotation drive disable input) | General-purpose digital input |
| 5 | IN3 | Input 3 (Reverse-rotation drive disable input) | General-purpose digital input |
| 6 | IN4 | Input 4 (alarm reset input) | General-purpose digital input |
| 7 | IN5 | Input 5 (deviation reset input) | General-purpose digital input |
| 8 | IN6 | Input 6 (external alarm input) | General-purpose digital input |
| 9 | IN7 | Input 7 (origin point sensor input) | General-purpose digital input |
| 10 | IN8 | Input 8 (pulse input disable command) | General-purpose digital input |
| 11 | N-C | | Unconnectable |
| 12 | N-C | | Unconnectable |
| 13 | N-C | | Unconnectable |
| 14 | N-C | | Unconnectable |
| 15 | F-PLS1+ | Pulse input 1 (Forward-rotation command pulse) | Open collector input or line driver input |
| 16 | F-PLS+ | | |
| 17 | F-PLS- | | |
| 18 | N-C | | Unconnectable |
| 19 | R-PLS1+ | Pulse input 2 (Reverse-rotation command pulse) | Open collector input or line driver input |
| 20 | R-PLS+ | | |
| 21 | R-PLS- | | |
| 22 | N-C | | Unconnectable |
| 23 | +5V | Internal control supply power +5V | Unconnectable |
| 24 | ANALOG-IN+ | Analog command input | Analog input |
| 25 | ANALOG-IN- | Analog command GND | |
| 26 | MONITOR2 | Analog monitor output 2 | |
| 27 | MONITOR1 | Analog monitor output 1 | |
| 28 | GND | Digital ground | |
| 29 | GND | Digital ground | |
| 30 | OUT1+ | Output 1 (alarm signal) | General-purpose digital output |
| 31 | OUT1- | | |
| 32 | OUT2+ | Output 2 (in-position signal) | General-purpose digital output |
| 33 | OUT2- | | |
| 34 | OUT3+ | Output 3 (servo ready signal) | General-purpose digital output |
| 35 | OUT3- | | |
| 36 | OUT4+ | Output 4 (brake control signal) | General-purpose digital output |
| 37 | OUT4- | | |
| 38 | OUT5+ | Output 5 (stop speed status signal) | General-purpose digital output |
| 39 | OUT5- | | |
| 40 | EX-LEAD+ | External encoder input | Line driver input |
| 41 | EX-LEAD- | | |
| 42 | EX-LAG+ | | |
| 43 | EX-LAG- | | |
| 44 | LEAD+ | Sensor signal output | Line driver input |
| 45 | LEAD- | | |
| 46 | LAG+ | | |
| 47 | LAG- | | |
| 48 | Z+ | | |
| 49 | Z- | | |
| 50 | GND | Digital ground | |



■ Analog input: Pin 24 (analog command input)

Establish this connection to use a voltage change as a speed or current command.


- Input voltage: Max. +10 VDC; Min. -10 VDC
- Connect GND of the input signal to pin number 25.
- Input is enabled by setting parameter ID75 "Speed Command Select" or ID76 "Torque Command Select" for analog input.
 - ⇒ Refer to 19.7 "Parameters for Setting Control Functions"
- Analog input setting parameters and analog input offsets need to be adjusted.
 - ⇒ Refer to 15.2 "To run with an analog command from the I/O connector" in.2 "Speed Control Mode"
 - Refer to 15.3 "To run with an analog command from the I/O connector" in.3 "Current Control Mode"




■ Digital input: Pins 15 to 21

Establish this connection to use a pulse signal as a position control command.

- Use the input pulse at 500 kHz for line driver input and 200 kHz or less for open collector input.
- Input is enabled by setting parameter ID74 "position command select" for pulse input.
 - ⇒ Refer to 19.7 "Parameters for Setting Control Functions"
- The command pulse type can be selected by using the parameter ID 120.
 - ⇒ Refer to 15.1.1 "Pulse Input Signal Types"
- The command pulse resolution per motor rotation can be set by using parameter ID121 and ID122



Connection example




List of pulse command input pin functions

| Pin No. | Pin name | Command description | | |
|---------|----------|----------------------------------|--------------------------|--------------------------------------|
| | | Forward/reverse pulse | Pulse/rotation direction | 90°-phase-difference two-phase pulse |
| 15 | F-PLS1+ | Forward-rotation command pulse + | Command pulse + | A-phase pulse + |
| 16 | F-PLS+ | | | |
| 17 | F-PLS- | Forward-rotation command pulse - | Command pulse - | A-phase pulse - |
| 19 | R-PLS1+ | Reverse-rotation command pulse + | Rotation direction + | B-phase pulse + |
| 20 | R-PLS+ | | | |
| 21 | R-PLS- | Reverse-rotation command pulse - | Rotation direction - | B-phase pulse - |

■ Digital input: Pins 3 to 10

These pins input different kinds of digital signals. The function of each pin can be changed from the parameters.


- The input voltage (+COM) is 5 VDC or 24 VDC (depending on the model).
- In factory settings, the L level (with the photocoupler energized) is ON, and the H level or the open state (without energizing the photocoupler) is OFF. The logic can be reversed from the parameters.
- The function selection of each pin can be set with parameter IDs 100 to 107. See the table below for settable functions.
- The I/O filter time can be changed.



Connection example

Parameters for Setting Digital Input Pin Functions

| Pin No. | Signal name (Factory setting) | Parameters | | |
|---------|--|------------|-----------------|-----------|
| | | ID | Name | Reference |
| 3 | IN1 (servo ON input) | 100 | Input 1 setting | ⇒ □19. 10 |
| 4 | IN2 (Forward-rotation drive disable input) | 101 | Input 2 setting | |
| 5 | IN3 (Reverse-rotation drive disable input) | 102 | Input 3 setting | |
| 6 | IN4 (alarm reset input) | 103 | Input 4 setting | |
| 7 | IN5 (deviation reset input) | 104 | Input 5 setting | |
| 8 | IN6 (external alarm input) | 105 | Input 6 setting | |
| 9 | IN7 (origin sensor input) | 106 | Input 7 setting | |
| 10 | IN8 (pulse input disable command) | 107 | Input 8 setting | |



Settable Digital Input Functions

This function can also be operated by setting the value of driver parameter ID30 (Servo Command) with various communication.

To find details of each status, refer to □16.3 "Servo Command."

| Function name | Description |
|---------------------------------|--|
| Servo ON | Sets the servo to ON. |
| Forward-rotation drive disable | Sets the speed command to 0 and disables forward-direction rotation. Effective at the time of position and speed control. |
| Reverse-rotation drive disable | Sets the speed command to 0 and disables reverse-direction rotation. Effective at the time of position and speed control. |
| Alarm reset | Clears driver alarms. |
| Deviation reset | Clears the position error counter. |
| Profile operation enabled | Enables profile operation to move to the target position in position control. |
| Origin sensor input | Detects an origin signal. |
| External alarm | If set to ON, the servo is set to OFF when the driver detects an alarm. |
| Gain switch | Switches between Gain 1 and Gain 2. |
| Analog input 0-point adjustment | Automatically adjusts offset for analog input. |
| Second current limit switch | Switches between the first and second current limits. |
| Pulse input disable command | Stops pulse command inputs from being read. |
| Homing start command | Starts homing, and restores to the original control mode automatically once homing is complete. |
| Analog input forced-0 command | Forces the analog input command to 0. |
| Simplified control input 1 to 8 | Used for input in the simplified control mode. |
| Control mode switch | Switches the control mode. |
| Hard stop | Automatically stops the motor. |
| Smooth stop | Stops the motor by reducing speed. |
| Emergency stop input | Turns off the brake output and forces the motor to stop. Then, turns off the servo by applying ID143 "servo off delay time." *BITO (servo on) of ID30 "Servo command" is not automatically cleared. |
| Ignore input | Nothing happens. (Used in operations, such as acquisition only of I/O logic information from a higher level.) |

"I/O filter time"

Instantaneous signals due to noise etc. can be canceled by increasing the set value of parameter ID117.

A stable input signal is valid for the period of time set when the I/O input signal changes.

This setting is used for the following I/O digital inputs.

CN7 connector (I/O connection)

| Pin No. | Signal name (Factory setting) | Parameters | | |
|---------|--|------------|-----------------|------------|
| | | ID | Name | Reference |
| 3 | IN1 (servo ON input) | 117 | I/O filter time | ⇒ □ 19. 10 |
| 4 | IN2 (Forward-rotation drive disable input) | | | |
| 5 | IN3 (Reverse-rotation drive disable input) | | | |
| 6 | IN4 (alarm reset input) | | | |
| 7 | IN5 (deviation reset input) | | | |
| 8 | IN6 (external alarm input) | | | |
| 9 | IN7 (origin sensor input) | | | |
| 10 | IN8 (pulse input disable command) | | | |

Supplement

This function cancels instantaneous signals. However, it also prolongs the time necessary for detecting ordinary signals.


In particular, during immediate stopping by origin signal (I/O) in homing operation, etc. a check for a change in the origin position must always be made after changing this parameter.

There may also be effects on the stop operation due to the limit signal or similar (I/O).


■ Digital output: Pins 30 to 39

These pins output different kinds of digital signals.

- Collector current: Max. 100 mA
- Max voltage: 30 VDC
- Use parameter IDs 110 to 114 to set the functions of each pin.



Connection example



Parameters for Setting Digital Output Functions

| Pin No. | Signal name (Factory setting) | Parameters | | | Remarks |
|---------|---------------------------------|------------|------------------|-----------|---|
| | | ID | Name | Reference | |
| 30,31 | OUT1 (alarm signal) | 110 | Output 1 setting | ⇒ □19. 10 | For changing the logic: ID69 "Control Selection Flag" ⇒ Refer to □19.7 "Parameters for Setting Control Functions" |
| 32,33 | OUT2 (in-position signal) | 111 | Output 2 setting | | |
| 34,35 | OUT3 (servo ready signal) | 112 | Output 3 setting | | |
| 36,37 | OUT4 (brake control signal) | 113 | Output 4 setting | | |
| 38,39 | OUT5 (stop speed status signal) | 114 | Output 5 setting | | |

Overview of Functions Settable in Digital Output

The various flags assigned in ID20 (Servo Status) can be output in digital output.
To find details of each status, refer to □15.5 "The Driver Operation Status."

| Function name | Description |
|----------------------------------|--|
| Servo ON | ON while servo ON |
| During profile operation | ON during profile operation |
| In-position signal | ON when the position deviation falls within the in-position range |
| Alarm signal | Is set to ON if an alarm is detected. |
| Forward limit | ON when the current position exceeds the value set in forward-direction move limit |
| Reverse limit | ON when the current position exceeds the value set in the reverse-direction move limit |
| Torque limit | ON when the current exceeds the limit value |
| Speed limit | ON when the speed exceeds the limit value |
| Position excessive deviation | ON when the position deviation exceeds the limit value |
| Servo ready signal | Is set to ON if servo control is possible. |
| During homing | ON during homing operation |
| During switching to second gain | ON when Gain 2 is used |
| Backup battery voltage low | ON when the backup battery voltage of the sensor is low |
| Drive power supply disconnection | ON when the voltage of the drive power supply is low |
| Stop speed status signal | Is ON if the motor speed is below the judgment speed. |
| Brake control signal | ON when the brake control signal is released |
| Alarm bit code signal 0 to 2 | Displays the alarm type if an alarm is detected. * Uses three outputs. |
| Profile command arrival | Turns ON when the target position is reached during profile operation. |

■ **+5V: Pin 23**

This is the 5V control power supply within the driver.
 This cannot be used as a control power supply for external devices.


■ **GND: Pins 28,29,50**

These GNDs are shared between each control signal.


■ **External encoder input: Pins 40 to 43
 (line driver input)**

This input is connected when an external encoder input signal is to be used as a feedback signal in position control.

- This is enabled by setting Parameter ID73, "Position Feedback Selection," in the external encoder.



Connection example




List of Digital Input Pin Functions

| Pin No. | Signal name |
|---------|-------------|
| 40 | LEAD+ |
| 41 | LEAD- |
| 42 | LAG + |
| 43 | LAG - |


■ LEAD/LAG/Z output: Pins 44 to 49 (line driver output)

Line driver output

- Line driver AM26C31 or equivalent



Connection example



LEAD/LAG/Z output function


The parameter ID126 can be used to set the output resolution.

| Pin No. | Signal name | Function |
|---------|-------------|---|
| 44, 45 | LEAD | <ul style="list-style-type: none"> ○ Brushless resolver 1X-BRX 1X-BRX (outputs Z signal once per rotation): Outputs a sensor signal in the resolution range of 1 to 512 per motor rotation. |
| 46, 47 | LAG | <ul style="list-style-type: none"> ○ Wire-saving incremental encoder 2048C/T, 2000C/T, 2500C/T wire-saving INC Outputs a sensor signal in the resolution range of 1 to the number of C/Ts of the used sensor per motor rotation. ○ Serial encoder 17Bit-INC/ABS, 23Bit-INC/ABS Outputs a sensor signal in the resolution range of 1 to 2048 per motor rotation. |
| 48, 49 | Z | <ul style="list-style-type: none"> ○ Brushless resolver 1X-BRX Outputs the Z signal generated by R/D conversion. ○ Wire-saving incremental encoder 2048C/T, 2000C/T, 2500C/T wire-saving INC Outputs the sensor Z signal. ○ Serial encoder 17Bit-INC/ABS, 23Bit-INC/ABS Outputs the Z signal generated from the sensor signal. |

Supplement

When Bit 13 or 14 of ID 69 "Control Switch" is 1 (enabled), this setting becomes invalid, and the position pulse of the encoder is output as the LEAD/LAG/Z output without being changed.


LEAD/LAG/Z output waveform




LEAD/LAG/Z output patterns

The output pattern of the Z phase differs as follows depending on the settings for the Z-signal output waveform selection (Bit 6 of parameter ID69).

When Bit 6 = "0" in parameter ID69 (factory setting)



When Bit 6 = "1" in parameter ID69



Z signal becomes Hi by synchronizing with the Hi state of the LEAD signal.

When Bit 15 of parameter ID69 is "1," the LEAD and LAG signals will be interchanged.

This is a logical inversion of the rotation direction.


Also in this case, the Z signal will be output at the above-described timing.

■ Monitor output: Pins 26, 27

The difference parameter values are output in analog signal form.

- They are output within the range ± 10 V using GND as the standard.
(The output is linear in the range up to ± 8 V.)
- The parameter IDs and magnification targeted for monitor output can be selected with parameters.

■ Internal block diagram



Parameters for Setting Monitor Output


| Pin No. | Signal name | Parameters | | |
|---------|-------------|------------|-------------------|-----------|
| | | ID | Name | Reference |
| 27 | MONITOR1 | 118 | Monitor 1 setting | ⇒ □ 19.11 |
| | | 185 | Monitor 1 gain | |
| 26 | MONITOR2 | 119 | Monitor 2 setting | |
| | | 186 | Monitor 2 gain | |

Factory settings


Monitor output 1:
Feedback current (ID42)

Monitor output 2:
Feedback speed (ID41)

7.8. Connecting the Analog Monitor Output Connector



■ Cable specifications



■ Parts for analog monitor cable

| Part name | Model or spec. | Maker | Remarks |
|--------------|------------------------|---------|---------|
| (1) Socket | 2418HJ-04-PHD | Neltron | |
| (2) Terminal | 2418TJ-PHD | Neltron | |
| (3) Cable | AWG24-28 or equivalent | — | |

■ Analog monitor output connector (debugging connector)

These are shared with Analog Monitor Output 1 and 2 (Pins 26 and 27) of the I/O connector.

The OUT2/output is the same signal as OUT2 from the I/O connector. However, it is a source signal that does not undergo photocoupler isolation.

The logic is inverted and output as 0/3.3 V.

| Pin No. | Function | Remarks |
|---------|----------------------------|----------------|
| 1 | Monitor output 1 | Analog output |
| 2 | Monitor output 2 | Analog output |
| 3 | OUT2/(In-position signal/) | Digital output |
| 4 | GND | Common |


7.9. Connecting External Resistors

External resistors (regenerative resistors) will be connected to the B1 and B2 terminals, connectors for connecting motors and external resistors.


■ Wiring the regenerative resistor

Applying a sudden deceleration or external rotation torque subjects the motor to a counter electromotive force due to regeneration effects, resulting in a rise in the drive voltage occurring inside the driver.

Connecting the regeneration resistor to the TAD8811 Series allows the regeneration protective circuit, which is built into the regeneration resistor, to protect the driver and motor by controlling such a rise in the drive voltage.



| Pin No. | Function |
|---------|----------|
| 1 | B1 |
| 2 | B2 |
| 3 | U-phase |
| 4 | V-phase |
| 5 | W-phase |



Select an appropriate resistor so that the maximum power capacity will be four times the regenerative power generated or larger.

If the capacity of the standard regeneration resistor illustrated in the left is insufficient, use a commercially-available cement resistor (47 Ω) with a higher capacity.



Caution

Regenerative resistors may become hot under some usage conditions.


- When connecting a regenerative resistor, attach it to a non-combustible article such as a metal object.
- Consider additionally using an external protecting device, such as a thermal fuse and a thermal protector.

7.10. Mechanical Brake

This driver is not equipped with a circuit for releasing a mechanical brake.

When a motor with a mechanical brake is to be used, it is necessary to prepare a 24-VDC power supply separately.

When it is necessary to synchronize the control of the mechanical brake with the servo ON/OFF of the driver, establish a connection with the following circuit and then use the "brake control signal" available as the I/O output. ⇒ Refer to □7.7 "Wiring the I/O Connector."



- *1: Be sure to prepare a 24 VDC power supply (0.5 A or more) for the brake separately from power supplies for I/O input and output (CN1), etc.
- *2: As the relay, select a coil-resistance product handling a current of 50 mA or less under an input voltage of 24 VDC or less.
- *3: It is unnecessary when a relay with a built-in coil-surge absorber is used.
- *4: This is a factory setting. The output terminal can be changed by parameter setting.

7.11. Other Considerations for Wiring

- For wiring, use cables we specify, to the greatest extent possible. When it is necessary to use a non-specified cable, select one by considering its usage environment, rated voltage, and rated current.
- Meet the following requirements if a motor cable other than the motor cables we specify is to be used.
Wire size/voltage endurance = AWG18 wire (0.75 sq)/300 VAC or higher
- Do not run a heavy-current line (a main circuit cable) and a light-current line (an I/O input and output cable and an encoder cable) in the same duct or bundle them together. If a heavy-current line and a light-current line cannot be placed in separate ducts, separate them by a distance of 30 cm or more. Wiring that is too close together may result in malfunctions due to noise on the light-current line.
- Firmly tighten the locking mechanisms and lockscrews of cable connectors.

8. How to Control the Driver

The driver is controlled mainly by SV-NET communication, pulse commands, or analog commands. With either method, parameters must be set first. Parameters can be set via the USB communication of the driver or by SV-NET communication with a higher-level device.

There are many types of parameters and corresponding functions. In some cases, controllers or other higher-level devices may control the driver while reading and writing these parameter values.

This section provides a broad overview of the parameters.

⇒Refer to □19 "List of Parameters"

| Parameter type | Basic description |
|---|---|
| Communication parameters | Sets MAC-IDs, communication speed, and other parameters for SV-NET. |
| Parameters for initializing and saving parameters | Used mainly to save parameter values in a nonvolatile memory. |
| Status parameters | Used for driver status acquisition, alarm detection, etc. |
| Control command parameters | These are parameters that are directly involved with motor operation such as servo ON and control method selection. |
| Servo feedback parameters | Acquires motor sensor information. |
| Servo gain parameters | Sets various kinds of servo gains. Used for adjustment. |
| Parameters for setting control functions | Selects electronic gears and the function of each control mode. |
| Parameters for setting homing operation | Sets homing operation. |
| Control mode switching parameter | Sets the method for switching the control mode. |
| Parameters for setting I/O (input, output) | Used to set I/O functions. |
| Parameters for setting analog monitor | Sets the analog monitor output. |
| Parameters for setting pulses | Sets input/output pulses and related settings. |
| Parameters for setting the analog input | Sets the analog input and related settings. |
| Special servo parameters | Used for more advanced control. |
| Parameters for setting error detection | Sets values to be detected as errors. |
| Parameters for internal monitor | Sets the analog monitor output and related settings. |
| Extension parameters | Sets highly sophisticated control. |

Most parameters are not changed once they have been set at the beginning. Depending on the usage, however, various kinds of parameters may need to be set before the driver is installed and run on equipment. Note that turning off the driver without saving the set parameters to nonvolatile memory will return the parameters to their original settings. After parameters have been changed, they must be saved.

9. Establishing Communication with Host Equipment

On the basis of our unique communication formats, the specifications of TAD8811 defines SV-NET communication and RS485 (Tamagawa Format and ModbusRTU Format) for communication with host equipment. For the details of the specifications, refer to each communication specification (SV-NET Communication Specification: SPC009568Y00; Serial Communication Specification: SPC009256W00; ModbusRTU Communication Specification: SPC009819W00). This chapter describes the communication specifications and the settings of MAC-ID and communication speed as initial settings for establishing communication with host equipment.

9.1. Procedure for Specifying Communication Specifications

First, make the settings of TAD8811 to specify necessary communication specifications. At factory default, it is set for SV-NET communication. When specifying different communication specifications, follow the procedure below to set parameters.

Supplement

To find methods for changing parameter values by using dedicated applications, see the relevant instruction manual by using the help function of each application.

■ Specifying communication specifications

1. Check that the power supply is OFF.
2. Connect TAD8811 to the PC via USB connection.
3. After the power supply has been turned on, wait for at least two seconds before starting the next operation.
4. Use the dedicated application to set the parameters by following the procedure below.

Communication specifications can be specified by using the Bit 1 and Bit 2 of ID 141 "Special Function Switching." For example, when designating RS485 ModbusRTU format as communication specifications, set ID 141 to "0x04." When a setting is changed, the change must always be saved by setting "1" in ID 17 "Parameters save."

| Step | ID | Parameter name | Setting value |
|------|-----|----------------------------|---|
| (1) | 141 | Special Function Switching | Bit2/Bit1 :SV-NET-RS485 Sets the communication protocol for CN5 and CN6 00=SV-NET enabled 01=RS485(Tamagawa Format)enabled 10=RS485(ModbusRTU Format)enabled |
| (2) | 17 | Parameters save | 1 |

9.2. Procedure for Setting a MAC-ID

Before performing motor control or making a setting change to a parameter via communication, set MAC-ID to establish communication. The MAC-ID is set to "63" as a default value; you must set a MAC-ID that is unique and not already used on the network.

Supplement

To find methods for changing parameter values by using dedicated applications, see the relevant instruction manual by using the help function of each application.

Supplement

To find methods for changing parameter values via communication using host equipment, see each communication specification (SV-NET Communication Specification: SPC009568Y00; Serial Communication Specification: SPC009256W00; ModbusRTU Communication Specification: SPC009819W00).

■ Setting a MAC-ID via USB communication

When it is necessary to change a setting via USB communication of the driver main unit, use a dedicated application to set ID5 "MAC-ID."

■ Setting MAC-IDs using SV-NET/Serial communication

1. Check that the power supply is OFF.
2. Connect only the driver on which you wish to set a MAC-ID to host equipment using the SV-NET cable (or a serial communication cable). Disconnect communication cables from other drivers.
3. After the power supply has been turned on, wait for at least two seconds before starting the next operation.
4. Set the parameters via SV-NET communication (or serial communication) by following the procedure below. ID5 "MAC-ID" can be set to a value from 1 to 63. When a setting is changed, the change must always be saved by setting "1" in ID17 "Parameters save."

| Step | ID | Parameter name | Setting value |
|------|----|-----------------|---------------|
| (1) | 5 | MAC-ID | 1–63 |
| (2) | 17 | Parameters save | 1 |



Caution

If parameter values are changed, save the parameters. Turning OFF the power supply without saving will return the parameter values to their original settings. ⇒ Refer to □16.1 "Storing Parameters"



Important

Changed MAC-IDs are enabled when the power is turned on. After the power has been turned on, wait for at least two seconds before starting SV-NET communication.

9.3. Procedure for Setting the Communication Speed

This section describes a procedure for setting the communication speed for the communication specifications specified in ID 141 "Special Function Switching." It is recommended that the SV-NET communication speed be maintained at the 1 Mbps (factory setting). However, if communication becomes unstable because the SV-NET cable is long, setting a slower communication speed may improve stability.

When changing the communication speed, record the communication speed you have set in order to avoid forgetting it. Changing the setting without due care and attention could lead to a problem in communication. Set and save communication speed properly.

Supplement

To find methods for changing parameter values by using dedicated applications, see the relevant instruction manual by using the help function of each application.

Supplement

To find methods for changing parameter values via communication using host equipment, see each communication specification (SV-NET Communication Specification: SPC009568Y00; Serial Communication Specification: SPC009256W00; ModbusRTU Communication Specification: SPC009819W00).

1. Turn ON the power supply.
2. Set parameters in accordance with the following procedure by using host equipment or a dedicated application. Set ID6 "Baud Rate" to a number corresponding to the communication speed in accordance with the communication specifications. When a setting is changed, the change must always be saved by setting "1" in ID 17 "Parameters save."

Example) When designating SV-NET = 1Mbps, RS232 = 56,000 bps, RS485 = 19,200 bps, an even parity for ModbusRTU, and stop bit = 1: ID6 = "0x2244"

* If a communication error occurs due to the surrounding environment or the cable state, designate a lower communication speed.

| Step | ID | Parameter name | Setting Value |
|------|----|---------------------|--|
| (1) | 6 | Communication Speed | SEG0 (Bit0-3): SV-NET communication speed 0: 125 kbps 1: 250 kbps 2: 500 kbps 4: 1 Mbps (factory default setting) SEG2 (Bit8-11): RS485 (ModbusRTU) communication speed 0: 115,200 bps (factory initial value) 1: 9,600 bps 2: 19,200 bps 3: 38,400 bps 4: 56,000 bps 5: 57,600 bps 6: 115,200 bps SEG3 (Bit12-15): ModbusRTU character setting 0: No parity, stop bit = 1 (factory default setting) 1: No parity, stop bit = 2 2: Even parity, stop bit = 1 3: Even parity, stop bit = 2 4: Odd parity, stop bit = 1 5: Odd parity, stop bit = 2 |
| (2) | 17 | Parameters save | 1 |

-
3. Turn OFF the power supply.
 4. Turn ON the power supply again and then wait for at least two seconds.
 5. Adjust the communication speed of the host equipment or the dedicated application to the communication speed set to the driver, and then check whether communication can be established.



Caution

If parameter values are changed, save the parameters.
Turning OFF the power supply without saving will return the parameter values to their original settings. ⇒ Refer to □16.1 "Storing Parameters"



Important

The changed communication speed will be enabled when the power is turned on. Once the communication speed has been changed, turn the power supply back on.

10. Trial Run

After the environment has been made ready for parameter changes, connect all of the required cables and then perform a trial run on each driver and motor set, one by one. Check whether the motor rotates normally. To prevent unexpected accidents, separate the motor from other equipment, and with nothing connected to the motor shaft, and then perform the trial run in a no-load state.

In a trial run, various types of operations can be performed, including a simple JOG operation from the settings panel of the driver main unit, speed control and position control under parameter settings close to those for an actual run via communication from host equipment, and speed control and position control via USB communication (dedicated application) from the driver main unit.

- Supplement** To find methods for operation by using dedicated applications, see the relevant instruction manual by using the help function of each application.
- Supplement** To find methods for setting parameter values via communication using host equipment, see each communication specification (SV-NET Communication Specification: SPC009568Y00; Serial Communication Specification: SPC009256W00; ModbusRTU Communication Specification: SPC009819W00).

10.1. Trial Run from Settings Panel

The speed and current can be controlled in a step-by-step fashion simply by using the settings panel. To find more details, refer to □20.9 "Operations in JOG Operation Mode."

1. Turn ON the power supply and then wait for at least two seconds.
2. If "AL**" appears on the settings panel (the asterisk (*) represents a certain numerical value), an alarm has been detected. In that case, eliminate the cause of the alarm and reset it with reference to 17 "Alarm Detection."
3. If no alarm is detected, start a trial run.
4. Perform a trial run by using the settings panel to take the following steps:
(Details of the following operations are described in □ 20.9 "Operations in JOG Operation Mode.")

| Step | Operation |
|------|--|
| (1) | Press the MODE button several times to make the display read . |
| (2) | Press the ◀ button to make the display read . |
| (3) | Press the ▲ or ▼ button to select for step-by-step speed control or for step-by-step current control. |
| (4) | Press the ◀ button to open the command value setting screen, and then use the ▲ or ▼ button to set a command value. Set a value in units of rpm and 0.01 A for step-by-step speed control and step-by-step current control, respectively. (When you put the driver into operation for the first time, you are advised to set a value between "30" and "60" (30 to 60 rpm) for step-by-step speed control and a value between "30" and "50" (0.3 to 0.5 A) for step-by-step current control.) |
| (5) | Press the ◀ button for a few seconds to make the display read . |
| (6) | Again press the ◀ button for a few seconds until three hyphens (-) appear like ; the servo will be turned ON, and the display will change to or . |
| (7) | While the ▲ button is being held down, forward-direction commands are given to make the motor rotate.(*1) While the ▼ button is being held down, reverse-direction commands are given to make the motor rotate. Releasing the buttons stops the motor (command = 0). |
| (8) | To finish the trial run, press the MODE button. |

(*1) The definition of the forward rotation direction can be changed by ID 72 "Reference Direction."

5. Check that control can be performed as set and that the motor rotates smoothly.

10.2. Speed Control Trial Run

1. Turn ON the power supply and then wait for at least two seconds.
2. If "AL**" appears on the settings panel (the asterisk (*) represents a certain numerical value), an alarm has been detected. In that case, eliminate the cause of the alarm and reset it with reference to 17 "Alarm Detection."
3. If no alarm is detected, start a trial run.
4. Set the parameters by following the procedures below.

| Step | Operation | | | | | | | | | | | | | | | | | | |
|------|--|-------------------------|---------------|-----|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | ID | Parameter name | Setting value | | | | | | | | | | | | | | | | |
| (1) | Set the control mode to speed control. | | | | | | | | | | | | | | | | | | |
| | 31 | Control Mode | 2 | | | | | | | | | | | | | | | | |
| (2) | Servo ON. Servo ON fixes the motor shaft. | | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0001 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| | | | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 |
| (3) | Set the rotation speed. (Example: 500 rpm). After this has been set, the motor will rotate. | | | | | | | | | | | | | | | | | | |
| | 37 | Real-time Command Speed | 500 | | | | | | | | | | | | | | | | |
| (4) | Change the rotation speed. (Example: 1000 rpm). After this has been set, the rotation speed will change. | | | | | | | | | | | | | | | | | | |
| | 37 | Real-time Command Speed | 1000 | | | | | | | | | | | | | | | | |
| (5) | Rotation stop. Stop the rotation using servo OFF. | | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0000 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| | | | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

5. Check that control can be performed as set and that the motor rotates smoothly. Proceed to a position control trial run.

Supplement

To perform a trial run again after use with pulse input and analog signal input, set IDs 75 "Speed Command Select" and 74 "Position Command Select" to "0," and then send commands via communication.

10.3. Position Control Trial Run

1. Set parameters in accordance with the following steps.

| Step | Operation | | | | | | | | | | | | | | | | | | |
|------|--|-----------------|---------------|-----|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | ID | Parameter name | Setting value | | | | | | | | | | | | | | | | |
| (1) | Set the control mode to position control. | | | | | | | | | | | | | | | | | | |
| | 31 | Control Mode | 1 | | | | | | | | | | | | | | | | |
| (2) | Reset the current position. Set the current position to "0." | | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x4000 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| | | | | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| (3) | Servo ON. Servo ON fixes the motor shaft. | | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0001 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| | | | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 |
| (3) | Set the move target position. (Example: Move in the forward direction (CCW) by 0x20000 (131072) pulses.) | | | | | | | | | | | | | | | | | | |
| | 32 | Target Position | 0x00020000 | | | | | | | | | | | | | | | | |
| (4) | Set the target speed. (Example: 100 rpm) | | | | | | | | | | | | | | | | | | |
| | 33 | Target Velocity | 100 | | | | | | | | | | | | | | | | |
| (5) | Set the acceleration/deceleration. (Example: Set the acceleration/deceleration speed in units of 10 rpm/sec. For example, set "100" for an acceleration/deceleration speed of 1000 rpm/sec.) | | | | | | | | | | | | | | | | | | |
| | 34 | Acceleration | 100 | | | | | | | | | | | | | | | | |
| | 35 | Deceleration | 100 | | | | | | | | | | | | | | | | |
| (6) | Profile ON. Once set, the motor will rotate to the position set in (3). | | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0003 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| | | | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | |
| (7) | Servo OFF. Set servo OFF after rotation stops. | | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0000 | B14 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| | | | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

2. Check that control can be performed as set and that the motor rotates smoothly. Perform trial runs for all the connected drivers and motors and check their operation.

Supplement

To perform a trial run again after use with pulse input and analog signal input, set IDs 75 "Speed Command Select" and 74 "Position Command Select" to "0," and then send commands via communication.

11. Servo Gain Adjustment


After the motor has been installed on equipment, various kinds of gains need to be adjusted to control the motor under optimal conditions. The servo gains set at the factory are set with a focus on ensuring safe operation. Adjust the servo gains if a more suitable setting is required to optimize operation of the equipment, or if adjusting the load inertia fails to resolve an overshoot (stoppage after the target has been passed) or vibration.

Supplement

The auto tuning function is implemented on the dedicated application "Motion Designer Drive."

To find the details of the auto tuning function, refer to the relevant instruction manual by using the help function of the dedicated application.

11.1. Servo Block Diagram



■ Automatic adjustment

• Tuning-free function

The tuning-free function estimates the load characteristics of the machine in actual operation in real time and automatically set the basic gain corresponding to the value of the stiffness parameter on the basis of the estimation. It is useful when the user is not sufficiently used to gain adjustment, or when gain adjustment is necessary for a multiaxial mechanism.

• Auto tuning function

The auto tuning function is an enhanced function used in the position or speed control mode. It uses the auto tuning function of the dedicated application "Motion Designer Drive" to set the machine stiffness and the positioning settling time, thereby improving response. It is useful when further improvement in response is necessary after adjustment by the tuning-free function. Since the adjustment is performed in uniaxial reciprocating operation, this function is effective in uniaxial gain adjustment.

■ Manual adjustment

• Manual gain tuning (basic)

This function is used to set the basic gain manually. It is useful when further improvement in response is necessary after adjustment by the auto tuning function.

• Manual gain tuning (advanced)

This function is an enhanced function used in the position or speed control mode to stabilize operation by advanced control. It is useful when further improvement in response and stability is necessary after adjustment by the auto tuning function.

■ List of Control Gain Parameter IDs

Parameter IDs that can be set for each function of automatic adjustment and manual adjustment are shown below.

| Classification | | Name | Symbol | Corresponding parameters to be set | | | |
|-------------------------------|---------------------------------|----------------------------------|-----------------------|--|----------------------------|--|---|
| Manual adjustment | Automatic adjustment | | | ID | Name | | |
| Manual gain tuning (advanced) | Manual gain tuning (basic) | Auto tuning function | Tuning-free function | Position loop gain | Kp | 50/60 | Position loop proportional gain 1 Position loop proportional gain 2 *1 |
| | | | | Speed loop gain | Kv | 51/61 | Speed loop proportional gain 1 Speed loop proportional gain 2 *1 |
| | | | | | Ki | 52/62 | Speed loop integral gain 1 Speed loop integral gain 2 *1 |
| | | | | Current loop gain | Kcp | 56 | Current loop proportional gain |
| | | | | | Kci | 57 | Current loop integral gain |
| | | | | Load inertia | Load | 59 | Load inertia |
| | | | Position feedforward | - | 68 | Position feedforward gain | |
| | | | Friction compensation | - | 300 | Friction compensation torque in the CW direction | |
| | | | | | 301 | Friction compensation torque in the CCW direction | |
| | | | | | 302 | Friction compensation viscous friction coefficient | |
| | | | Filters | - | 53/260 | Low-pass filter cutoff frequency 1–2 | |
| | | | | | 261 | Low-pass filter order 2 | |
| | | | | | 54/63/270/273 /276/279/282 | Notch filter center frequency 1–7 | |
| | | | | | 55/64/271/274 /277/280/283 | Notch filter attenuation 1–7 | |
| | 272/275/278 /281/284 | Bandwidth of notch filter 3 to 7 | | | | | |
| | Speed feedforward | - | 290 | Speed feedforward gain | | | |
| | | | 291 | The number of speed feedforward filters | | | |
| | Weight compensation | | 303 | Weight compensation torque | | | |
| | Disturbance observer | - | 310 | Disturbance observer gain | | | |
| | | | 311 | Disturbance observer LPF cut-off frequency | | | |
| | Speed stabilizing control | - | 320 | Speed stabilizing control time estimation | | | |
| | | | 321 | Speed stabilizing control gain 1 | | | |
| | | | 322 | Speed stabilizing control gain 2 | | | |
| | Position command Damping filter | - | 390 | Position command damping filter 1 center frequency | | | |
| | | | 391 | Position command damping filter 1 center attenuation | | | |
| | | | 392 | Position command damping filter 1 width | | | |

*1: Switching between Gain 1 (Kp1, Kv1, and Ki1) and Gain 2 (Kp2, Kv2, and Ki2) can be specified by gain switch settings (ID80 to 82).

12. Tuning-Free Function

The tuning-free function is a function of the driver to automatically tune the servo gain. During controlling by position control or speed control, the servo driver estimates the load inertia and friction correction value on a real time basis. With this, the optimum gain tuning is automatically conducted in accordance with the response settings set in advance.

This function is available with the driver software Ver. 6.00 or later..

12.1. Precautions for Use

The tuning-free function may not be correctly conducted in some cases under the following conditions:

- In the case where operation whose speed is less than 120 [rpm] is continued.
- In the case where operation whose acceleration/deceleration speed does not exceed 4000 [rpm/s].
- In the case where the torque at the time of acceleration/deceleration is too small.
- In the case where the load inertial is extremely small or large (not more than twice as much or 20 times as much as or more than the rotor inertia).
- In the case where the load inertia largely fluctuates.
- In the case where a large torque is added during acceleration/deceleration.
- In the case where mechanical rigidity is extremely low.
- In the case where a mechanical play is extremely large.

In the case where tuning is not correctly conducted, change the operating conditions or use auto-tuning by the dedicated application software "Motion Designer Driver," or conduct manual tuning.

When the tuning-free function is activated, as the following parameters are automatically updated, manual changes in settings are not accepted.

ID59 "load inertia," ID50 "position loop proportional gain," ID51 "speed loop proportional gain 1," ID52 "speed loop integration gain 1," ID60 "position loop proportional gain 2," ID61 "speed loop proportional gain 2," ID62 "speed loop integration gain 2," ID56 "current loop proportional gain," ID57 "current loop integration gain," ID68 "position feed forward gain," ID260 "low-pass filter cutoff frequency 2," ID261 "low-pass filter order 2," ID300 "friction compensation torque in the CW direction," ID301 "friction compensation torque in the CCW direction," and ID302 "friction correction viscosity friction coefficient."

If you want to change settings manually, deactivate the tuning-free function.

When the tuning-free function is activated, parameters are automatically saved once in 30 minutes.

If you do not want to have parameters be saved automatically, deactivate the tuning-free function.

12.2. Settings of Tuning-Free Function

In the tuning-free function, the following three parameters are set.

ID360 "tuning-free function mode"

- 0: tuning-free function is disabled.
- 1: only load inertia is estimated.
ID59 "load inertia" is automatically estimated and set.
- 2: load inertia and friction correction values are estimated.
ID59 "load inertia," ID300 "friction compensation torque in the CW direction," ID301 "friction compensation torque in the CCW direction," and ID302 "friction correction viscosity friction coefficient" are automatically estimated and set.

* The parameters for friction correction (ID300 to 302) are not used for controlling unless otherwise Bit 2 of ID256 "special function switching 2" is set to "1."

ID361 “tuning-free function response setting”

When the tuning-free function is enabled, the targeted servo response is set.

The setting range is 0 to 29 (factory setting 14). The larger the value is, the higher the response tuning becomes. But if the value is set to be too large, oscillation could be caused.

Use it within the scope not to cause oscillation.

| ID361 set value | Response speed | Guide for equipment |
|-----------------|----------------|---------------------|
| 29 | | |
| 28 | | |
| 27 | | |
| 26 | | |
| 25 | | |
| 24 | | |
| 23 | | |
| 22 | | |
| 21 | | |
| 20 | | |
| 19 | | |
| 18 | | |
| 17 | | |
| 16 | | |
| 15 | | |
| 14 | | |
| 13 | | |
| 12 | | |
| 11 | | |
| 10 | | |
| 9 | | |
| 8 | | |
| 7 | | |
| 6 | | |
| 5 | | |
| 4 | | |
| 3 | | |
| 2 | | |
| 1 | | |
| 0 | | |

ID256 “special function switching 2” (Bit 12)

In the case where oscillation is detected when the tuning-free function is enabled, it is possible to set whether the response setting is automatically lowered or not.

● In the case of Bit 12=0 of ID256,

Automatic setting of response setting at the time when oscillation is detection is “Enabled.”

In the case where motor oscillation is detection within 10 minutes after the tuning-free function is enabled for the first time, the value of ID361 “tuning-free function response setting” is automatically lowered.

● In the case of Bit 12=1 of ID256,

Automatic setting of response setting at the time when oscillation is detection is “Disabled.”

Even if motor oscillation is detected, the value of ID361 “tuning-free function response setting” is not changed.

*“The tuning-free function is enabled for the first time” means that ID360 “tuning-free function mode” is changed from “0” to “1” or “2” in the state where ID59 “load inertia” is set to “0.”

In the case where the power is turned on in the state where the tuning-free function is enabled in advance, or in the case where the tuning-free function is enabled in the state where ID59 “load inertia” is set, response setting at the time when oscillation is detected is not automatically set.

■ The method of setting in the case where the tuning-free function is used for the first time.

| Procedures | Operation | | |
|------------|---|---------------------------------------|---|
| | ID | Parameter name | Set value/Read value |
| ① | Load inertia is set to "0." | | |
| | 59 | Load inertia | 0 (g·cm ²) |
| ② | Tuning-free function response setting is set. | | |
| | 361 | Tuning-free function response setting | [Any value] (0~29) For safety, set lower values initially. For reference, in the case of high rigidity due to ball screws and others, set the value at about 13 to 14, and in the case of low rigidity due to belt driving and others, set the value at about 6 to 10. |
| ③ | The tuning-free function mode is selected from the following: | | |
| | 360 | Tuning-free function mode | 1: Only load inertia is estimated. 2: Load inertia and friction correction values are estimated. In the case where the friction correction function is used ("2"), set Bit 2 of ID256 "special function switching" to "1." |
| ④ | Drive by position control or speed control. As for the type of command, use the type that is actually used. As for operation, operate it with the operation patterns pursuant to the aforementioned precautions for use. | | |

The tuning-free function judges the initial tuning on the following conditions:

Conditions: In the state where the value of ID59 "load inertia" is "0," ID360 "tuning-free function mode" is changed from "0" to "1" or "2."

In the case where tuning is judged as the initial tuning, the estimated value of ID59 "load inertia" is changed to high speed first, and the value is leveled with time and changes are reduced.

*Though the value of ID59 "load inertia," which is immediately updated at the first time, may vary greatly in some cases due to speed at the time of initial operation/acceleration and deceleration speed/friction and others of machine, the value converges to the estimated value while operation is continued for a while.

If you want to change the response setting after of tuning is started, change the value of ID361 "tuning-free function response setting. In the case where the value is increased and oscillation (vibration) is caused, this point is the threshold value.

In the case of Bit 12="0" of ID256 "special function switching 2," the function to automatically reduce the value of ID361 "tuning-free function response setting" would work with oscillation detection only if ID360 "tuning-free function mode" is changed from "0" to "1" or "2" for the first time. This function is enabled only for 10 minutes immediately after ID360 "tuning-free function mode" is changed from "0" to "1" or "2."

When the tuning-free function is enabled, parameters are saved automatically once in 30 minutes.

■ The method of setting in the case where tuning is already conducted for 30 minutes or longer.

Tuning is resumed from the value set previously at the time when the power is turned on. Unlike the initial tuning, the estimated value of ID59 "load inertia" is leveled from the start and does not sharply change.

■ The method of setting in the case where the load inertia is known in advance.

| Procedures | Operation | | |
|------------|---|----------------|----------------------------------|
| | ID | Parameter name | Set value/Read value |
| ① | Load inertia is set. | | |
| | 59 | Load inertia | [Any value] (g·cm ²) |
| ② | Tuning-free function response setting is set. | | |

| | | | |
|---|------------|---|---|
| | 361 | Tuning-free function response setting | [Any value] (0~29) For safety, set lower values initially. For reference, in the case of high rigidity due to ball screws and others, set the value at about 13 to 14, and in the case of low rigidity due to belt driving and others, set the value at about 6 to 10. |
| ③ | | The tuning-free function mode is selected from the following: | |
| | 360 | Tuning-free function mode | 1: Only load inertia is estimated. 2: Load inertia and friction correction values are estimated. In the case where the friction correction function is used ("2"), set Bit 2 of ID256 "special function switching 2" to "1." |
| ④ | | Drive by position control or speed control. As for the type of command, use the type that is actually used. As for operation, operate it with the operation patterns pursuant to the aforementioned precautions for use. | |

In the case where ID360 "tuning-free function mode" changes from "0" to "1" or "2" in the state that the value of ID59 "load inertia" is those other than "0," the tuning is not judged as the initial tuning. Therefore, the estimated value of ID59 "load inertia" is leveled from the start and does not sharply changes, and it changes gradually from the default value to the estimated value.

*In the case where the value of ID59 "load inertia," which is set in advance, is not more than 2.5 times as much as the rotor inertia value of combination motor, the value of ID59 "load inertia" is renewed to the value 2.5 times as much as the motor rotor inertia.

● Parameters to be renewed

The tuning-free function renews the following parameters on a real time basis by using load characteristic estimated value in accordance with the setting of ID360 "tuning-free function mode."

| ID360 set value | ID | Parameter name |
|-----------------|-----|--|
| 1 / 2 | 59 | Load inertia |
| 2 | 300 | Friction correction CW directional torque |
| 2 | 301 | Friction correction CCW directional torque |
| 2 | 302 | Friction correction viscosity friction coefficient |

● Parameters to be set in accordance with response settings

The tuning-free function sets the following parameters in accordance with the set value of ID361 "tuning-free function response setting."

| ID | Parameter name |
|-----|------------------------------------|
| 50 | Position loop proportional gain 1 |
| 51 | Speed loop proportional gain 1 |
| 52 | Speed loop integration gain 1 |
| 260 | Low-pass filter cutoff frequency 2 |
| 56 | Current loop proportional gain |
| 57 | Current loop integration gain |

● Parameters to be set to fixed values

The tuning-free function sets the following parameters to fixed values.

| ID | Parameter name | Set value |
|-----|-------------------------|-----------------|
| 68 | Position forward gain | 30 [%] |
| 261 | Low-pass filter order 2 | 1 [First order] |

13. Manual Gain Tuning (Basic)

13.1. Servo Gain

■ Speed loop proportional gain (K_v)

As the load inertia increases, the speed loop response is reduced. For the speed loop proportional gain, the standard setting is determined in proportion to the inertia ratio between the load and motor. Increasing the speed loop proportional gain causes the motor to start vibrating during a run and stop. The value at which this happens is the speed loop proportional gain limit. Set it to approximately 80% of the limit value, keeping in mind variations between equipment.

■ Speed loop integral gain (K_i)

This gain has the effect of increasing the speed loop response. Increasing the speed loop integral gain to a certain amount increases the rigidity of the servo system. However, increasing it too much results in vibration in response.

Also increase the speed loop integral gain if adjusting the speed loop proportional gain fails to reduce overshooting during acceleration/deceleration, if there is significant rotational unevenness, or if you wish to reduce the positioning time. Set it to the highest value within the range that causes no vibration.

■ Position loop proportional gain (K_p)

The position loop proportional gain cannot be increased higher than the speed loop response. Therefore, before adjusting the position loop proportional gain, adjust the speed loop gain.

A greater position loop proportional gain improves the response to a position command. However, increasing it excessively contributes to increasing the overshoot that occurs after rotation has stopped. For equipment with low rigidity, the position loop proportional gain cannot be set to a high value.

■ Optimal servo gain adjustment

Adjust the three basic gains to their highest possible values so that the motor will stop without overshoot or any vibrations when it is stopped during high-speed rotation.



Important

Cautions for servo gain adjustment

The optimal servo gain value varies greatly according to the state of the load. Re-adjustment is required if the load conditions change.

The machine might generate large vibrations during gain adjustment. Therefore, perform gain adjustment in a state allowing rapid servo OFF or power shutdown.


13.2. Setting the Load Inertia

When the rigidity of the load is high, favorable servo performance can be obtained simple by using the inertia estimation function to estimate load inertia. During tuning, the motor repeats the forward-direction (CCW) and reverse-direction (CW) rotations.

It is recommended that when the inertia estimation function is to be used for adjustment, the adjustment be started in a state where each parameter is in the factory setting. Set the parameters in accordance with the following steps.

| Step | Operation | | | | | | | | | | | | | | | | | |
|------|--|------------------------------|-----------------------|-----|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|
| | ID | Parameter name | Setting value | | | | | | | | | | | | | | | |
| (1) | Set the control mode to inertia estimation mode. | | | | | | | | | | | | | | | | | |
| | 31 | Control Mode | 5 | | | | | | | | | | | | | | | |
| (2) | Set the speed loop proportional gain for tuning. For a high load, however, the setting will need to be changed. ⇒ Refer to □19.14 "Special Servo Parameters" | | | | | | | | | | | | | | | | | |
| | 145 | Speed loop proportional gain | 200 (factory setting) | | | | | | | | | | | | | | | |
| (3) | Servo ON. Servo ON starts inertia estimation. | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0001 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 |
| (4) | During tuning, the motor rotates for several seconds. Wait for the motor to stop. | | | | | | | | | | | | | | | | | |

Performing the above operations estimates the load inertia automatically, setting it in ID59 "Load Inertia."



Caution

In auto tuning, servo ON causes the motor to alternate between forward (CCW) direction rotation and reverse (CW) direction rotation. Before operating, check that the environment surrounding the motor is safe and then set the servo ON.

To set the load inertia manually, directly set the parameter ID59 "Load Inertia."

| ID | Parameter name | Description | Factory setting | Setting range |
|----|----------------|----------------------|-----------------|---------------|
| 59 | Load Inertia | [g·cm ²] | 0 | 0-50000 (*) |

* 0-3000 for software ver. 4.30 or earlier

Supplement

To efficiently make adjustments when the load inertia cannot be estimated, estimate the inertia by using the inertia estimation function and then increase/decrease the setting based on the estimated value.

13.3. Adjusting the Basic Gains

■ Adjusting the speed loop proportional gain and speed loop integral gain in speed control mode

To adjust servo gain, first use the speed control mode.

Set the parameters by following the procedures below, and then rotate the motor to check the conditions when the motor is stopped.

Supplement The steps shown in the following table should be performed when Bit 7 "Acceleration limit ON" of ID30 "Servo Command" has been set to OFF. If it is set to ON, set "30000" in ID35 "Deceleration."

| Step | Operation | | | | | | | | | | | | | | | | | | |
|------|--|-------------------------|---------------|-----|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | ID | Parameter name | Setting value | | | | | | | | | | | | | | | | |
| (1) | Set the control mode to speed control. | | | | | | | | | | | | | | | | | | |
| | 31 | Control Mode | 2 | | | | | | | | | | | | | | | | |
| (2) | Servo ON. | | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0001 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| | | | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 |
| (3) | Set the rotation speed to 3000 rpm. Rotate the motor at 3000 rpm. | | | | | | | | | | | | | | | | | | |
| | 37 | Real-time Command Speed | 3000 | | | | | | | | | | | | | | | | |
| (4) | Set the rotation speed to 0 rpm. Monitor the state of the load after rotation has stopped. | | | | | | | | | | | | | | | | | | |
| | 37 | Real-time Command Speed | 0 | | | | | | | | | | | | | | | | |

○ If the motor overshoots when it stops

Increase the speed loop proportional gain (Kv1). Increasing the speed loop integral gain (Ki1) is also effective.

○ If the motor vibrates when it stops

Slightly reduce the speed loop proportional gain (Kv1) or the speed loop integral gain (Ki1).

Reducing the low-pass filter cutoff frequency (LPF-f) value may deaden vibrations and allow you to increase the speed loop proportional gain (Kv1).

⇒ Refer to □13.4 "Filter Adjustment"

Supplement More reliable gain adjustment can be achieved by adjusting gains while checking servo rigidity by adding a force to the load when the motor is not operating, or by other methods.

| ID | Parameter name | Description | Factory setting | Setting range |
|----|----------------|---------------------------------------|------------------------------|---------------|
| 51 | Kv1 | Speed loop proportional gain 1 | 200 | 0-2000 |
| 52 | Ki1 | Speed loop integral gain 1 | 50 | 0-2000 |
| 53 | LPF-f | Low-pass Filter Cutoff Frequency (Hz) | Resolver: 600 Other: 1000 | 0-1000 |

■ Adjusting the position loop proportional gain (Kp1) in position control mode

After optimal gains have been set in speed control mode, use position control mode to check that there is no vibration after rotation stops. Set the parameters by following the procedures below, and then rotate the motor to check the conditions when the motor is stopped.

| Step | Operation | | | | | | | | | | | | | | | | | |
|------|--|---------------------------|---------------|-----|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|
| | ID | Parameter name | Setting value | | | | | | | | | | | | | | | |
| (1) | Set the control mode to position control. | | | | | | | | | | | | | | | | | |
| | 31 | Control Mode | 1 | | | | | | | | | | | | | | | |
| (2) | Reset the current position. Set the current position to "0." | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x4000 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 |
| (3) | Servo ON. Servo ON fixes the motor shaft. | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0001 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| (4) | Set the move target position. (Example: When a motor with a 1X resolver is rotated 100 turns in the forward direction) | | | | | | | | | | | | | | | | | |
| | 32 | Target Position | 204800 | | | | | | | | | | | | | | | |
| (5) | Set the target speed. Set to 3000 rpm. | | | | | | | | | | | | | | | | | |
| | 33 | Target Velocity | 3000 | | | | | | | | | | | | | | | |
| (6) | Set acceleration and deceleration. Set to 10000 rpm/sec. | | | | | | | | | | | | | | | | | |
| | 34 | Acceleration (10 rpm/sec) | 1000 | | | | | | | | | | | | | | | |
| | 35 | Deceleration (10 rpm/sec) | 1000 | | | | | | | | | | | | | | | |
| (7) | Profile ON. Rotation starts. The motor stops at the set position. Monitor the state. | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0003 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 |
| (8) | After the state during the rotation stop has been checked, turn the servo off. | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0000 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

Supplement

In profile operation, acceleration are based on the value set in ID34"Acceleration", deceleration are based on the value set in ID35"Deceleration"

○ If vibration occurs during the rotation stop after a positional move

Reduce the position loop proportional gain (Kp1).

| ID | Parameter name | Description | Factory setting | Setting range |
|----|----------------|-----------------------------------|-----------------|---------------|
| 50 | Kp1 | Position loop proportional gain 1 | | 0-799 |

○ If position excessive deviation (Alarm 42) occurs


Increase the position loop proportional gain (Kp1).

If the situation does not change, readjust the gain of the load inertia and that of the speed loop.

In addition, increase the value for the ID202 "Position Deviation Error Detection Pulse Count."

13.4. Filter Adjustment

In addition to servo gains, the driver also has a low-pass filter and a notch filter. Adjusting the frequency has the effect of reducing vibrations, which may allow servo gains to be set to greater values.



■ Adjusting the low-pass filter

Inserting the low-pass filter into a current command may reduce vibrations. Setting the cutoff frequency of the filter properly can further improve servo gains. The setting range for the cutoff frequency is usually approximately 100 to 1000 (Hz). Setting "0" disables the low-pass filter.

| ID | Parameter name | Description | Factory setting | Setting range |
|----|----------------|---------------------------------------|-----------------------------------|---------------|
| 53 | LPF-f | Low-pass filter cutoff frequency (Hz) | For resolver: 600 Others: 1000 | 0~1000 |

No. 2 low-pass filter is a low-pass filter of IIR type capable of switching from primary to secondary and vice versa. This parameter is automatically set at the time of auto-tuning.

| ID | Parameter name | Description | Factory setting | Setting range |
|-----|------------------------------------|---|-----------------|---------------|
| 260 | Low-pass filter cutoff frequency 2 | No. 2 low-pass filter cutoff frequency (Hz) 0 or lower and 5001 or higher: low-pass filter 2 disabled 1 to 5000: cutoff frequency set | 0 | 0~5000 |
| 261 | Low-pass filter order 2 | No. 2 low-pass filter order 0: secondary 1: primary | 0 | 0~1 |

■ Adjusting the notch filter


The notch filter attenuates a specific frequency, allowing machine oscillation to be suppressed without reducing the system response.

- Both the center frequency and the magnitude of attenuation of the notch filter can be adjusted.
- Setting the center frequency to "0" or "1000", or the magnitude of attenuation to "0" disables the notch filter.
- Guide for attenuation level: 30: -3 dB, 50: -5dB, 75: -12dB, 87: -18dB.



If the magnitude of attenuation is too large, oscillation could be caused. Set the magnitude of attenuation usually at 30 or lower for use.

| ID | Parameter name | Description | Factory setting | Setting range |
|----|----------------|--------------------------------------|-----------------|---------------|
| 54 | NF-f1 | Notch filter center frequency 1 (Hz) | 0 | 0-1000 |
| 55 | NF-d1 | Notch filter attenuation 1 (dB) | 0 | 0-1000 |
| 63 | NF-f2 | Notch filter center frequency 2 (Hz) | 0 | 0-1000 |
| 64 | NF-d2 | Notch filter attenuation 2 (dB) | 0 | 0-100 |



The setting method of the notch filters 3 to 7 is different from that of the notch filters 1 to 2.

- The center frequency, magnitude of attenuation and width of the notch filter can be adjusted respectively.
- Setting the center frequency to “0” or “5001” disables the notch filter.
- Guide for magnitude of attenuation: 100: 0dB, 70: -3dB, 40: -8dB, 20: -15dB, 0: -20dB, 0: -75dB.

| ID | Description | Factory setting | Setting range |
|---------------------|--|-----------------|---------------|
| 270/273/276/279/282 | Center frequency of notch filter 3 to 7 (Hz) | 0 | 0~5000 |
| 271/274/277/280/283 | Magnitude of attenuation of notch filter 3 to 7 (dB) | 0 | 0~100 |
| 272/275/278/281/284 | Width of notch filter 3 to 7 (Hz) | 50 | 1~100 |



注意

Do not set Center frequency of notch filter to less than 50 Hz. Motor runaway and vibration may occur. With driver software version 5.03 or later, settings below 50 Hz are automatically set to 50 Hz.

13.5. Confirming the Set Gains

Perform the following steps to check whether or not the set value is appropriate. Set the parameters (data IDs) by following the procedures below. Evaluate the setting by monitoring the state of the load when the motor has stopped following high-speed rotation.

| Step | Operation | | | | | | | | | | | | | | | | | | |
|------|--|-------------------------|---------------|-----|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | ID | Parameter name | Setting value | | | | | | | | | | | | | | | | |
| (1) | Set the control mode to speed control. | | | | | | | | | | | | | | | | | | |
| | 31 | Control Mode | 2 | | | | | | | | | | | | | | | | |
| (2) | Servo ON. | | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0001 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| | | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 |
| (3) | Set the rotation speed to 3000 rpm. Rotate the motor at 3000 rpm. | | | | | | | | | | | | | | | | | | |
| | 37 | Real-time Command Speed | 3000 | | | | | | | | | | | | | | | | |
| (4) | Set the rotation speed to 0 rpm. Monitor the state of the load after rotation has stopped. | | | | | | | | | | | | | | | | | | |
| | 37 | Real-time Command Speed | 0 | | | | | | | | | | | | | | | | |

■ Monitoring the load state after the motor is stopped from high-speed rotation

If there is no overshoot (stoppage after the target has been passed) or vibration after the motor has been stopped when running at high-speed rotation, the load inertia has been successfully adjusted. If overshoot and vibration persist, set the load inertia to a value at which less overshoot and vibration occur, and adjust the servo gains as described in the next chapter.

13.6. Gain-switch Function

In cases such as when the equipment is loose (backlash) or experiences vibrations during a rotation stop, using the gain-switch function may enable stabilization to be achieved more quickly.

By setting ID80 "Gain-Switch Method Select" to specify how to switch between Gain 1 (Kp1, Kv1, and Ki1) and Gain 2 (Kp2, Kv2, and Ki2), control performance can be improved.

■ Gain 1

| ID | Parameter name | Description |
|----|----------------|-----------------------------------|
| 50 | Kp1 | Position loop proportional gain 1 |
| 51 | Kv1 | Speed loop proportional gain 1 |
| 52 | Ki1 | Speed loop integral gain 1 |

■ Gain 2

| ID | Parameter name | Description |
|----|----------------|-----------------------------------|
| 60 | Kp2 | Position loop proportional gain 2 |
| 61 | Kv2 | Speed loop proportional gain 2 |
| 62 | Ki2 | Speed loop integral gain 2 |

■ Gain-switch method select


| ID | Parameter name | Setting value | Description |
|----|---------------------------|---------------|--|
| 80 | Select Gain-switch Method | 0 | No switching (fixed to gain 1) |
| | | 1 | Automatically switched by speed command |
| | | 2 | Automatically switched by motor feedback speed |
| | | 3 | Automatically switched by position deviation value |
| | | 4 | Switched by I/O input command |
| | | 5 | Switched by Bit 11 of ID30 "Servo Command" |
| | | 6 | Switched when motor stopping command is continued for the specified time or longer |
| | | 7 | Switched when motor stopping command is continued for the specified time or longer with a current command lower than or equal to the specified value |
| | | 9 | No switching (fixed to gain 2) |

The factory setting is "0."

■ Gain-switch point

The gain-switch point is enabled when ID80 "Gain-Switch Method Select" is 1 to 3. Switchover to Gain 1 takes place when the speed or deviation exceeds the gain-switch point H, and switchover to Gain 2 takes place when it falls below the gain-switch point L. Switchover takes place smoothly between the two points while interpolating between Gains 1 and 2.

| ID | Parameter name | Description | Factory setting | Setting range |
|----|-------------------|--|-----------------|---------------|
| 81 | GainChangePoint_H | Gain-switch point H [rpm] or [pulse] Set in units of rpm if ID80 "Gain-Switch Method Select" is set to 1 or 2 and in units of pulses if it is set to 3. | 100 | 0-32767 |
| 82 | GainChangePoint_L | Gain-switch point L [rpm] or [pulse] Set in units of rpm if ID80 "Gain-Switch Method Select" is set to 1 or 2 and in units of pulses if it is set to 3. | 50 | 0-32767 |



| Speed command/motor feedback speed/position deviation value | Gain used |
|---|-----------------------------|
| Gain-switch point: H or more | Gain 1 |
| Gain-switch point: Between H and L | Value linearly interpolated |
| Gain-switch point: L or less | Gain 2 |

■ Switching gains by "Servo Command"

When it is necessary to switch gain by the Bit 11 "second gain switch" of ID30 "Servo Command," the ID80 "Gain-Switch Method Select" needs to be set to "5" in advance.

| ID | Parameter name | Setting value | Setting value | | | | | | | | | | | | | | | |
|----|----------------|---------------|---------------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | | | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| 30 | Servo Command | 0x0800 | * | * | * | * | 1 | * | * | * | * | * | * | * | * | * | * | * |

ON (1) : Gain 2
OFF (0) : Gain 1

■ Switching gains in response to motor rotation/stop

When ID80 "Gain-Switch Method Select" is set at 6 or 7, gain is switched in response to the rotation/stop of the motor. Note that the descriptions for ID81 and ID82 are different from those that ordinarily apply.

| ID | Description |
|----|--|
| 81 | Stop Speed Judgment Time [msec] Gain is switched when the motor stopping command (position control: no change in command value; speed control: speed 0 command) is continued for the set value of time or longer. |
| 82 | Stop Speed Judgment Current Command [0.01 A] (only when ID80 = 7) Gain is switched when the current command is the set value or lower in addition to the judgment from Stop Command Time. |

■ Speed limit switching

By setting Bit 11 "speed limit switching" of ID256 "special function switching 2" to "1," the speed limit can also be changed at the time of gain switch.

When ID80 "gain switch method select" is set to between 1 and 3, in the case of gain-switch point of H or higher, the speed limit changes to ID88 "speed limit," and in the case of gain-switch point of L or lower, the speed limit changes to ID89 "speed limit 2, and at the midpoint, the speed limit is interpolated by speed limit 1 and speed limit 2 and changes smoothly.

13.7. Saving Parameters

After parameter setting has been completed, the new parameters need to be saved to nonvolatile memory. Turning off the driver without saving them to nonvolatile memory will result in the set values being erased. This section describes how to save set values to nonvolatile memory.

1. To use pulse or analog input for position, speed, and torque commands, pre-set the control method in ID74 "Position Command Select," ID75 "Speed Command Select," and ID76 "Torque Command Select."
2. Perform the following steps to save parameters:

| Step | Operation | | |
|------|--|-----------------|---------------|
| | ID | Parameter name | Setting value |
| (1) | Save parameters to nonvolatile memory. | | |
| | 17 | Parameters save | 1 |

Those parameters whose "M" column field is marked with in 19 "List of Parameters" are saved to the nonvolatile memory by this operation. Usually you should store parameters with the servo OFF. After the parameter storing has been completed, the value returns to "0."


14. Manual Gain Tuning (Advanced)

This chapter assumes the use of the dedicated application "Motion Designer Drive."
"Motion Adjuster" does not support the monitoring function and automatic settings.

14.1. Position Command Damping Filter

The position command damping filter suppresses vibrations at the tip of the device during position control.

It is effective for relatively low frequencies at about 1 to 100 Hz.



This function is available with the driver software Ver. 4.61 or later.


This function can be used only in the position control mode with the fine rotation axis, regardless of the type of command: profile operation, position command via communication, and pulse input.

The position command damping filter suppresses vibrations by removing the device's vibration frequency component from the position command.

The frequency to be set for filtering can be measured by using the frequency sweep function provided by "Motion Designer Drive."

When the frequency analysis screen is displayed by the frequency sweep function, find a point where the gain drops (Antiresonance point), and set the frequency at the point to ID390 "Position Command Damping Filter 1 Center Frequency."

It may be more effective to set a value that is 5 to 10% lower than the frequency at the antiresonance point obtained from an actual measurement.



Note that, under any of the following conditions, the filter cannot produce the damping effect and requires adjustment in a different way.

- (1) When the vibration frequency is 100 Hz or higher
→ Try the notch filter.
- (2) When vibration is caused by an external force
→ Increase the gain or try the disturbance observer.
- (3) When the load is heavy and the torque (current) is saturated for a long time during movement
→ Adjust the acceleration or deceleration for example, by using the smoothing function.

■ Method for setting the position command damping filter

| Step | Operation | |
|------|---|--|
| | ID | Setting/read value |
| (1) | Measure the frequency characteristic of the device by using the frequency sweep function provided by Motion Designer Drive. | |
| (2) | Set the center frequency of the damping filter. | |
| | 390 Position Command Damping Filter 1 Center Frequency | Arbitrary (0.1 Hz) Set a value in the range of 10 to 1000. Set a value that is about 5 to 10% lower than the frequency at the antiresonance point obtained from an actual measurement. |
| (3) | Set the attenuation as needed. | |
| | 391 Position Command Damping Filter 1 Attenuation | Arbitrary Usually, keep the default value (0). Rough standard for attenuation: 70 = -3 dB, 20 = -15 dB, 10 = -20 dB, 0 = -75 dB |
| (4) | Set the width as needed. | |
| | 392 Position Command Damping Filter 1 Width | Arbitrary Usually, keep the default value (50). As this setting value becomes smaller, the attenuated frequency range becomes narrower and steeper. |

14.2. Speed Stabilization Control

By using the speed stabilization control, it is possible to improve the accuracy of speed calculation and reduce harmful speed ripples due to calculation errors.

This enables high gain (high rigidity) adjustment even for sensors with relatively low resolution.

This control also has the effect of reducing noise unique to analog sensors such as resolvers.

This function can be used only in the position control mode with the finite rotation axis.

Do not use this function for operation in speed or current control mode.

This function uses the value of parameter ID59 "Load Inertia" and must not be used for a system in which the load inertia is unknown or varies significantly.

This function is automatically set by auto tuning by "Motion Designer Drive."

Selecting "Enable speed stabilization control" during auto tuning sets the optimum value for the type and resolution of the sensor and the load inertia.

The following parameters are changed by automatic setting:


- Bit 4 of ID257 "Observer Switch"
- ID320 "Speed Stabilization Control Estimated Time"
- ID321 "Speed Stabilization Control Gain 1"
- ID322 "Speed Stabilization Control Gain 2"

14.3. Feed-forward Functions

"Position Feed-forward" and "Speed Feed-forward" functions are available as functions for hastening responses to commands.

The position feed-forward function adds a theoretical speed command calculated from a position command to a speed command directly without the position loop, and has the effect of reducing position deviations.

The speed feed-forward function adds the theoretical current command calculated from a speed command and the inertia to a current command directly without the speed loop, and has the effect of reducing speed deviations.



Set ID68 "Position Feed-forward Gain" to hasten position responses, and set ID290 "Speed Feed-forward Gain" to hasten speed responses.

Both gains are to be set in percentage [%]. Set 0 [%] to disable the feed-forward function(s), or set 100 [%] for 100% feed-forward commands or namely for the theoretical zero-deviation control.

The speed feed-forward gain can be set not only up to 100% but also up to 500%.


In addition, the speed feed-forward can be filtered by averaging according to the setting of ID291 "Speed Feed-forward Filter Number." It may be better to set the filter for example, when analog speed commands are significantly affected by noise.

The speed command acceleration calculation cycle can be set at Bit 3-0 of ID291 "Speed Feed-forward Filter Number", and the averaged number of speed feed-forward commands can be set at Bit 7-4 thereof.

Increasing the feed-forward gain improves the responsiveness and decreases the deviation, but increasing it excessively may result in problems such as large overshoot and vibration (oscillation) from effects due to disturbances and the device rigidity. When setting the feed-forward functions, increase their gains gradually from 0 [%] after making the usual gain adjustment.

14.4. Disturbance Observer

The disturbance observer is a control function that estimates the disturbance torque from a current command and a speed feedback and corrects the current command to negate the disturbance torque. This function can improve the motor shaft response performance to external disturbances. The disturbance observer can also be used to hasten speed responses while keeping the speed loop gain low, and as such it can be expected to produce a damping effect.



Set Bit 0 of ID257 "Observer Switch" to "1" to enable the disturbance observer.

Set the intensity of the disturbance observer in ID310 "Disturbance Observer Gain." The unit is [%] and the intensity is set until 500%.

The intensity is to be set at percentage [%] and can be set to up to 500%.

When there is an annoying sound due to noise and other harmonic components, setting ID311 "Disturbance Observer LPF Frequency" can remove frequency components above the setting value.

■ Method for setting the disturbance observer


| Step | Operation | | | | | | | | | | | | | | | | | |
|---|--|------------------------------------|--|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | ID | Parameter name | Setting/read value | | | | | | | | | | | | | | | |
| (1) | Enable the disturbance observer. | | | | | | | | | | | | | | | | | |
| | 257 | Observer Switch | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| | | | * | * | * | * | * | * | * | * | * | * | * | * | * | * | * | 1 |
| (2) | Gradually increase the disturbance observer gain. | | | | | | | | | | | | | | | | | |
| | 310 | Disturbance Observer Gain | Arbitrary (%) Set a value in the range of 1 to 500. | | | | | | | | | | | | | | | |
| (3) | Adjust the disturbance observer LPF frequency as needed. | | | | | | | | | | | | | | | | | |
| | 311 | Disturbance Observer LPF Frequency | Arbitrary (Hz) Set a value in the range of 1 to 3000. | | | | | | | | | | | | | | | |
| <ul style="list-style-type: none"> As the disturbance observer gain becomes higher, the responsiveness to disturbances increases. However, when the disturbance observer gain is too high, it may cause problems, such as a loud driving sound and oscillation. Decreasing the disturbance observer LPF frequency lowers the responsiveness performance, but may render the effect of reducing the driving sound. | | | | | | | | | | | | | | | | | | |

14.5. Correction for Friction and Gravity

Correcting for friction and gravity cancels friction and gravity torques to reduce delay in response to torque fluctuations by including the current corresponding to the torque components associated with friction and own weight of a device in the current command.

The function is particularly effective for addressing quadrant protrusion experienced by precision machines.

Correction can be made with torques from static friction, viscous friction, and gravity.



Corrections for friction and gravity are illustrated in the figures above.

Correction for friction is enabled by assigning "1" for Bit 2 in ID 256 "Special Function Switching 2."
Correction for friction is enabled by assigning "1" for Bit 3 in ID 256 "Special Function Switching 2."

When correction for friction is enabled, the current corresponding to ID 300 "Friction Compensation Torque in the CW Direction" [0.01 A] is deducted from the torque command when the motor shaft rotates CW.

In contrast, the current corresponding to ID 301 "Friction Compensation Torque in the CCW Direction" [0.01 A] is added to the torque command when the shaft rotates CCW.

Torques from friction components are cancelled in this manner.

Note that the value of 0 for ID 302 "Friction Compensation Viscous Friction Coefficient" brings the slope in the above figure to nil. In this case, the correction is performed only for static friction, which fact makes the friction correction constant regardless of the speed.

When any value is assigned for ID 302 "Friction Compensation Viscous Friction Coefficient," the friction correction grows larger in proportion to the speed increase. The greater the assigned value, the steeper the slope becomes for the friction correction. Viscous friction can be cancelled when the slope coincides with the characteristic of a device.

Assign a value to ID 303 "Weight Compensation Torque" [0.01A] in order to add gravity correction torque for a vertical shift by the amount of correction. The correction is made in the positive direction when a positive value is assigned, and the negative direction when a negative value is assigned.

Torques corresponding to gravity can be cancelled in this manner. A positive assigned value indicates that CW is directed upward.

14.5.1. Auto-configuration

Auto-configuration can be made with ID 300 "Friction Compensation Torque in the CW Direction," ID 301 "Friction Compensation Torque in the CCW Direction," and ID 303 "Weight Compensation Torque."

Note that auto-configuration is not possible with ID 302 "Friction Compensation Viscous Friction Coefficient." It must be manually configured.

| Step | Operation | | | | | | | | | | | | | | | | | | |
|------|--|----------------|--------------------|-----|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | ID | Parameter name | Setting/read value | | | | | | | | | | | | | | | | |
| (1) | Choose torque estimation mode for making a correction for friction. | | | | | | | | | | | | | | | | | | |
| | 31 | Control mode | 6 | | | | | | | | | | | | | | | | |
| (2) | Servo On: Once the servo is turned on, the motor shaft makes four round trips at around 3 rpm at 2-second intervals. | | | | | | | | | | | | | | | | | | |
| | 30 | Servo command | 0x0001 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| | | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 |
| (3) | Auto-configuration is completed in about 20 seconds. Once auto-configuration is complete, the motor shaft stops at 0 rpm. | | | | | | | | | | | | | | | | | | |
| | (4) Once auto-configuration is complete, values are assigned to ID 300, ID 301, and ID 303. | | | | | | | | | | | | | | | | | | |
| (5) | Servo Off: Turn off the servo and go back to the original control mode. | | | | | | | | | | | | | | | | | | |
| | 30 | Servo command | 0x0000 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| | | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

Automatically assigned values for correction for static friction and gravity may include nonuniformities and errors in measurements depending on the stiffness and backlash of your device in some cases.

If an errors is a problem for you, fine tune the settings manually after the auto-configuration.

Note that auto-configuration is not possible with ID 302 "Friction Compensation Viscous Friction Coefficient." It must be manually configured. ⇒ Refer to □ 14.5.2 "Manual Configuration"

In order to use a set parameter for correction, "1" must be assigned to Bit 2 and Bit 3 in ID 256 "Special Function Switching 2."

14.5.2. Manual Configuration



Caution

- Assignment of a value far beyond the optimal value may make the motor uncontrollable or cause large vibrations. Gradually assign larger values while ensuring safety in the surrounding area.
- During manual configuration, a shaft being adjusted may suddenly stop or start oscillating. Leave a sufficient margin of movable range to make an adjustment.


Friction correction

First, make an ordinary gain adjustment and drive the target device under typical operating conditions.

Then, use the digital oscilloscope function in Motion Designer Drive to display the waveforms for adjustment of "instantaneous speed" (= feedback speed) by type of speed log in the log setting, Parameter ID 462 "Internal Speed Command Monitor 2" (= speed command), and ID 470 "Speed Integration Monitor" (Speed integral value).

A considerably large value assigned for the gain makes it difficult to identify spots affected by friction just by observing the feedback speed waveform. Additional observation of the speed integral value facilitates discrimination of such subtle impacts.

The figure below presents a digital oscilloscope waveform when a trapezoidal speed command was given around 0 rpm without correcting for friction.



Without correction for friction, the feedback speed lags behind the speed command during sign transition (change in the direction of motor rotation).


In this event, the speed integral value steeply rises in order to compensate for the change in static friction torque.

The motor speed catches up with the command speed when the speed integral value increases. Given that a faster speed results in a greater torque associated with viscous friction, the speed integral value continues to rise proportionately to the speed.

In order to perform correction for friction, enable the function by assigning "1" to Bit 2 in ID 256 "Special Function Switching 2."


Then, gradually increase the assigned values for ID 300 "Friction Compensation Torque in the CW Direction" [0.01 A] and ID 301 "Friction Compensation Torque in the CCW Direction" [0.01 A] to curb the rise in speed integral associated with static friction. Adjust to bring this rise in speed integral close to 0.

Assignment of an excessively large value leads the sign transition of speed integral value. In order to avoid such over-compensation, assign a smaller value.




Next, gradually increase the assigned value for ID 302 "Friction Compensation Torque in the CCW Direction" to curb the rise in speed integral caused by viscous friction. Adjust to bring the rise in speed integral close to 0.

Assigning an excessively large value leads the sign transition of the speed integral value. In order to avoid such over-compensation, assign a smaller value.



- Correction for gravity
 Vertical shafts and other shafts subject to effects from gravity constantly generate torque to compete with and overcome gravity.
 In the same way as manual configuration of correction for friction, a waveform displayed with the digital oscilloscope function of Motion Designer Drive offsets the impact from gravity from the speed integral of 0.



In order to perform correction for gravity, enable the function by assigning "1" to Bit 3 of ID 256 "Special Function Switching 2."

Correction for gravity is made when a value is assigned to ID 303 "Weight Compensation Torque" [0.01 A] to shift the speed integral upward or downward.

Increase an assigned value in the positive direction when CW is directed upward. Increase an assigned value in the negative direction when CCW is directed upward.

Once the center of speed integral is adjusted to 0, the gravity torque is cancelled out.

15. Operation

15.1. Position Control Mode

Operations in position control mode are divided into three control types.

1. Profile Operation

In this operation type, the driver calculates trapezoidal-path movement patterns based on the target position, target speed, acceleration, deceleration, and other settings. This method allows easy operation because the host controller does not need to calculate operation patterns. However, this method cannot be used for complex movements other than trapezoid-path movement patterns.

2. Real-Time Position Command (SV-NET)

In this operation type, the SV-NET controller constantly sends position commands so that the driver can operate following those position commands. The SV-NET controller controls the driver by continuously sending a position command at specified time intervals. The motor operates at a constant speed if the amounts of change in command values are constant; it accelerates or decelerates if they are not constant. The real-time position command method allows fast and complex movements, but to control the motor steplessly and smoothly, the SV-NET controller needs to perform somewhat advanced calculations.

3. Command Pulse Input

In this operation type, the driver operates according to a position command pulse signal that is input from the I/O connector. This operation type is mainly used when the host controller serves as a sequencer or similar means to control the driver by way of pulse signals.

This section describes the general operational procedures for these operation types.

To run in profile operation

| Step | Operation | | | | | | | | | | | | | | | | | | |
|------|---|-------------------------|--|-----|-------|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | ID | Parameter name | Setting/read value | | | | | | | | | | | | | | | | |
| (1) | Set Position Command Select to communication command. | | | | | | | | | | | | | | | | | | |
| | 74 | Position Command Select | 0x00 | | | | | | | | | | | | | | | | |
| (2) | Set the control mode to position control. | | | | | | | | | | | | | | | | | | |
| | 31 | Control Mode | 1 | | | | | | | | | | | | | | | | |
| (3) | Set to servo ON (ID30; Bit 0: ON). Servo ON fixes the motor shaft. | | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0001 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| | | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | |
| (4) | Read the current position. | | | | | | | | | | | | | | | | | | |
| | 40 | Feedback Position | Current position (pulse) | | | | | | | | | | | | | | | | |
| (5) | Set the target position. | | | | | | | | | | | | | | | | | | |
| | 32 | Target Position | Current position + Move distance (pulse) | | | | | | | | | | | | | | | | |
| | Set the target speed. | | | | | | | | | | | | | | | | | | |
| | 33 | Target Velocity | Arbitrary (rpm) | | | | | | | | | | | | | | | | |
| | Set acceleration and deceleration. | | | | | | | | | | | | | | | | | | |
| | 34 | Acceleration | Arbitrary (10 rpm/sec) | | | | | | | | | | | | | | | | |
| | 35 | Deceleration | Arbitrary (10 rpm/sec) | | | | | | | | | | | | | | | | |
| (6) | Set Profile Operation Enabled to ON (ID30; Bit 1: ON). Move starts. | | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0003 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| | | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | |
| (7) | Regardless of whether or not the motor is running, the target position, target speed, acceleration, and deceleration can be changed. If these values are changed, the new values are reflected immediately whether the motor is in operation or not. However, if the target position is changed to a closer position during deceleration to cause a gap between the stop position after deceleration and the target position, the motor decelerates to stop, and then goes back to the target position. | | | | | | | | | | | | | | | | | | |
| (8) | While profile operation is enabled, Bit1 "During profile operation" of ID20 is ON. Entering the stop position range sets Bit2 "In Position" of ID20 to ON. If Bit 1 of ID69 "Control switch" is set to 1, Bit 1 of ID30 and Bit 1 of ID20 are automatically set to OFF after a single profile operation, which ends profile operation. | | | | | | | | | | | | | | | | | | |
| | 20 | Servo Status | B31 | B30 | ----- | | | | | | | | | | B4 | B3 | B2 | B1 | B0 |
| | | | * | * | ----- | | | | | | | | | | * | * | 1 | 1 | 1 |

To run with real-time position commands

| Step | Description | | | | | | | | | | | | | | | | | | |
|------|---|----------------------------|--|-----|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | ID | Parameter name | Setting/read value | | | | | | | | | | | | | | | | |
| (1) | Set Position Command Select to communication command. | | | | | | | | | | | | | | | | | | |
| | 74 | Position Command Select | 0x00 | | | | | | | | | | | | | | | | |
| (2) | Set the control mode to position control. | | | | | | | | | | | | | | | | | | |
| | 31 | Control Mode | 1 | | | | | | | | | | | | | | | | |
| (3) | Set to servo ON (ID30; Bit 0: ON). Servo ON fixes the motor shaft. | | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0001 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| | | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 |
| (4) | Check the current position. | | | | | | | | | | | | | | | | | | |
| | 40 | Feedback Position | Current position (pulse) | | | | | | | | | | | | | | | | |
| (5) | Set the real-time position command. | | | | | | | | | | | | | | | | | | |
| | 36 | Real-time Command Position | Current position + Move distance (pulse) | | | | | | | | | | | | | | | | |
| (6) | Repeatedly input ID36 "Real-time Command Position." In this case, the SV-NET controller controls speed, acceleration, and deceleration. | | | | | | | | | | | | | | | | | | |

To run with a pulse command from the I/O connector

| Step | Description | | | | | | | | | | | | | | | | |
|------|--|-------------------------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| | ID | Parameter name | Setting/read value | | | | | | | | | | | | | | |
| (1) | Set position command select to pulse input. | | | | | | | | | | | | | | | | |
| | 74 | Position Command Select | 0x01 | | | | | | | | | | | | | | |
| (2) | Set the pulse input type (for details, refer to the next page). | | | | | | | | | | | | | | | | |
| | 120 | Pulse Input Mode | Bit 0 = 0: Forward/reverse pulse Bit 0 = 1: Pulse/rotation direction The polarity is reversed when Bit 7 is 1. | | | | | | | | | | | | | | |
| (3) | Set the control mode to position control. | | | | | | | | | | | | | | | | |
| | 31 | Control Mode | 1 | | | | | | | | | | | | | | |
| (4) | Parameter save. Store the pulse input setting. | | | | | | | | | | | | | | | | |
| | 17 | Parameters save | 1 | | | | | | | | | | | | | | |
| (5) | Restart the power supply (after changing and saving the pulse input setting parameter, restart the power supply). | | | | | | | | | | | | | | | | |
| (6) | Turn on the IN5 (input 5: deviation reset input) signal. The deviation counter is reset. | | | | | | | | | | | | | | | | |
| (7) | Turn on the IN1 (input 1: servo ON input) signal. Servo ON fixes the motor shaft. | | | | | | | | | | | | | | | | |
| (8) | Rotation starts when pulses selected in ID120 "Pulse Input Mode" are input through the I/O connector. In this case, speed, acceleration, and deceleration are controlled by a host system that generates the pulses. | | | | | | | | | | | | | | | | |

15.1.1. Pulse Input Signal Types

| ID | Parameter name | Setting value |
|-----|------------------|---|
| 120 | Pulse Input Mode | 0: Forward /reverse pulse 1: Pulse/rotation direction 2: 90°-phase-difference two-phase pulse mode The polarity is reversed when Bit 7 is 1. |


When the motor is operated by using the pulse input from the I/O connector as the position command signal, a pulse input signal type can be selected from between two types by setting "Pulse Input Signal Mode Select." This section describes the two pulse input signal types on the assumption that ID72 "Reference Direction" is set to "0," or its factory setting (forward direction (CCW)).

Forward rotation pulse/reverse rotation pulse

- I/O connector input pin

| Pin No. | Function | Description |
|---------|---------------|----------------------------------|
| 15,16 | Pulse input 1 | Forward-rotation command pulse + |
| 17 | | Forward-rotation command pulse - |
| 19,20 | Pulse input 2 | Reverse-rotation command pulse + |
| 21 | | Reverse-rotation command pulse - |

- Pulse input type




Pulse/rotation direction

- I/O connector input pin

| Pin No. | Function | Description |
|---------|---------------|----------------------|
| 15,16 | Pulse input 1 | Command pulse + |
| 17 | | Command pulse - |
| 19,20 | Pulse input 2 | Rotation direction + |
| 21 | | Rotation direction - |

- Pulse input type




90°-phase-difference two-phase pulse mode

- I/O connector input pin

| Pin No. | Function | Description |
|---------|---------------|-----------------|
| 15,16 | Pulse input 1 | A-phase pulse + |
| 17 | | A-phase pulse - |
| 19,20 | Pulse input 2 | B-phase pulse + |
| 21 | | B-phase pulse - |

- Pulse input type



- The direction is forward when the A-phase pulse leads by 90°. The direction is reverse when the B-phase pulse leads by 90°.
- Pulses are counted at each edge.

15.1.2. Pulse Command Software Filter Function

| ID | Parameter name | Setting value |
|-----|------------------|--|
| 120 | Pulse Input Mode | Bit 5 and Bit 4: Pulse command software filter 00: No filter 01: 500 kHz (allowable frequency) 10: 250 kHz (allowable frequency) 11: 125 kHz (allowable frequency) |

This function can set a filter for pulse commands, that acts as a lowpass filter for the set frequency.

15.1.3. Setting the Pulse Input Signal Resolution (Setting the Electronic Gear)





| ID | Parameter name | Factory setting | Setting range |
|-----|--|-----------------|---------------|
| 121 | Pulse Input Signal Resolution: numerator (N) | 2048 | 1-1073741825 |
| 122 | Pulse Input Signal Resolution: denominator (M) | 1 | 1-16384 |

Factory setting: 2048 pulses

In operation using pulse input for position control, the resolution of pulse input signals (the rotation angle of the motor shaft per pulse of input command from a higher-level device) can be arbitrarily set by changing the data of "ID121" and "ID122" (electronic gear). The pulse command resolution corresponding to one turn is given by the following expression.

$$\text{Pulse command resolution corresponding to one turn} = \frac{\text{Numerator of pulse input signal resolution}}{\text{Denominator of pulse input signal resolution}} = \frac{N}{M}$$

Example) When ID121 = 20480 and ID122 = 5, the motor shaft rotates by five turns for 20480 pulses.

- 
Important Under normal circumstances, set the pulse command resolution to equal to or less than the position control resolution of the driver. (The position resolution differs depending on the motor sensors) ⇒ Refer to □1.2. "Specifications."
- 
Important ID 121/ID 122 "Pulse Input Signal Resolution: numerator/denominator" are enabled when ID 74 "Position Command Select" is set to "1" for pulse input. This is not reflected in the position commands sent from SV-NET.
- 
Important Make an appropriate setting so that the value of [ID122 × sensor resolution] will be 0x70000000 or lower.
- 
Important Whenever ID121/ID122 is changed, make sure to backup data and restart the power supply.


15.1.4. Deviation Reset

Deviation reset by I/O

I/O connector

| Pin No. | Function (Factory setting) |
|---------|----------------------------|
| 7 | Input 5 (deviation reset) |

This function is used mainly to operate using position control pulse inputs. Setting Deviation Reset to ON (L level) resets the position deviation counter to "0." Setting Counter Reset to ON during pulse input stops motor rotation. Until set to OFF, the position deviation remains fixed at 0. Before starting operation using position control pulse inputs, set the Counter Reset to ON before servo ON in order to avoid a position deviation error.



Automatic deviation counter reset

If the Control Selection Flag Bit 0 is set to "1," the position deviation counter is fixed at "0" while the servo is OFF.

| ID | Parameter name | Setting | Factory setting | Reference |
|----|----------------|---|-----------------|-----------|
| 69 | Control Switch | Automatic deviation reset Bit 0: 0: Disable, 1: Enable | 0x0001 | ⇒ □19.7 |

15.1.5. Pulse Input Disable Function

I/O connector

| Pin No. | Function (Factory setting) |
|---------|---------------------------------------|
| 10 | Input 8 (pulse input disable command) |

This function is used to operate using position control pulse inputs. When the pulse input disable command is set to ON, the motor ignores pulse commands from the host controller, and stops rotating. It does not rotate until the command is set to OFF.

If the motor stops with Deviation Reset ON, moving the motor shaft by external force does not change the position deviation, which remains 0. The static rigidity is therefore lowered. A stop due to the pulse input disable function causes a deviation from the rotation of the motor shaft, and the motor is made to stop at the latest command position under position control.


15.1.6. Smoothing Time Setting Function

| ID | Parameter name | Factory setting | Setting range |
|----|------------------|-----------------|--|
| 78 | Smoothing Time 1 | 0 [msec] | 0 to 1638 <input type="text" value="DEC"/> |
| 79 | Smoothing Time 2 | 0 [msec] | 0 to 1638 <input type="text" value="DEC"/> |

This setting is made when smoother operation is needed in position control. Motion in response to the position command is smoothed by applying a moving average for the set time to the amount of change in the position command value.

This function acts as a primary filter when only Smoothing Time 1 is set. It acts as a secondary filter when both Smoothing Time 1 and 2 are set.


When Smoothing Time 1 is set to "0," Smoothing Time 1 and 2 will be disabled.



Caution

Do not change the set values during servo ON.
Such an operation might cause unexpected motion.

Attainment of speed



Supplement

When the smoothing time is set, the position deviation is given as the difference between the position specified by the position command after filtering and the current position.


15.1.7. Positioning Completion Signal (In-position) Function

I/O connector

| Pin No. | Function (factory setting) |
|-----------|------------------------------|
| 32 and 33 | Ouput 2 (in-position signal) |

| ID | Parameter name | Factory setting | Setting range |
|----|---|-----------------|---------------|
| 77 | In-position (positioning completion) signal range | Using a sensor | 1 to 32767 |

The positioning completion status can be found by checking Output 2 (in-position). In position control, Output 2 (in-position signal) is ON when the value of the position deviation is smaller than or equal to the in-position (positioning completion) signal range set by ID77.



15.2. Speed Control Mode

Speed control operation has two control types.

1. Real-time speed command (SV-NET)

This control type operates the motor with speed commands sent from the SV-NET controller. When a command speed value sent from the SV-NET controller is received, the motor starts to rotate and maintains the same speed. By continuously changing the speed, acceleration/deceleration can be controlled.

2. Analog speed command

Operation is achieved by using the analog signal input through the I/O connector as the speed command.

To run with a real-time speed command

| Step | Operation | | | | | | | | | | | | | | | | | |
|------|--|-------------------------|------------------------|-----|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|
| | ID | Parameter name | Setting/read value | | | | | | | | | | | | | | | |
| (1) | Set Speed Command Select to speed command via communication. | | | | | | | | | | | | | | | | | |
| | 75 | Speed Command Select | 0x00 | | | | | | | | | | | | | | | |
| (2) | Set the control mode to speed control. | | | | | | | | | | | | | | | | | |
| | 31 | Control Mode | 2 | | | | | | | | | | | | | | | |
| (3) | Set Bit 7 "Acceleration limit ON" of ID30 to ON. Enable ID34 "Acceleration" and ID35 "Deceleration." | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0080 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 |
| | | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| (4) | Servo ON. Servo ON fixes the motor shaft.(*1) | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0081 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 |
| | | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 1 |
| (5) | Set the acceleration. | | | | | | | | | | | | | | | | | |
| | 34 | Acceleration | Arbitrary (10 rpm/sec) | | | | | | | | | | | | | | | |
| (6) | Set the deceleration. | | | | | | | | | | | | | | | | | |
| | 35 | Deceleration | Arbitrary (10 rpm/sec) | | | | | | | | | | | | | | | |
| (7) | Set the real-time speed command. Rotation starts. | | | | | | | | | | | | | | | | | |
| | 37 | Real-time command speed | Arbitrary (rpm) | | | | | | | | | | | | | | | |
| (8) | To stop, set the rotation speed to 0 rpm. | | | | | | | | | | | | | | | | | |
| | 37 | Real-time command speed | 0 | | | | | | | | | | | | | | | |

(*1) Turning the servo ON automatically sets the initial value of ID37 "Real-time command speed" to "0."

Supplement

To achieve smooth acceleration/deceleration with real-time speed commands, Bit 7 "Acceleration limit ON" of ID30 "Servo Command" should be set to ON. This enables the settings of ID34 "Acceleration" and ID35 "Deceleration," allowing you to adjust acceleration and deceleration.

To run with an analog command from the I/O connector

1. Setting the analog input speed conversion scale value and the offset

| Step | Operation | | | | | | | | | | | | | | | | | |
|------|--|--|--------------------|-----|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|
| | ID | Parameter name | Setting/read value | | | | | | | | | | | | | | | |
| (1) | Set the scale value of the speed equivalent of the analog input (factory setting: 6000 rpm). Set the speed (rpm) at 10 V (full scale) relative to 0 V. Example: If "6000" is set, the speed at 5 V is 3000 rpm and that at 10 V is 6000 rpm. | | | | | | | | | | | | | | | | | |
| | 130 | Analog input signal speed conversion scale value | Arbitrary (rpm) | | | | | | | | | | | | | | | |
| (2) | Input the analog input signal to specify zero speed (reference) to the I/O connector (PIN No. 24, 25). Example: If ID130 is set to "6000" with reference to 0 V, the speed at 10 V is 6000 rpm and that at -10 V is -6000 rpm. Example: If ID130 is set to "6000" with reference to 5 V, the speed at 10 V is 3000 rpm and that at 0 V is -3000 rpm. | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0100 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 |
| (4) | The analog signal input is measured automatically and the value is set in ID132 "Analog Input Offset." Example: A value of approximately 1195 is set relative to 5V as a reference. | | | | | | | | | | | | | | | | | |
| (5) | Save the set speed conversion scale value and offset. | | | | | | | | | | | | | | | | | |
| | 17 | Parameters save | 1 | | | | | | | | | | | | | | | |

2. Running by inputting an analog signal

| Step | Operation | | | | | | | | | | | | | | | |
|------|--|----------------------|---|--|--|--|--|--|--|--|--|--|--|--|--|--|
| | ID | Parameter name | Setting/read value | | | | | | | | | | | | | |
| (1) | Set speed command select to speed command by analog signal input. | | | | | | | | | | | | | | | |
| | 75 | Select Speed Command | 0x01 (The analog signal polarity is reversed when Bit 7 is 1.) | | | | | | | | | | | | | |
| (2) | Set the control mode to speed control. | | | | | | | | | | | | | | | |
| | 31 | Control Mode | 2 | | | | | | | | | | | | | |
| (3) | Parameter storing. Store the set values. After the power is turned on again, the motor can be operated by performing operations (4) to (6). | | | | | | | | | | | | | | | |
| | 17 | Parameters save | 1 | | | | | | | | | | | | | |
| (4) | Input an analog signal voltage to specify zero speed (reference) from the I/O connector (PIN No. 24, 25). | | | | | | | | | | | | | | | |
| (5) | Turn on the servo ON input signal (input 1: factory setting). Servo ON fixes the motor shaft. | | | | | | | | | | | | | | | |
| (6) | Rotation is started by changing the analog signal voltage. | | | | | | | | | | | | | | | |

Supplement

Control speed, acceleration, and deceleration from the high-level system.

15.2.1. Analog Input Zero Clamp Function

| ID | Parameter name | Factory setting | Setting range |
|-----|-------------------------|-----------------|--------------------|
| 133 | Analog Input Zero Clamp | 0 | 0 to 1000 [0.01 V] |

Set the analog input dead band. If the dead band is set, analog input commands within the range specified by this set value are treated as 0 for analog inputs.

If the analog input signal varies due to noise or other reasons, the motor may be unable to stop properly. This function must be set in such a case.

Example: When the analog input offset is set to 0 V and the analog input zero clamp value is set to "50" (0.5 V), analog input values in the range of ± 0.5 V are treated as zero input commands.

15.2.2. Analog Input Filtering Function

| ID | Parameter name | Setting value |
|-----|---------------------|--|
| 134 | Analog Input Filter | 0: No averaging 1: Averaging of 2 analog input commands 2: Averaging of 4 analog input commands 3: Averaging of 8 analog input commands 4: Averaging of 16 analog input commands |

Take the moving average of the analog input commands. This setting is effective when analog input commands vary due to noise or other reasons and cause the motor to malfunction.

Supplement

Analog inputs are read on a 50 μ s cycle.

15.2.3. Analog Input Forced-0 Command Function

I/O setting parameter

| ID | Function | Setting value |
|------------|--|---------------|
| 100 to 107 | Setting of I/O input 1 to 8 (IN1 to 8) | 0x0E (14) |

The analog input forced-0 command input can be used to set the analog input command to 0.

15.2.4. Speed Command Acceleration and Deceleration Setting Function

| ID | Parameter name | Factory setting | Setting range |
|----|----------------|-----------------|-------------------------|
| 34 | Acceleration | 1000 | 0 to 65535 [10 rpm/sec] |
| 35 | Deceleration | 1000 | 0 to 65535 [10 rpm/sec] |

Acceleration and deceleration can be set in speed control.

15.3. Current Control Mode

Current control operation has two control types.

The AC servo motor generates a torque proportional to the motor current. Therefore, controlling the current in this mode enables control of the motor torque.

1. Real-time current command (SV-NET)

This control type operates the motor with current commands sent from the SV-NET controller. When the command current value sent from the SV-NET controller is received, the motor starts to rotate and the current is maintained. It also can perform current control by continuously varying the command current value.

2. Analog current command

Operation is achieved by using the analog signal input through the I/O connector as the current command.

To run with a real-time current command

| Step | Operation | | | | | | | | | | | | | | | | | | |
|------|--|---------------------------|--------------------|-----|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | ID | Parameter name | Setting/read value | | | | | | | | | | | | | | | | |
| (1) | Set Torque Command Select to torque command via communication. | | | | | | | | | | | | | | | | | | |
| | 76 | Torque Command Select | 0x00 | | | | | | | | | | | | | | | | |
| (2) | Set the control mode to current control. | | | | | | | | | | | | | | | | | | |
| | 31 | Control Mode | 3 | | | | | | | | | | | | | | | | |
| (3) | Servo ON. In current control mode, the motor shaft is not fixed.(*1) | | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0001 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| | | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 |
| (4) | Set the real-time current command. Rotation starts. | | | | | | | | | | | | | | | | | | |
| | 38 | Real-time command current | Arbitrary (0.01 A) | | | | | | | | | | | | | | | | |

(*1) Turning the servo ON automatically sets the initial value of ID38 "Real-time command current" to "0."

To run with an analog command from the I/O connector

1. Setting the analog input current conversion scale value and the offset

| Step | Operation | | | | | | | | | | | | | | | | | |
|------|--|--|--------------------|-----|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|
| | ID | Parameter name | Setting/read value | | | | | | | | | | | | | | | |
| (1) | Set the scale value of the current equivalent of the analog input. Factory setting: 500 (0.01 A) Set the current (A) at 10 V (full scale) relative to 0 V. Example: 9 A at 5 V and 18 A at 10 V when "1800" is assigned. | | | | | | | | | | | | | | | | | |
| | 131 | Analog input signal current conversion scale value | Arbitrary (0.01 A) | | | | | | | | | | | | | | | |
| (2) | Input the analog signal voltage for specifying zero current (reference) to the I/O connector (PIN No. 24, 25). Example: If ID131 is set to "1800" relative to 0 V as a reference, the current is 18 A at 10 V and -18 A at -10 V. Example: If ID131 is set to "1800" relative to 5 V as a reference, the current is 9 A at 10 V and -9 A at 0 V. | | | | | | | | | | | | | | | | | |
| (3) | Start measuring the analog input offset value. Set ID30 "Analog Input 0-point Adjustment Command" (Bit 8) to ON. | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0100 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 |
| (4) | The analog signal input is measured automatically and the value is set in ID132 "Analog Input Offset." Example: A value of approximately 1195 is set relative to 5V as a reference. | | | | | | | | | | | | | | | | | |
| (5) | Save the set current conversion scale value and the offset. | | | | | | | | | | | | | | | | | |
| | 17 | Parameters save | 1 | | | | | | | | | | | | | | | |

2. Running by inputting an analog signal

| Step | Operation | | | | | | | | | | | | | | | |
|------|--|-----------------------|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
| | ID | Parameter name | Setting/read value | | | | | | | | | | | | | |
| (1) | Set torque command select to torque command by analog signal input. | | | | | | | | | | | | | | | |
| | 76 | Torque Command Select | 1 (The analog signal polarity is reversed when Bit 7 is 1.) | | | | | | | | | | | | | |
| (2) | Set the control mode to current control. | | | | | | | | | | | | | | | |
| | 31 | Control Mode | 3 | | | | | | | | | | | | | |
| (3) | Parameter saving. Save the set values. | | | | | | | | | | | | | | | |
| | 17 | Parameters save | 1 | | | | | | | | | | | | | |
| (4) | Input the analog signal voltage corresponding to zero current (reference) from the I/O connector (PIN No. 24, 25). | | | | | | | | | | | | | | | |
| (5) | Turn on the servo ON input signal (input 1: factory setting). The motor is excited. | | | | | | | | | | | | | | | |
| (6) | Rotation is started by changing the analog signal voltage. | | | | | | | | | | | | | | | |

Supplement Control current from the high-level system.

15.3.1. Analog Input Zero Clamp Function

| ID | Parameter name | Factory setting | Setting range |
|-----|-------------------------|-----------------|---------------------|
| 133 | Analog Input Zero Clamp | 0 | 0 to 1,000 [0.01 V] |

Set the analog input dead band. If the dead band is set, analog input commands within the range specified by this set value are treated as 0 for analog inputs.

If the analog input signal varies due to noise or other reasons, the motor may be unable to stop properly. This function must be set in such a case.

Example: When the analog input offset is set to 5.0 V and the analog input zero clamp value is set to "50" (0.5 V), analog input values in the range of 5.0 ± 0.5 V (4.5 to 5.5 V) are treated as zero input commands.

15.3.2. Analog Input Filtering Function

| ID | Parameter name | Setting value |
|-----|---------------------|--|
| 134 | Analog Input Filter | 0: No averaging 1: Averaging of 2 analog input commands 2: Averaging of 4 analog input commands 3: Averaging of 8 analog input commands 4: Averaging of 16 analog input commands |

Take the moving average of the analog input commands. This setting is effective when analog input commands vary due to noise or other reasons and cause the motor to malfunction.

Supplement Analog inputs are read on a 50 μ s cycle.

15.3.3. Analog Input Forced-0 Command Function

I/O setting parameter

| ID | Function | Setting value |
|------------|---|---------------|
| 100 to 107 | Setting of I/O inputs 1 to 8 (IN1 to 8) | 0x0E (14) |

The analog input forced-0 command input can be used to set the analog input command to 0.

15.3.4. Speed Limit Function

The speed limit can be used for protection in the current control mode.

In speed control mode, the analog signal input is used as the current limit for pseudo current control with speed limit.

When the analog signal polarity is negative, the speed command polarity is reversed automatically.

Supplement


When the motor speed reaches the limit value, the motor current is not controlled according to analog input commands but controlled as a result of motor speed.

| Step | Operation | | |
|------|--|-------------------------|--|
| | ID | Parameter name | Setting/Read value |
| (1) | Set the analog current command. | | |
| | ⇒ Refer to □15.3 "Current Control Mode." | | |
| (2) | Set torque command select to "Use analog signal input as torque command with speed limit." | | |
| | 76 | Torque Command Select | 3 (The analog signal polarity is reversed when Bit 7 is "1.") |
| (3) | Set the control mode to speed control. | | |
| | 31 | Control Mode | 2 |
| (4) | Set the speed limit value. | | |
| | 37 | Real-time Command Speed | Arbitrary (rpm) |
| (5) | Set Bit 2 of ID69 "Control Switch" to "1" if you do not want to clear ID37 "Real-time Command Speed" to 0 when the servo is turned ON. | | |
| (6) | Input the analog signal voltage as the 0 current (reference) to the I/O connector (PIN No. 24, 25). | | |
| (7) | Turn on the Servo ON input signal (Input 1: Factory setting) to excite the motor. | | |
| (8) | Start rotation by changing the analog signal voltage. Use the host system to control the current command value. | | |
| (9) | The current is limited by the current limit values (IDs 86, 87, 65, and 66) when they are smaller than the current command value set by this function. | | |

15.4. Homing Mode


In the homing mode, the origin return is executed and then the current position is reset to the value set in parameter ID 91 "Homing Preset Value."

The origin can be found in two different ways: using an origin signal or using a mechanical stopper.



Important

Homing operation cannot be conducted from the position in excess of the origin signal detection range. Homing operation should always be conducted in the state where the object is moved before the origin signal detection range.



Important

If the setting of the homing start direction is wrong, the homing operation cannot be correctly completed. Set the homing start direction correctly.

Homing with an origin signal

(1) Position preset by moving to the Z signal detection position after detecting an origin signal **For sensors other than wire-saving INC sensors (17/23Bit-INC, 17/23Bit-ABS, and 1X-BRX)**

When an origin signal is detected, the motor decelerates to a stop and moves to the sensor Z signal detection position, and the current position is reset to the preset value.

In the case where homing is conducted from the position before the origin signal detection position, the motor always stops at the Z signal detection position before the origin signal detection range. But in the case of homing from the origin signal detection range when the Z signal detection position is within the origin signal detection range, the motor stops at the Z signal detection position in the origin signal detection range.


For wire-saving INC sensors

After power-on, if the sensor Z signal is not detected until the start of homing, the Z signal detection operation will first be performed when the homing operation is started.

The Z signal detection operation is an operation for detecting the Z signal position at the speed set in ID 94 "Homing creep speed" (when the set value is 50 [rpm] or larger, the speed is fixed to 50 [rpm]). When the Z signal is detected at least one time after power-on, the homing operation is performed as is the case of other sensors.

Supplement


Motors equipped with wire-saving incremental encoders can perform high-accuracy current control by detecting the sensor Z signal (Z-phase output position of the wire-saving incremental encoders) after power-on.



Caution

After detection of the origin signal, when the position preset is performed by moving the motor to the Z signal detection position, the Z signal detection position must be within the operation range. If the Z signal is not detected within the operation range, the homing operation cannot normally be completed. For example, if the actual operation range is narrower than the range corresponding to one turn of the motor shaft, the motor needs to be attached to the equipment appropriately so that the Z signal can be detected within the operation range.

■ For sensors other than wire-saving INC sensors (17/23 Bit-INC, 17/23 Bit-ABS, 1X-BRX)



Ⓢ : Homing start point

The above diagram illustrates an example of operation that is produced when ID 72 "Reference Direction" is set to "0" (CCW), and ID 92 "Homing Start Direction" is set to "0" (forward direction).


Supplement

Motors equipped with 17/23 Bit-INC or 17/23 Bit-ABS sensors perform absolute accuracy compensation (full absolute status confirmation) when their motor shaft rotates by 12 degrees (approximately 4,369 pulses for 17 Bit sensors; approximately 279,620 pulses for 23 Bit sensors) at most after power-on.

Supplement

*1 Only when the homing operation from the origin signal detection range is performed with a 17/23 Bit-INC or 17/23 Bit-ABS sensor, the homing operation for absolute accuracy compensation (full absolute status confirmation) will first be performed after the motor shaft rotates by 12 degrees (approximately 4,369 pulses for 17 Bit sensors; approximately 279,620 pulses for 23 Bit sensors) at most.

■ For wire-saving INC sensors



Ⓢ : Homing start point


— (solid line); Homing operation

··· (dotted line); Z signal detection operation

The above diagram illustrates an example of operation that is produced when ID 72 "Reference Direction" is set to "0" (CCW), and ID 92 "Homing Start Direction" is set to "0" (forward direction).

Supplement

- The above diagram illustrates operation that is produced when the Z signal has never been detected before the start of the homing operation. When the Z signal has been detected, the homing operation is performed in the same manner as for other sensors.
- The Z signal detection operation is performed at the moving speed set in ID 94 "Homing Creep Speed." If the homing creep speed is set to 50 [rpm] or larger, the upper limit of the operation speed will become 50 [rpm]. Once the Z signal is detected, the homing creep speed in the operation will become the set value of ID 94.



Ⓢ : Homing start point

— (solid line); Homing operation

··· (dotted line); Z signal detection operation

The above diagram illustrates an example of operation that is produced when ID 72 "Reference Direction" is set to "0" (CCW), and ID 92 "Homing Start Direction" is set to "0" (forward direction).


Supplement

- The above diagram illustrates operation that is produced when the Z signal has never been detected before the start of the homing operation. When the Z signal has been detected, the homing operation is performed in the same manner as for other sensors.
- The Z signal detection operation is performed at the moving speed set in ID 94 "Homing Creep Speed." If the homing creep speed is set to 50 [rpm] or larger, the upper limit of the operation speed will become 50 [rpm]. Once the Z signal is detected, the homing creep speed in the operation will become the set value of ID 94.

(2) Position preset by immediate stop with origin signal

When an origin signal is detected, the motor is immediately stopped, and the current position is reset to the preset value at that position.

In the case where homing operation is conducted from the origin signal detection range, the present position is the origin position.



Ⓢ : Homing start point

The above diagram illustrates an example of operation that is produced when ID 72 "Reference Direction" is set to "0" (CCW), and ID 92 "Homing Start Direction" is set to "0" (forward direction).

Supplement

Motors equipped with wire-saving incremental encoders can perform high-accuracy current control by detecting the sensor Z signal (Z-phase output position of the wire-saving incremental encoders) after power-on.




Caution

When it is necessary to perform position preset with a wire-saving INC sensor by immediate stopping using the origin signal, the motor needs to be installed in the equipment appropriately so that the Z signal detection position will be within the operation range. If the Z signal cannot be detected because the Z signal detection position is not within the operation range, oscillation or unusual noise may occur due to the decreased accuracy of the electrical degree.


(3) Position preset after detecting an origin signal and returning until the triggering origin signal is cancelled

When an origin signal is detected, the motor returns to the origin signal cancellation position and immediately stops, and then the position is reset.



Ⓢ : Homing start point

The above diagram illustrates an example of operation that is produced when ID 72 "Reference Direction" is set to "0" (CCW), and ID 92 "Homing Start Direction" is set to "0" (forward direction).



Caution

In the process of position preset performed after detecting the origin signal and returning until the origin signal is canceled, if a stop is made outside the origin signal detection range, the motor cannot normally return to the origin signal cancellation position. Therefore, set the speed and deceleration of the motor appropriately.

Supplement Motors equipped with 17/23 Bit-INC or 17/23 Bit-ABS sensors perform absolute accuracy compensation (full absolute status confirmation) when their motor shaft rotates by 12 degrees (approximately 4,369 pulses for 17 Bit sensors; approximately 279,620 pulses for 23 Bit sensors) at most after power-on.

Supplement *1 Only when the homing operation from the origin signal detection range is performed with a 17/23 Bit-INC or 17/23 Bit-ABS sensor, the homing operation for absolute accuracy compensation (full absolute status confirmation) will first be performed after the motor shaft rotates by 12 degrees (approximately 4,369 pulses for 17 Bit sensors; approximately 279,620 pulses for 23 Bit sensors) at most.

Supplement Motors equipped with wire-saving incremental encoders can perform high-accuracy current control by detecting the sensor Z signal (Z-phase output position of the wire-saving incremental encoders) after power-on.


Caution

When it is necessary to perform position preset with a wire-saving INC sensor by returning until the origin signal is cancelled, the motor needs to be installed in the equipment appropriately so that the Z signal detection position will be within the operation range. If the Z signal cannot be detected because the Z signal detection position is not within the operation range, oscillation or unusual noise may occur due to the decreased accuracy of the electrical degree.

• **Origin detection methods**

There are two different ways to detect an origin signal: origin detection by I/O and origin detection by the SV-NET controller (communication commands).

Origin signal detection by I/O:

An origin signal is detected by assigning the origin signal input to either of ID 100 to 107 of I/O setting parameters.

⇒ Refer to □19.10 "Parameters for Setting I/O."

Origin signal detection by the SV-NET controller (communication commands):

An origin signal is detected when the SV-NET controller sets Bit 13 "Origin detection notification" of parameter ID30 "Servo Command." ⇒ Refer to □19.4 "Control Command Parameters."

Homing by mechanical stopper

When thrust against the mechanical stopper is detected, the current position is reset to the preset value

Thrust time and thrust torque can be set.



Important

When performing the homing operation with the mechanical stopper, do not use the forward-rotation (reverse-rotation) disable input or the origin sensor input (Example) Do not install wiring for the I/O input specified at the factory default settings (IN2 "Forward-rotation disable input," IN3 "Reverse-rotation disable input," or IN7 "Origin sensor input").

(1) Position preset by thrust detection and stop

When thrust is detected, the motor stops, and the current position is reset to the preset value at that position.

Supplement

Motors equipped with wire-saving incremental encoders can perform high-accuracy current control by detecting the sensor Z signal (Z-phase output position of the wire-saving incremental encoders) after power-on.



Caution

When it is necessary to perform position preset with a wire-saving INC sensor after stopping by thrust detection, the motor needs to be installed in the equipment appropriately so that the Z signal detection position will be within the operation range. If the Z signal cannot be detected because the Z signal detection position is not within the operation range, oscillation or unusual noise may occur due to the decreased accuracy of the electrical degree.

(2) Position preset by moving to the Z signal detection position after detecting thrust

When thrust is detected, the motor stops and moves to the sensor Z signal detection position, and the current position is reset.

Supplement





Motors equipped with wire-saving incremental encoders can perform high-accuracy current control by detecting the sensor Z signal (Z-phase output position of the wire-saving incremental encoders) after power-on.



Caution

When it is necessary to perform position preset with a wire-saving INC sensor after stopping by thrust detection and moving to the Z signal detection position, the motor shaft must make one turn or more in detection of the Z signal in the homing operation. If the thrust detection position corresponds to less than one turn of the motor shaft, the motor cannot normally move to the Z signal detection position.

15.4.1. Rotation Start Direction in Homing Mode

| ID72 | ID92 | Rotation start direction of motor shaft |
|------|------|--|
| 0 | 0 |  CCW |
| 0 | 1 |  CW |
| 1 | 0 |  CW |
| 1 | 1 |  CCW |

| ID | Parameter name | Description | Reference |
|----|---------------------|--|-----------|
| 72 | Reference Direction | Sets the forward rotation direction 0: CCW, 1: CW | ⇒ □19.7 |

| ID | Parameter name | Description | Reference |
|----|------------------------|--|-----------|
| 92 | Homing Start Direction | Homing rotation direction 0: Forward direction; 1: Reverse direction | ⇒ □19.8 |

15.4.2. Homing with an origin signal (origin detection by I/O)

| Step | Operation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--------|--|------------------------|---|--------|-----|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|--|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | ID | Parameter name | Setting/read value | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (1) | Select a homing operation from the following. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 90 | Homing Mode | 0: Position preset by moving to Z signal detection position after detecting origin signal 2: Position preset by immediate stop after detecting origin signal 3: Position preset after detecting origin signal and returning until triggering origin signal is canceled | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (2) | Set the position set after homing operation. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 91 | Homing Preset Value | Arbitrary (pulse) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (3) | Set the homing start direction. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 92 | Homing Start Direction | 0: Forward direction 1: Reverse direction | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (4) | Set the homing speed. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 93 | Homing Speed | Arbitrary (rpm), Factory setting: 500 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (5) | Set the homing creep speed. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 94 | Homing Creep Speed | Arbitrary (rpm), Factory setting: 50 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (6) | Set the acceleration | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 34 | Acceleration | Arbitrary (10rpm), Factory setting: 1000 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (7) | Set the deceleration | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 35 | Deceleration | Arbitrary (10rpm), Factory setting: 1000 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (8) | Use the I/O setting parameter to assign an origin signal to any of inputs 1 to 8. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 100 to 107 | Setting IN1 to IN8 | 0x07 Negative logic (usually ON) is set when Bit 7 is 1. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (9) | Set to homing control. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 31 | Control Mode | 4 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (10) | Set to servo ON (ID 30; Bit 0: ON). Homing control mode starts. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | <table border="1"> <tr> <td>0x0001</td> <td>B15</td><td>B14</td><td>B13</td><td>B12</td><td>B11</td><td>B10</td><td>B9</td><td>B8</td><td>B7</td><td>B6</td><td>B5</td><td>B4</td><td>B3</td><td>B2</td><td>B1</td><td>B0</td> </tr> <tr> <td></td> <td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>1</td> </tr> </table> | 0x0001 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 |
| 0x0001 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 | | | | | | | | | | | | | | | | | | | | | |
| | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | | | | | | | | | | | | | | | | | | | | | |
| | The motor starts moving according to the settings of ID92 "Homing Start Direction," ID93 "Homing Speed" and ID34 "Acceleration." | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (11) | The origin position is detected according to the origin signal set in (8). | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <p>[When the "position preset by moving to Z signal detection position after detecting origin signal" is selected]</p> <p>The motor decelerates to a stop at the deceleration set in ID35 "Deceleration" and moves to the sensor Z signal detection position at the speed set in ID94 "Homing Creep Speed." The current position is then reset to the value set in ID91 "Homing Preset Value."</p> <p>[When the "position preset by immediate stop after detecting origin position" is selected]</p> <p>When receiving the speed 0 command, the motor stops and the current position is reset to the value set in ID91 "Homing Preset Value."</p> <p>[When the "position preset after detecting origin signal and returning until the triggering origin signal is canceled" is selected]</p> <p>The motor decelerates to a stop at the deceleration set in ID35 "Deceleration" and returns at the speed set in ID94 "Homing Creep Speed" until the origin signal is canceled. The current position is then reset to the value set in ID91 "Homing Preset Value."</p> <p>After homing finishes, ID31 "Control Mode" is set to "1" (position control). To store the setting after the homing operation, refer to □ 16.1 "Saving Parameters."</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

15.4.3. Homing with an origin signal (origin detection by communication commands)

| Step | Operation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|------|---|------------------------|---|-----|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | ID | Parameter name | Setting/read value | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (1) | Select a homing operation from the following. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 90 | Homing Mode | 0: Position preset by moving to Z signal detection position after detecting origin signal 2: Position preset by immediate stop after detecting origin signal 3: Position preset after detecting origin signal and returning until the triggering origin signal is canceled | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (2) | Set the position set after homing operation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 91 | Homing Preset Value | Arbitrary (pulse) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (3) | Set the homing direction. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 92 | Homing Start Direction | 0: Forward direction 1: Reverse direction | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (4) | Set the homing speed. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 93 | Homing Speed | Arbitrary (rpm), Factory setting: 500 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (5) | Set the homing creep speed. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 94 | Homing Creep Speed | Arbitrary (rpm), Factory setting: 50 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (6) | Set the acceleration | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 34 | Acceleration | Arbitrary (10rpm), Factory setting: 1000 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (7) | Set the deceleration | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 35 | Deceleration | Arbitrary (10rpm), Factory setting: 1000 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (8) | Set to homing control. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 31 | Control Mode | 4 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (9) | Set to servo ON (ID 30; Bit 0: ON). Homing mode starts. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0001 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | <table border="1"> <thead> <tr> <th>B15</th><th>B14</th><th>B13</th><th>B12</th><th>B11</th><th>B10</th><th>B9</th><th>B8</th><th>B7</th><th>B6</th><th>B5</th><th>B4</th><th>B3</th><th>B2</th><th>B1</th><th>B0</th> </tr> </thead> <tbody> <tr> <td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>1</td> </tr> </tbody> </table> | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 |
| B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | | | | | | | | | | | | | | | | | | | | |
| | The motor starts moving according to the settings of ID92 "Homing Start Direction," ID93 "Homing Speed" and ID34 "Acceleration." | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| (10) | Set "Origin Signal" (ID 30; Bit 13: ON) to detect the origin position. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x2001 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | <table border="1"> <thead> <tr> <th>B15</th><th>B14</th><th>B13</th><th>B12</th><th>B11</th><th>B10</th><th>B9</th><th>B8</th><th>B7</th><th>B6</th><th>B5</th><th>B4</th><th>B3</th><th>B2</th><th>B1</th><th>B0</th> </tr> </thead> <tbody> <tr> <td>0</td><td>0</td><td>1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>1</td> </tr> </tbody> </table> | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 |
| B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | | | | | | | | | | | | | | | | | | | | |
| | <p>[When the "position preset by moving to Z signal detection position after detecting origin signal" is selected] The motor decelerates to a stop at the deceleration set in ID35 "Deceleration" and moves to the sensor Z signal detection position at the speed set in ID94 "Homing Creep Speed," and the current position is reset to the value set in ID91 "Homing Preset Value."</p> <p>[When the "position preset by immediate stop after detecting origin signal" is selected] When receiving the speed 0 command, the motor stops and the current position is reset to the value set in ID91 "Homing Preset Value."</p> <p>[When the "position preset after detecting origin signal and returning until the triggering origin signal is canceled" is selected] The motor decelerates to a stop at the deceleration set in ID35 "Deceleration" and returns at the speed set in ID94 "Homing Creep Speed" until the origin signal (Bit 13 of ID30) is canceled. The current position is then reset to the value set in ID91 "Homing Preset Value."</p> <p>After homing finishes, ID31 "Control Mode" is set to "1" (position control). To store the setting after the homing operation, refer to □16.1 "Saving Parameters."</p> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

15.4.4. Homing by mechanical stopper

| Step | Operation | | | | | | | | | | | | | | | | | |
|--|---|------------------------|--|-----|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|
| | ID | Parameter name | Setting/read value | | | | | | | | | | | | | | | |
| (1) | Select a homing operation from the following. | | | | | | | | | | | | | | | | | |
| | 90 | Homing Mode | 1: Position preset at that position by thrust detection and stop 4: Position preset by moving to the Z signal detection position after detecting thrust | | | | | | | | | | | | | | | |
| (2) | Set the position set after homing operation. | | | | | | | | | | | | | | | | | |
| | 91 | Homing Preset Value | Arbitrary (pulse) | | | | | | | | | | | | | | | |
| (3) | Set the homing start direction. | | | | | | | | | | | | | | | | | |
| | 92 | Homing Start Direction | 0: Forward direction 1: Reverse direction | | | | | | | | | | | | | | | |
| (4) | Set the homing start speed. | | | | | | | | | | | | | | | | | |
| | 93 | Homing Speed | Arbitrary (rpm), Factory setting: 500 | | | | | | | | | | | | | | | |
| (5) | Set the thrust time. | | | | | | | | | | | | | | | | | |
| | 95 | Homing Thrust Time | Arbitrary (msec), Factory setting: 1000 | | | | | | | | | | | | | | | |
| (6) | Set the thrust torque. | | | | | | | | | | | | | | | | | |
| | 96 | Homing Thrust Torque | Arbitrary (0.01A), Factory setting: 100 | | | | | | | | | | | | | | | |
| (7) | Set the acceleration | | | | | | | | | | | | | | | | | |
| | 34 | Acceleration | Arbitrary (10rpm), Factory setting: 1000 | | | | | | | | | | | | | | | |
| (8) | Set the deceleration | | | | | | | | | | | | | | | | | |
| | 35 | Deceleration | Arbitrary (10rpm), Factory setting: 1000 | | | | | | | | | | | | | | | |
| (9) | Set to homing control. | | | | | | | | | | | | | | | | | |
| | 31 | Control Mode | 4 | | | | | | | | | | | | | | | |
| (10) | Set to servo ON (ID 30; Bit 0: ON). Homing mode starts. | | | | | | | | | | | | | | | | | |
| | 30 | Servo Command | 0x0001 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 |
| (11) | The motor starts moving according to the settings of ID92 "Homing Start Direction," ID93 "Homing Speed" and ID34 "Acceleration." | | | | | | | | | | | | | | | | | |
| | The motor stops after detection of thrust according to the settings of ID95 "Homing Thrust Time" and ID96 "Homing Thrust Torque." | | | | | | | | | | | | | | | | | |
| <p>[When the "position preset at that position by thrust detection and stop" is selected] The position where the motor stopped is reset to the value set in ID91 "Homing Preset Value."</p> <p>[When the "position preset by moving to the Z signal detection position after detecting thrust" is selected] The motor further moves to the sensor Z signal detection position, and the current position is reset to the value set in ID91 "Homing Preset Value."</p> <p>After homing finishes, ID31 "Control Mode" is set to "0" (servo OFF). To store the setting after the homing operation, refer to □16.1 "Saving Parameters."</p> | | | | | | | | | | | | | | | | | | |

15.5. The Driver Operation Status

The driver status can be checked by reading the following parameter values.

Parameters by which the driver status can be checked

| ID | Parameter name | Description | |
|---|--|---|---|
| 20 | Servo Status | Bit0: During Servo ON | ON while servo ON |
| | | Bit1: During profile operation | ON during profile operation ⇒ Refer to □14.1 "Position Control Mode." |
| | | Bit2: In-position | ON when the position deviation pulse falls within the range set in ID77 "In-position Signal Range." |
| | | Bit3:Alarming | ON if stopped by detection of an alarm |
| | | Bit4:Arrive at forward limit | ON when ID83 "Soft Limit Select" is set to "Enable" and the current position exceeds the value set in ID84 "Forward-direction soft limit" |
| | | Bit5:Arrive at reverse limit | ON when ID83 "Soft Limit Select" is set to "Enable" and the current position exceeds the value set in ID85 "Reverse-direction soft limit" |
| | | Bit6: Torque limit | ON when the current reaches the value set in ID86 "Forward-rotation Current Limit" or ID87 "Reverse-rotation Current Limit" |
| | | Bit7: Speed limit | ON when the speed exceeds the value set in ID88 "Speed Limit" |
| | | Bit8: Position excessive deviation | ON when the position deviation pulse exceeds the value set in ID202 "Deviation Error Detection Pulse" OFF when the position excessive deviation alarm (42) occurs and the motor stops. |
| | | Bit9: Servo ready | ON when the servo is ready to be driven |
| | | Bit10: During homing | ON during homing operation |
| | | Bit11: During switching to second gain | ON when Gain 2 is used |
| | | Bit12: Backup battery voltage low | ON when the battery voltage low alarm is received from the 17, 23bit-ABS encoder |
| | | Bit13: Drive power supply disconnection | ON when the drive voltage is equal to or below the value set in ID206 "Power Supply Shutoff Detection Voltage" |
| | | Bit14: Stop speed status | ON when the motor speed is equal to or below the value set in ID182 "Stop Speed Judgment Speed" |
| Bit16: Mechanical brake output signal | ON when the brake control signal is released | | |
| Bit20 to 22: Alarm bit code | Alarms detected can be identified by these bits. ⇒ Refer to □17 "Alarm Detection." | | |
| Bit24: Arrival at profile command target position | Turns ON for 10 msec when the target position is reached during profile operation | | |
| It is recommended to always monitor these parameters even during operation. | | | |
| 21 | I/O Status | Bit0 - Bit7 Bit8 - Bit12 | IN1 - IN8 OUT1 - OUT5 |
| | Can check the I/O status. | | |
| 22 | Alarm Code | Obtains the alarm code when an alarm is detected. | |
| | Check the code when an alarm is detected. ⇒ Refer to □17 "Alarm Detection" | | |
| 40 | Feedback Position | Current position (pulse) | |
| | Can be read at any time to check the current position. | | |
| 41 | Feedback Speed | Current speed (rpm) | |
| | Can be read at any time to check the current position. | | |
| 42 | Feedback Current | Present current (0.01 A) | |
| | Can be read at any time to check the current position. | | |

Special servo feedback parameters

| ID | Parameter name | Description | | | | | |
|----|----------------|---|---------------|--------------------------------|------------------------------------|--------------|-------------|
| | | Bits 47 to 40 | Bits 39 to 32 | Bits 31 to 24 | Bits 23 to 16 | Bits 15 to 8 | Bits 7 to 0 |
| 43 | Feedback PVC | ID40 "Feedback Position" Lower-order 2 bytes (pulse) | | ID41 "Feedback Speed" (rpm) | ID42 "Feedback Current" (0.01A) | | |
| 44 | Feedback SVC | ID45 "Sensor Position1" Lower-order 2 bytes (pulse) | | ID41 "Feedback Speed" (rpm) | ID42 "Feedback Current" (0.01A) | | |

15.6. Control Mode Switch Function

The control mode switch function allows you to use two control modes while switching between them during servo operation.

To use the control mode switch function, set the following values to ID99 "second control mode."

- Bits 3 to 0: selection of second control mode
 - 0: Disable control mode switching
 - 1: Position control
 - 2: Speed control
 - 3: Current control

- Bit 12 to 15: Selection of a command to be used when switching to second control mode
 - 0: Reset the command value (Command for speed and current controls = 0, Command for position control = current position)
 - 1: Continue the command value that was used before switching

If you do not want to reset the command value when the control mode is switched to the second control mode, set Bit 12 to 1.

In this case, you need to set the desired command value before the control mode is switched.

Also, if you do not want to reset the command value when the control mode is switched to the first control mode, set Bit 2 of ID69 "Control Switch" to 1.

In speed and current controls, the command values in both the first and second control modes can be either real-time command values set by the parameter or analog input command values.

In position control, all of the real-time position command, profile position command, and pulse command can be used as commands, but the command before the start of first control can be continued at the time of switching of control mode only with profile position command. (In other controls, the first command is automatically initialized to the current position.)



Caution

Only position control, speed control, and current control can be set as the second control mode. When using the control mode switch function, also set any of position control, speed control, and current control as the first control mode. If any other control mode is set as the first control mode, an unexpected movement might occur at the moment the mode is switched.

The control mode can be switched by using Bit 9 of ID30 "Servo Command" or by setting control mode switch (16) to the setting parameters ID100 to ID107 and switching the mode through I/O.

⇒ Refer to □19.10 "Parameters for Setting I/O (Input)"

Example: Setting position control to the first control mode and speed control to the second control mode, and switching between modes by servo command

| Step | Operation | | | | | | | | | | | | | | | | | | |
|---|--|---------------------|--------------------|-----|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | ID | Parameter name | Setting/read value | | | | | | | | | | | | | | | | |
| (1) | Set the control mode to position control. (first control mode) | | | | | | | | | | | | | | | | | | |
| | 31 | Control mode | 1 | | | | | | | | | | | | | | | | |
| (2) | Set the second control mode to speed control and set no initialization of first command. | | | | | | | | | | | | | | | | | | |
| | 99 | Second control mode | 0x1002 | | | | | | | | | | | | | | | | |
| (3) | Servo ON. | | | | | | | | | | | | | | | | | | |
| | 30 | Servo command | 0x0001 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| | | | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 |
| (4) | Conduct position control by following the method described in 15.1 "Position Control Mode." | | | | | | | | | | | | | | | | | | |
| (5) | Set the first speed command in advance by following the method described in 15.2 "Speed Control Mode." | | | | | | | | | | | | | | | | | | |
| (6) | Switch to the second control mode. | | | | | | | | | | | | | | | | | | |
| | 30 | Servo command | 0x0201 | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| | | | 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 |
| (7) | Conduct speed control by following the method described in 15.2 "Speed Control Mode." | | | | | | | | | | | | | | | | | | |
| <ul style="list-style-type: none"> The control mode is switched to the first control mode when Bit 9 of ID30 is set to "0" and switched to the second control mode when it is set to "1." The control mode can also be switched by I/O input (Input 1 to Input 8). If "0x10 (16)" is set to I/O setting parameters ID 100 to 107, the corresponding I/O inputs serve as control mode switch inputs. | | | | | | | | | | | | | | | | | | | |

15.7. Simplified Control Mode

■ Overview

In the simplified control mode, the motor operation is executed according to a user-created program. In the simplified control function, you can create any program having up to 128 steps. In each step, it is possible to perform a move command, command change during move, condition branch through I/O, contact output, homing, alarm reset, current position reset, and parameter change. To find detailed information for the simplified control mode, refer to the separately issued "TAD881x Simplified Control Operation Manual" (MNL000661W00).

To operate the driver in simplified control mode, you need to set parameter ID31 Control Mode to "14" in advance.

■ Editing the program

The program can be easily edited by using the dedicated application. To find detailed information on how to edit the program, refer to the application software manual.

■ Downloading and uploading the program

The program can also be downloaded from and uploaded to the driver by using the dedicated application. Refer to the application software manual.

■ Program start signal

The program starts up when the driver I/O input "Servo ON input" is turned on.

The driver's CN1-I/O input 1 (IN1) is set to "Servo ON input" at the factory.

Input 2 to Input 8 can be changed to the program start signal by changing the settings of I/O setting parameters ID100 to 107.

The program can also be kept running without I/O input by setting Bit 7 to "1" (I/O input = Negative logic) at the parameter ID that is set to "Servo ON input."

■ I/O inputs

To use I/O input (Input 1 to Input 8) in the branch condition setting in the created program, change the settings of corresponding I/O setting parameter ID100 to 107 to "0x0F."

Note that you need to assign one input to "Servo ON command" and so you can use the remaining seven inputs for the branch condition.

Example: To use I/O input (IN3) for the program start signal and use Input 1, Input 2, Input 4 to Input 8 for the program branch conditions, set the parameter IDs as follows:

ID100 = 0x0F

ID101 = 0x0F

ID102 = 0x01

ID103 to ID107 = 0x0F

■ I/O outputs

To use I/O outputs (Output 1 to Output 5) in the created program, change the settings for the corresponding I/O setting parameter IDs 110 to 114 to "0xFFFFFFFF."

Example: To use I/O outputs (Output 3 to Output 5) in the program, change the settings of the parameter IDs as follows:

ID112 to 114 = 0xFFFFFFFF

■ Commands

For types and details of commands available for the simplified control function, refer to the separately issued "TAD881x Simplified Control Operation Manual" (MNL000661W00).

■ Start of motor excitation

The "Servo ON input" of the I/O input signal is used as the program start signal. The motor is actually excited immediately after the "SVON" command is executed while the program is running.

16. Supplementary Explanation about Functions

16.1. Saving Parameters

| ID | Parameter name | Setting value |
|----|-----------------|---------------|
| 17 | Parameters save | 1 |

Save parameters to a nonvolatile memory. Storable parameters are marked with O in the "M" column in □19 "List of Parameters." Usually you should save parameters with the servo OFF. After the parameter save has been completed, the value returns to "0."



Caution

If you turn the power supply OFF without doing this operation, the changes you made will be lost. Save parameters to enable the changes.

16.2. Initializing Parameters

| ID | Parameter name | Setting value |
|----|------------------|---------------|
| 16 | Parameters init. | 1 |

Initialize all parameters according to the driver's built-in default value table. Note that initializing parameters does not save them to a nonvolatile memory. Besides initialization, also save parameters as described in □16.1 "Saving Parameters."



Caution

This function does not always return all parameters to their factory settings. Do not use this function if either the driver or the motor is a special product designed to meet your specifications

16.3. Servo Command

■ Bit 0: Servo ON

| ID | Parameter name | Setting | | | | | | | | | | | | | | | |
|----|----------------|---------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| 30 | Servo Command | * | * | * | * | * | * | * | * | * | * | * | * | * | * | * | 1 |

Setting Bit 0 of ID30 "Servo Command" to "1" turns the servo ON. During position and speed control, the motor shaft is fixed. The servo ON signal can also be input from the I/O connector. ⇒ Refer to □ 7.7 "Wiring the I/O Connector."



Important

Do not turn the servo ON within 2 seconds after power has been turned on.

■ Bit 1: Profile Operation Enabled

| ID | Parameter name | Setting | | | | | | | | | | | | | | | |
|----|----------------|---------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| 30 | Servo Command | * | * | * | * | * | * | * | * | * | * | * | * | * | 1 | * | |

When Bit 1 of ID30 "Servo Command" is "1," the position control (profile operation) is performed with the set target position, target speed, acceleration, and deceleration. Use this parameter when operating by setting a target position for position control.

■ Bit 2: Deviation Reset

| ID | Parameter name | Setting | | | | | | | | | | | | | | | |
|----|----------------|---------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| 30 | Servo Command | * | * | * | * | * | * | * | * | * | * | * | * | 1 | * | * | |

Setting Bit 2 of ID30 "Servo Command" to "1" clears the deviation between the command position and the current position.

This function is enabled when the position control pulse input is used for operation. Setting "Deviation Reset" to ON during a pulse input stops rotation of the motor while maintaining the current position. After "1" (ON) is set, this Bit retains the value until "0" (OFF) is set.

■ Bit3: Alarm Reset

| ID | Parameter name | Setting | | | | | | | | | | | | | | | |
|----|----------------|---------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| 30 | Servo Command | * | * | * | * | * | * | * | * | * | * | * | 1 | * | * | * | |

Setting Bit 3 of ID30 "Servo Command" to "1" clears an alarm.
 Set Alarm Reset after eliminating the cause of the problem.
 ⇒ Refer to □17 "Alarm Detection."

■ Bit 4: Hard Stop

| ID | Parameter name | Setting | | | | | | | | | | | | | | | |
|----|----------------|---------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| 30 | Servo Command | * | * | * | * | * | * | * | * | * | * | 1 | * | * | * | 1 | |

Setting Bit 4 of ID30 "Servo Command" to "1" automatically stops the motor when the speed 0 command is given.

Supplement This function is also active during operation in any control mode other than speed control and during operation according to analog commands.
 When Hard Stop is ON, the motor does not rotate even when an operation command is given.

■ Bit 5: Smooth Stop

| ID | Parameter name | Setting | | | | | | | | | | | | | | | |
|----|----------------|---------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| 30 | Servo Command | * | * | * | * | * | * | * | * | * | 1 | * | * | * | * | 1 | |

Setting Bit 5 of ID30 "Servo Command" to "1" decelerates the motor at the deceleration set in ID35 "Deceleration" until it stops.

Supplement

This function is also active during operation in any other control mode than speed control and during operation according to analog commands. When Smooth Stop is ON, the motor does not rotate even when an operation command is given. Executing Smooth Stop immediately before completion of profile operation may cause an overshoot of the target position.

■ Bit 7: Enabling Acceleration/Deceleration during Speed Control

| ID | Parameter name | Setting | | | | | | | | | | | | | | | |
|----|----------------|---------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| 30 | Servo Command | * | * | * | * | * | * | * | 1 | * | * | * | * | * | * | * | |

| ID | Parameter name | Setting value | Factory setting | Setting range |
|----|----------------|---------------|-----------------|---|
| 34 | Acceleration | [10 rpm/sec] | 1000 | 0 to 65535 <input type="text" value="DEC"/> |
| 35 | Deceleration | [10 rpm/sec] | 1000 | 0 to 65535 <input type="text" value="DEC"/> |

When Bit 7 of ID30 "Servo Command" is "1," ID34 "Acceleration" and ID35 "Deceleration" are enabled during speed control by communication.

Supplement

This setting applies only to the speed control mode. Acceleration and deceleration operations are executed unconditionally in the homing mode and at smooth stop.

■ Bit 8: Setting an Analog Input 0-point Adjustment Command

| ID | Parameter name | Setting | | | | | | | | | | | | | | | |
|----|----------------|---------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| 30 | Servo Command | * | * | * | * | * | * | * | 1 | * | * | * | * | * | * | * | |

Setting Bit 8 of ID30 "Servo Command" to "1" samples the analog command signals for approximately 0.1 seconds. The average of these values is then set to ID132 "Analog Input Offset."

Set this parameter to use the analog signal for speed control or current control.

To execute an analog command signal offset setting, input an analog signal voltage equivalent to 0 speed or 0 current.

■ Bit 9: Second Control Mode Switch

| ID | Parameter name | Setting | | | | | | | | | | | | | | | |
|----|----------------|---------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| 30 | Servo Command | * | * | * | * | * | * | 1 | * | * | * | * | * | * | * | * | * |

OFF (0): First control mode (ID31)
ON (1): Second control mode (ID99)

Setting Bit 9 of ID30 "Servo Command" to "1" switches the control mode to the second control mode.

Use this parameter to switch between control modes while continuing the servo ON operation.

⇒ Refer to □15.6 "Control Mode Switch Function."

■ Bit 10: Second Current Limit Switch

| ID | Parameter name | Setting | | | | | | | | | | | | | | | |
|----|----------------|---------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| 30 | Servo Command | * | * | * | * | * | * | 1 | * | * | * | * | * | * | * | * | * |

OFF (0): First current limit (ID86 and ID87)
ON (1): Second current limit (ID65 and ID66)

Setting Bit 10 of ID30 "Servo Command" to "1" switches the current limit value to the second current limit. Use this parameter to switch the current limit value only during a particular operation.

■ Bit 11: Second Servo Gain Switch

| ID | Parameter name | Setting | | | | | | | | | | | | | | | |
|----|----------------|---------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| 30 | Servo Command | * | * | * | * | 1 | * | * | * | * | * | * | * | * | * | * | * |

OFF (0): Gain 1 (ID50, ID51 and ID52)
ON (1): Gain 2 (ID60, ID61 and ID62)

Setting Bit 11 of ID30 "Servo Command" to "1" switches the control gain to Gain 2.

To switch between gains, the ID80 "Gain-Switch Method Select" needs to be set to "5" in advance.

⇒ Refer to □13.6 "Gain-Switch Function."

■ Bit 12: Smart ABS Sensor Alarm Reset

| ID | Parameter name | Setting | | | | | | | | | | | | | | | |
|----|----------------|---------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| 30 | Servo Command | * | * | * | 1 | * | * | * | * | * | * | * | * | * | * | * | |

Setting Bit 12 of ID30 "Servo Command" to "1" clears alarms on the sensor side.

Use this parameter for Smart ABS sensors, such as 17, 23Bit-ABS.

⇒ Refer to □17.5 "Sensor Alarm Reset"

■ Bit 13: Origin Detection Notification

| ID | Parameter name | Setting | | | | | | | | | | | | | | | |
|----|----------------|---------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| 30 | Servo Command | * | * | 1 | * | * | * | * | * | * | * | * | * | * | * | * | |

Setting Bit 13 of ID30 "Servo Command" to "1" to recognize the origin detection signal.

Use this parameter to detect the origin with the SV-NET controller during a homing operation in homing mode.

⇒ Refer to □15.4 "Homing Mode."

■ Bit 14: Current Position Reset

| ID | Parameter name | Setting | | | | | | | | | | | | | | | |
|----|----------------|---------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| 30 | Servo Command | * | 1 | * | * | * | * | * | * | * | * | * | * | * | * | * | |

| ID | Parameter name | Setting value | Factory setting | Setting range |
|----|----------------------|---------------|-----------------|--|
| 39 | Position Reset Value | (pulse) | 0x00000000 | -2147483648 to 2147483647 <input type="text" value="DEC"/> |

Setting Bit 14 of ID30 "Servo Command" to "1" sets the current position to the value set in ID39 "Reset Position."

■ Bit 15: Smart ABS Sensor Alarm & Multi-rotation Reset

| ID | Parameter name | Setting | | | | | | | | | | | | | | | |
|----|----------------|---------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| 30 | Servo Command | 1 | * | * | * | * | * | * | * | * | * | * | * | * | * | * | |

Setting Bit 15 of ID30 "Servo Command" to "1" clears alarms and multi-rotation data on the sensor side.

Use this parameter for a smart ABS sensor, such as 17, 23Bit-ABS.

⇒ Refer to □17.5 "Sensor Alarm Reset"

16.4. Servo OFF Delay Function

| ID | Parameter name | Setting value | Factory setting | Setting range |
|-----|-----------------|------------------------------------|-----------------|---|
| 143 | Servo OFF Delay | Delay time (msec) before servo OFF | 0 | 0 to 10000 <input type="text" value="DEC"/> |

When switching from servo ON to OFF, the time that elapses between when a servo OFF command is set to, and when the servo is actually turned OFF, can be adjusted. When the mechanical brake is controlled by Output 4 (brake control signal), setting ID143 to a value longer than the release time setting for the mechanical brake allows the servo to turn OFF after the mechanical brake is applied.

16.5. Defining the Forward Rotation Direction

| ID | Parameter name | Setting value |
|----|---------------------|-----------------|
| 72 | Reference Direction | 0: CCW 1: CW |

The forward rotation direction can be changed to CW by setting ID 72 "Reference Direction" to "1."

Supplement

Note that changing the "Reference Direction" also changes the sign of the position data.

16.6. Setting the Position Soft Limit

■ Setting soft limit enable/disable

| ID | Parameter name | Setting value |
|----|-------------------|-------------------------|
| 83 | Soft Limit Select | 1: Enable 0: Disable |


■ Positive-side soft limit

| ID | Parameter name | Setting value | Setting range |
|----|--------------------------|---------------|--|
| 84 | Positive-side soft limit | (pulse) | -2147483648 to 2147483647 <input type="text" value="DEC"/> |

■ Reverse-side soft limit

| ID | Parameter name | Setting value | Setting range |
|----|-------------------------|---------------|---|
| 85 | Reverse-side soft limit | (pulse) | 2147483648 to 2147483647 <input type="text" value="DEC"/> |

A position limit can be set by software so that the motor does not move out of the intended range. After the detection of position soft limit, the motor immediately stops (speed command 0) (only position and speed control is enabled).




Depending on the motor speed, the motor may stop in excess of the limit position. Therefore, make settings in consideration of operation conditions of the motor.

16.7. Servo OFF Using Communication Stop

The driver has a function which, for safety reasons, automatically turns the servo OFF if USB communication or SV-NET communication ceases for any reason. Set the time for communication cease detection using ID 148 "Enable Off Time." The factory setting is 1000 [msec]. Therefore, the servo is turned OFF if no communication takes place for one second.

| ID | Parameter name | Setting value | Setting range |
|-----|------------------|---------------|--|
| 148 | Enable Off Timer | (msec) | 1 to 10000 <input type="text" value="DEC"/> 0: Cancel |



Setting "0" cancels this function, so that the servo does not turn OFF even if communication ceases. Consider the equipment operating conditions before attempting to cancel this function.

17. Alarm Detection

If an alarm is detected, the driver turns the servo OFF to stop operation. If an alarm is detected, an alarm reset must be performed after first checking the details of the alarm from the alarm code and eliminating the cause of the problem. This chapter describes such alarm-related matters.

17.1. How to Detect an Alarm

■ Checking using the settings panel

If an alarm occurs, the alarm code (AL-**) will be displayed in the settings panel.

"**" represents an alarm code.

■ Checking an alarm with a parameter

An alarm turns on Bit 3 "Alarming" (alarm occurs) of ID 20 "Servo Status" and prompts an update of ID 22 "Alarm Code."

| ID | Parameter name | Setting | | | | | | | | | |
|----|----------------|---------|-----|-------|----|----|----|----|----|----|--|
| | | B31 | B30 | | B5 | B4 | B3 | B2 | B1 | B0 | |
| 20 | Servo Status | * | * | | * | * | 1 | * | * | * | |

| ID | Parameter name | Read value |
|----|----------------|----------------|
| 22 | Alarm Code | (Decimal code) |

Alternatively, Bit 20-22 "Alarm Bit Code (Ab0-Ab2) in ID 20 "Servo Status" also indicates if any alarm is issued and its rough classification.

Correspondence between alarm bit codes and alarm codes is as follows: Ab0 = Bit 20, Ab1 = Bit 21, and Ab2 = Bit 22.

Refer to □17.2 "List of Alarm" to find the correspondence between alarm bit codes and alarm codes.

Alarm bit codes (Ab0, Ab1, and Ab2) are all 0 when there is no alarm.


(Example) Alarm Code 71 "Excess Drive Voltage"

| ID | Parameter name | Setting | | | | | | | |
|----|----------------|---------|-------|-----------|-----------|-----------|-------|----|--|
| | | B31 | | B22 (Ab2) | B21 (Ab1) | B20 (Ab0) | | B0 | |
| 20 | Servo Status | * | | 1 | 0 | 1 | | * | |

Alarm bit codes Ab0 = 1, Ab1 = 0, Ab2 = 1

Once conditions for certain alarms are met, corresponding bits change to 1 in ID 29 "Warning Status Display."

⇒Refer to □17.10 "Alarm Detection Disabling Settings and Warning Status Display."

| ID | Parameter name | Description |
|----|------------------------|---|
| 29 | Warning Status Display | <p>The corresponding Bit is 1 when the condition enclosed in parentheses in the following is met.</p> <p>Bit 0: Drive voltage low warning (The drive voltage drops, or Alarm 72 conditions are met.)</p> <p>Bit 1: Backup battery voltage low warning (The backup battery voltage is 3.1 V or less (only the absolute encoder).)</p> <p>Bit 3: Actual current overload warning (Alarm 21 conditions are met.)</p> <p>Bit 4: Command current overload warning (Alarm 22 conditions are met.)</p> <p>Bit 5: Overspeed warning (Alarm 31 conditions are met.)</p> <p>Bit 6: Multi-rotation warning (Alarm 41 conditions are met.)</p> <p>Bit 7: Excess position deviation warning (Alarm 42 conditions are met.)</p> <p>Bit 8: Driver temperature warning (Alarm 51 conditions are met.)</p> <p>Bit 9: External encoder count warning (Alarm 67 conditions are met.)</p> <p>Bit10: External encoder position error warning (Alarm 68 conditions are met.)</p> <p>Bit11: Excess regenerated volume warning (Alarm 74 conditions are met.)</p> <div style="border: 1px solid black; border-radius: 5px; padding: 2px; display: inline-block; margin-top: 10px;">  Important </div> <p>In case any alarm is issued, Bit 3-11 in ID 29 "Warning Status Display" are fixed at a status corresponding to the alarm. These can be cleared by resetting the alarm.</p> |

■ Checking an alarm with a digital output from the I/O connector

An alarm turns on the corresponding digital output on the I/O connector.

(Factory setting: Pins 30 and 31 for Output 1)

Alarm bit codes can be checked with digital output by assigning Bit 20-22 in ID 20 "Servo Status Display" to any digital output.

⇒Refer to □7.7 "Wiring the I/O Connector"

⇒Refer to □19.10 "Parameters for Setting I/O" (Parameter ID 110-114)

17.2. List of Alarm

| Alarm code | Alarm bit code | | | Name | Description | Situation | Main cause | Corrective action | | | | |
|------------|----------------|-----|-----|-------------|---|--|---|---------------------|--|--|--|--|
| | Ab2 | Ab1 | Ab0 | | | | | | | | | |
| 11 | 0 | 0 | 1 | Overcurrent | Power drive area error, overcurrent | Occurs only when powering on. | Driver failure | Replace the driver. | | | | |
| | | | | | An electric current exceeding the allowable current value of the driver flowed. | Alarm 11 occurs even when power is turned on by disconnecting the motor cable (U, V, and W). | | | Motor wiring short | Check the motor wiring. Check that the connection of motor cable U, V, and W is not shorted. Check the branched-out wire out of the connector. Make a correct wiring connection. | | |
| | | | | | Do not repeatedly the power turn on and off without a good reason when this alarm is issued. Instead, try troubleshooting by following instructions in the "Corrective action" section. | Occurs when servo is turned ON. | | | Motor winding short | Replace the motor. Check the balance of resistor between each motor line, and if unbalance is found, replace the motor. | | |
| | | | | | | | | | Driver malfunction (Failure of the driver transistor (IPM/IGBT)) | Replace the driver. Remove the motor cable and turn the servo on. If an error occurs immediately, replace the driver with a new (operating) driver. | | |
| | | | | | | | | | Occurs during acceleration/deceleration. | Driver adjustment failure | Reduce the gain. | |
| | | | | | | | | | | Driver malfunction | Replace the driver. | |
| | | | | | | | | | | — | Ground fault of the servo motor power cable (U, V, and W) | Fix the wiring. |
| | | | | | | | | | | — | The overcurrent detection circuit has malfunctioned due to external noise. | Take noise countermeasures. |
| | | | | | | | | | | — | The power cable or the motor cable is incorrectly wired or has a bad connection. | Fix the wiring. |
| | | | | | | | | | | — | The inside of the motor cable (U, V, and W) is short-circuited or a ground fault has occurred. | The cable may have short-circuited. Replace the cable. |
| | | | | | | | | | | — | The inside of the servo motor, motor cable or terminal block (U, V, and W) has short-circuited or a ground fault has occurred. | The servo motor may have failed. Replace the servo motor. |
| | | | | | | | | | | — | The regeneration resistor is incorrectly wired or has a bad connection. | Fix the wiring. |
| | | | | | | | | | | — | Frequent use of the dynamic brake (DB for emergency stop by the driver) | Change the methods of driver selection and operation or change the equipment to reduce the frequency of use of the DB. Replace the driver. |
| | | | | | | | | | | — | The regeneration resistance value of the driver is too small. | Change to the one with the regeneration resistance specified for the driver. |
| | | | | | — | Malfunction resulting from noise | Take appropriate noise countermeasures such as wiring FG correctly. Use a thicker size wire for FG. | | | | | |

| Alarm code | Alarm bit code | | | Name | Description | Situation | Main cause | Corrective action |
|------------|----------------|-----|-----|------------------------------|--|--|--|---|
| | Ab2 | Ab1 | Ab0 | | | | | |
| 11 | 0 | 0 | 1 | Overcurrent | | — | Welding of the dynamic brake relay due to frequent Servo-ON/OFF operation. | Replace the driver. Discontinue the operation of the dynamic brake with Servo ON-OFF. |
| 21 | 0 | 1 | 0 | Actual current overload | Overload protection is prompted in accordance with 16.9 "Characteristics of Overload Alarm Detection" when actual and command values in torque command exceed an overload level. An actual current overload turns on Bit 3 in ID 29 "Warning Status Display." | The motor vibrates when servo is ON or in operation. | Adjustment failure | Re-adjust the gain. |
| | | | | | | Occurs during acceleration/deceleration. | High acceleration/deceleration | Reduce acceleration/deceleration. |
| 22 | 0 | 1 | 0 | Command current overload | A command current overload turns on Bit 4 in ID 29 "Warning Status." | Occurs during constant-speed rotation. | High load torque The servo motor is used at an output exceeding its rated output (rated current) | Check installed equipment. Reduce the load. Review the running pattern. Consider a higher output servo motor. |
| | | | | | | Occurs when servo is turned ON. | Motor wiring Erroneous connection of the servo motor The output terminals U, V, and W of the servo driver do not match the input terminals U, V, and W of the servo motor. | Check the motor wiring. |
| 31 | 0 | 1 | 1 | Overspeed | The motor rotational speed has exceeded the set value of Over-Speed Alarm Detection Speed (ID 201). Bit 5 in ID 29 "Warning Status Display" is turned on. | Occurs during operation. | Speed overshoot | Re-adjust the gain. Do not give an excessive speed command. Check the command pulse input frequency and the electronic gear ratio. Make a gain adjustment when an overshoot has occurred due to a poor gain adjustment. Make the sensor wiring connection as shown in the wiring diagram. |
| 41 | 1 | 0 | 0 | Counter Overflow | Driver position Counter error Bit 6 in ID 29 "Warning Status Display" is turned on. | Occurs during rotation. | The in-driver position counter has exceeded the specifications. | Allow the move distance from the origin to be within 0x70000000 (1,879,048,192) counts. Set Bit3 of the alarm mask (ID 209) to 1 in application as an infinite rotation axis. |
| 42 | 1 | 0 | 0 | Position excessive deviation | The position deviation pulse exceeds the set value of Position Deviation Error Detection Pulse Count (ID 202). Bit 7 in ID 29 "Warning Status Display" is turned on. | Occurs during pulse command input. | Pulse input without servo ON input. | Check the servo ON input. |
| | | | | | | | The forward-rotation drive disable input or the reverse-rotation drive disable input has not been input or set. | Check the wiring and settings. |
| | | | | | | | The motor movement has not followed the command. | Check if the motor rotates according to the position command pulses. Check with the torque monitor that the output torque is not saturated. Adjust servo gains (IDs 50 to 52). Set the highest possible value for Position Deviation Error Detection Pulse Count (ID 202). |
| | | | | | | | The current position corresponds to 0x70000000 (1,879,048,192) pulses or more. | Disable the speed stabilizing control and the position command damping filter. |
| | | | | | | Occurs during acceleration/deceleration. | High acceleration/deceleration | Lower the acceleration/deceleration. |

| Alarm code | Alarm bit code | | | Name | Description | Situation | Main cause | Corrective action |
|---------------|----------------|-----|-----|--------------------|--|----------------------------------|---|---|
| | Ab2 | Ab1 | Ab0 | | | | | |
| 51 | 0 | 1 | 0 | Over heat | Abnormal driver internal temperature is detected. Bit 8 in ID 29 "Warning Status Display" is turned on. | Occurs during operation. | Use under frequent overload conditions. | Relax operation conditions. Increase the capacity of the driver and motor. Set a longer acceleration/deceleration time. Reduce the load. |
| | | | | | | | Ambient temperature high | Improve heat dissipation conditions by installing a fan, for example. Improve the ambient temperature and cooling conditions of the driver. |
| 61 — 69 | 0 | 1 | 1 | Sensor error | Description depends on types of sensors. Refer to □17.3 "List of Sensor Alarm." | | | |
| 71 | 1 | 0 | 1 | Over Voltage | Drive power supply voltage increased and exceeded the predetermined value. AC100 V product Drive power supply voltage: Approx. 200 VDC AC200 V product: Drive power supply voltage: Approx. 400 VDC | Occurs during operation. | Insufficient capacity for regenerative protection | Add regenerative resistance. |
| | | | | | | Occurs when power is turned on. | Wrong voltage specification is used if detected when power is turned on. | Exchange the driver. Measure the voltage between the power supply cables. |
| 72 | 1 | 0 | 1 | Voltage Down | The drive power supply voltage has fallen below the specified value. AC100 V product: Drive power supply voltage: Approx. 50 VDC (Approx. 35 VAC) AC200 V product: Drive power supply voltage: Approx. 150 VDC (Approx. 100 VAC) Bit 0 of ID 29 "Warning Status Display" is turned on regardless of the servo status. | Occurs during operation. | Insufficient power supply capacity | Increase the capacity of the power supply voltage. Change the power supply. |
| | | | | | | | Drive power supply line disconnection | |
| | | | | | | Occurs when power is turned on. | Drive line disconnection | Check the wiring. |
| 73, 74 | 1 | 1 | 0 | Regeneration error | Regeneration protection operated continuously, which resulted in an exceeding of the threshold of the regeneration alarm detection capacity (ID 207). Bit 11 of ID 29 "Warning Status Display" is turned on. | Occurs during operation. | Insufficient capacity for regenerative resistance Regenerative resistance is not as specified. | Review the operation pattern. Check if the regenerative resistance is as specified. |
| 75 | 1 | 0 | 1 | Drive power error | No drive voltage increase (P-N on DC side after rectification) despite detected power input (AC side) | Occurs when power is turned on. | Power voltage is too low. | Check the power voltage (ex. input of AC100 V to a device operating with AC200 V). |
| | | | | | | | Failure of a power circuit | Replace the driver. |
| 81 | 1 | 1 | 1 | External alarm | Detection of I/O input (external alarm input) ⇒ Refer to □19.10 "Parameters for Setting I/O" | Occurs during operation. | An external alarm was issued. | Cancel the alarm from the source. |
| | | | | | | | Disconnected I/O cable | Check the I/O cable. |
| 91, 93 | 1 | 1 | 1 | Flash Memory Error | Nonvolatile memory read error | Occurs when power is turned on. | IC nonvolatile memory or CPU malfunction | Replace the driver. |
| 92 | 1 | 1 | 1 | | Nonvolatile memory write error | Occurs during parameter storing. | | |
| 98 | 1 | 1 | 1 | Hardware Error | CPU error | Occurs during operation. | Malfunction resulting from noise | Install noise filter. |
| | | | | | | Occurs when power is turned on. | Driver failure | Replace the driver. |
| 99 | 1 | 1 | 1 | Parameter Error | Parameter error | Occurs during parameter storing. | Parameter values written in nonvolatile memory were incorrect. (No write executed). | Check changed parameter values. |

17.3. List of Sensor Alarm

■ Brushless resolver 1X-BRX

| Alarm code | Name | Description | Situation | Main cause | Corrective action |
|------------|--------------|---|---------------------------------|---|---|
| 61 | Sensor error | Correct resolver signal detection failed. | Occurs when power is turned on. | Resolver signal has low amplitude or the cable is disconnected. | Check if the sensor cable and sensor are correctly connected. <ul style="list-style-type: none"> Replace the driver. Check the compatibility between the driver and motor models. |
| 62 | | | | Resolver signal has too large an amplitude. | Check if the sensor cable and sensor are correctly connected. <ul style="list-style-type: none"> Replace the driver. Check the compatibility between the driver and motor models. |

■ Encoder wiring-saving INC

| Alarm code | Name | Description | Situation | Main cause | Corrective action |
|------------|-------------------------------|---|--|--|--|
| 62 | Sensor not Connect Error | Disconnection of the sensor cable was detected. | Occurs during operation. | No sensor cable connected | Check the connection. |
| 63 | Sensor initialization error 1 | A/B/Z signals were abnormal immediately after the power was turned on (normally: high impedance). | Occurs when power is turned on. | <ul style="list-style-type: none"> The control power supply was immediately restored after being turned off. Sensor cable disconnection Sensor signal failure | <ul style="list-style-type: none"> After cutting off the power and the display on the setting panel turns off, turn on the power supply again. Check the connection. Replace the motor. |
| 64 | Sensor initialization error 2 | <ul style="list-style-type: none"> U/V/W signals was received (high impedance was not cancelled after the power was turned on). Power was turned on when the sensor cable was disconnected. | | | |
| 65 | Sensor initialization error 3 | Data error was detected with U/V/W signals. (All of U/V/W were either High or Low.) | | | |
| 66 | Initial Z signal error | <ul style="list-style-type: none"> Detection position of Z signal is abnormal. Z signal was detected. | Occurs after the motor rotates slightly when the power is turned on. | <ul style="list-style-type: none"> Sensor cable disconnection Sensor signal failure | <ul style="list-style-type: none"> Check the connection. Replace the motor. |

■ External Encoder

| Alarm code | Name | Description | Situation | Main cause | Corrective action |
|------------|---------------------------------|--|---|---|--|
| 67 | External Encoder Count Error | Correct receipt of external encoder signal failed. | Occurs when external encoder signals are input into the driver. | Disconnected external encoder or open phase | Check the external encoder output signals and input/output. |
| | | Bit 9 of ID 29 "Warning Status Display" is turned on. | | Error in the input of external encoder signals to the I/O connector | Check the connection and wiring to the I/O connector. |
| 68 | External Encoder Position Error | <p>There is a difference between the movement distance recognized by external encoder and that recognized by motor sensor.</p> <p>Bit 10 of ID 29 "Warning Status Display" is turned on.</p> | Occurs when external encoder signals are input into the driver. | Inadequate setting of ID 124 "External Encoder Resolution" | <ul style="list-style-type: none"> Review the setting for ID 124. Cancel this alarm by setting ID209 "Alarm Mask." |

■ Encoder 17, 23Bit-ABS/17, 23Bit-INC

| Alarm code | Name | Description | Situation | Main cause | Corrective action |
|------------|--------------------------|--|---|---|---|
| 61 | Sensor Battery Error | Sensor backup battery error Bit 1 of ID 29 "Warning Status Display" is turned on. | Occurs when power is turned on. | The battery of the 17, 23Bit-ABS sensor was removed. | Clear the sensor alarm by setting Bit 15 "Smart ABS sensor alarm & multi-rotation reset" of ID 30 "Servo Command." Use it after setting ID 140 "Abs Mode" to 0. |
| | | | | The battery cable is disconnected. | Repair the cable Or, replace the battery. |
| | | | | The battery voltage lowered to approximately 3 V or less. | Replace the battery. |
| 62 | Sensor not Connect Error | Motor-driver sensor connection line error | Occurs when power is turned on. | No sensor cable connected | Check the connection. |
| | | | | Power was applied to the 17, 23Bit-ABS sensor for the first time. | Clear the sensor alarm by setting Bit 15 "Smart ABS sensor alarm & multi-rotation reset" of ID 30 "Servo Command." |
| | | | | The sensor cable was once disconnected and reconnected. | Check the sensor connection, then clear the sensor alarm by setting Bit 15 "Smart ABS sensor alarm & multi-rotation reset" of ID 30 "Servo Command." |
| 63 | Counter Overflow Error | Error of multi-rotation counter of the sensor | Occurs when the motor is rotating. | The multi-rotation counter of the 17, 23Bit-ABS sensor has exceeded the specifications. | Reset the multi-rotation counter by setting Bit 15 "Smart ABS sensor alarm & multi-rotation reset" of ID 30 "Servo Command." Set ID 140 "Abs Mode" to 0 in application as an infinite rotation axis. |
| 64 | 1rev Count Error | One-rotation counter error of the sensor | Occurs when power is turned on. Occurs when the motor is rotating. | Error detected in the one-rotation counter of the 17, 23Bit sensor. | Clear the sensor alarm by setting Bit 15 "Smart ABS sensor alarm & multi-rotation reset" of ID 30 "Servo Command." |
| 66 | Overspeed Error | Speed error | Occurs when power is turned on. | Battery backup The sensor rotated at a speed exceeding the specification during battery drive. | Clear the sensor alarm by setting Bit 15 "Smart ABS sensor alarm & multi-rotation reset" of ID 30 "Servo Command." Use it after setting ID 140 "Abs Mode" to 0. Set the number of motor rotations to less than 6000 rpm and turn on the control power supply. |

17.4. Resetting Alarm

| ID | Parameter name | Setting | | | | | | | | | | | | | | | |
|----|----------------|---------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| 30 | Servo Command | * | * | * | * | * | * | * | * | * | * | * | 1 | * | * | * | |



Caution

Clear the alarm after eliminating the cause of the problem.

17.5. Clearing a Sensor Alarm

| ID | Parameter name | Setting | | | | | | | | | | | | | | | |
|----|----------------|---------|-----|-----|-----|-----|-----|----|----|----|----|----|----|----|----|----|----|
| | | B15 | B14 | B13 | B12 | B11 | B10 | B9 | B8 | B7 | B6 | B5 | B4 | B3 | B2 | B1 | B0 |
| 30 | Servo Command | 1 | * | * | * | * | * | * | * | * | * | * | * | * | * | * | |

If the sensor is 17, 23Bit-ABS, the alarm codes 61, 63, 64, and 66 are alarms recorded on the sensor side.

Assign "1" to Bit 15 "Smart ABS sensor alarm & multi-rotation reset" of ID 30 "Servo Command" when it is necessary to clear alarms recorded on the sensor side.

Once sensor alarms are cleared, cancel the alarms by running a normal alarm reset.

⇒ Refer to □17.4 "Resetting Alarm"

17.6. Checking the Alarm History

Refer to "Alarm History-1" and "Alarm History-2" to see the past 8 alarm records.

| ID | Parameter name | Read value | Description | | | |
|----|-----------------|---------------------------|-------------|-------------|------------|-----------|
| | | | Bit31 to 24 | Bit23 to 16 | Bit15 to 8 | Bit7 to 0 |
| 23 | Alarm History-1 | Alarm code records 1 to 4 | Record 4 | Record 3 | Record 2 | Record 1 |
| 24 | Alarm History-2 | Alarm code records 5 to 8 | Record 8 | Record 7 | Record 6 | Record 5 |

■ Records 1 to 8 are in decimal.

New alarm is registered in Alarm History-1 and the older ones are shifted down. The oldest history is deleted.

17.7. Checking Detailed Alarm Occurrence Information

Detailed information at the time of alarm occurrence can be checked (alarm recorder function)
 Setting the alarm history code and information code you wish to check in parameter ID 25 "Select Alarm Occurrence Information to be Displayed" displays information at the time of alarm occurrence specified for parameter ID 26 "Alarm Occurrence Information."

| ID | Parameter name | Description |
|----|---|--|
| 25 | Select Alarm Occurrence Information to be Displayed | <p>Alarm occurrence information is displayed in ID 26 according to the following settings:</p> <ul style="list-style-type: none"> · Bit 15 to 8 = Alarm history code 00: Record 1 (Latest), 01:Record 2, ... 07:Record 8 · Bit 7 to 0 = Alarm information code 00: Alarm code 01: Month and day of occurrence [BCD] * The year is not displayed. 02: Hour and minute of occurrence [BCD] * The second is not displayed. 03: Total driver power ON time (minutes) 04: Servo Status (ID 20) 05: Feedback current [0.01 Arms] (ID 42) 06: Feedback speed [rpm] (ID 41) 07: Feedback position [pulse] (ID 40) 08: Drive power supply voltage [0.1 V] (ID 161) 09: Driver temperature [0.1°C] (ID 160) 0A: Overload monitor [0.1%] (ID 159) 0B: Command overload monitor [0.1%] <p>Example: Set at 0x0306 when looking at the speed when the alarm Record 4 was generated.</p> |
| 26 | Alarm occurrence information | <p>Alarm occurrence information Displays the data specified with ID 25.</p> |

Supplement

To set the year/month/date and hour/minute of alarm occurrence (calendar function), refer to the next page.
 The value displayed for each servo data is actually the value just before the alarm occurred.

17.8. Setting the Calendar Function

To record "Month and day of occurrence" and "Hour and minute of occurrence" in Alarm Occurrence Information (alarm recorder function), the calendar function needs to be set in advance. Set the calendar function after purchasing this driver.

The calendar function is the Real Time Clock (RTC) function maintained by the driver's built-in lithium battery even when the power goes off. The date and time held by the calendar function are confirmed by referring to ID 240 "Current Date" and ID 241 "Current Time."

To change values, set new values by adding "88" to the most significant value as shown in the table below. The date and time values are automatically updated and the calendar restarts from the newly set values.

Supplement

The calendar function can be configured with a special application. Refer to the instruction manual of each application.

| ID | Parameter name | Description |
|-----|----------------|--|
| 240 | Current Date | <p>Calendar function: Current date Displays the date registered in the driver in binary coded decimal form. Example: November 23, 2013 → 0x00131123 To change the current date, set new values by adding 0x88 to the most significant 1 byte. Example: To change the current date to March 5, 2014, set 0x88140305. This parameter is saved when data is set. (Parameter storing does not have to be implemented.)</p> <div style="border: 1px solid black; padding: 2px; display: inline-block; margin-top: 10px;"> Important </div> <p style="margin-left: 20px;">Setting the year to 00 is not allowed.</p> |
| 241 | Current Time | <p>Calendar function: Current time Displays the current time registered in the driver in binary coded decimal (BCD) form. Example: 23h 12m 05sec → 0x00231205 To change the current time, set new values by adding 0x88 to the most significant 1 byte. Example: To change the current time to 11h 32m 01sec, set 0x88113201. This parameter is saved when data is set. (Parameters storing does not have to be implemented.)</p> |

The calendar function is maintained by the lithium battery in the driver. (Service life indication: approximately 4 to 5 years from the month of manufacture; a fee will be charged for battery replacement.)

After the battery expires, even if the calendar is reset, the current date and current time are cleared to 0x000000 due to power-off. If an alarm occurs under the condition, "Month and day of occurrence" and "Hour and minute of occurrence" in Detailed Alarm Occurrence Information, these are saved as 0x0000.

The calendar function is accurate within approximately 60 seconds per month.


17.9. Characteristics of Overload Alarm Detection

By comparing the motor current command and the detection level, an overload alarm is detected with the following time characteristics:

There are two types of overload alarms: Actual Current Overload (21) detected from the actual motor current and Command Current Overload (22) detected from the command current.

Actual current detection has the advantage because it allows detection that better reflects the actual increase in the motor temperature.

Command current detection has the advantage that it allows alarm detection even under abnormal motor wiring condition or other abnormal conditions.



17.10. Alarm Detection Disabling Settings and Warning Status Display

Issuance of some alarms can be disabled. Use this setting when you do not want to issue an alarm during the initial adjustment or experiment.

Note that ID29 "Warning Status Display" remains enabled even when alarm detection is disabled.



Caution

Continued operation while alarm conditions persist can cause failure of a device, a driver, or a motor. Use the alarm detection disabling settings only when safety measures have been implemented on the host system side. Any failures and damage caused by continued operation while alarm detection is disabled are not covered by warranty.

| ID | Parameter name | Description |
|-----|------------------------|--|
| 209 | Alarm Mask | <p>Disables detection of some alarms. Setting the specified bit to "1" disables the issuance of an alarm.</p> <p>Bit 0: 1 = Actual Current Overload Alarm (21) Bit 1: 1 = Command Current Overload Alarm (22) Bit 2: 1 = Overspeed Alarm (31) Bit 3: 1 = Multi-rotation Alarm (41) Bit 4: 1 = Position Excessive Deviation Alarm (42) Bit 5: 1 = Driver Temperature Alarm (51) Bit 6: 1 = External Encoder Count Alarm (67) Bit 7: 1 = External Encoder Position Error Alarm (68) Bit 8: 1 = Regeneration Capacity Alarm (74) Bit 12: 1 = Drive power low alarm (72)</p> <p>Example: Set 0x0030 when disabling Excessive Deviation Alarm (42) and Circuit Board Overheat Alarm (51).</p> |
| 29 | Warning Status Display | <p>The corresponding Bit is 1 when the condition enclosed in parentheses in the following is met.</p> <p>Bit 0: Drive power supply voltage low warning (The drive power supply voltage is low, or the Alarm 72 conditions are met.) Bit 1: Backup battery voltage low warning (The backup battery voltage is 3.1 V or less (only the absolute encoder).) Bit 3: Actual current overload warning (Alarm 21 conditions are met.) Bit 4: Command current overload warning (Alarm 22 conditions are met.) Bit 5: Overspeed warning (Alarm 31 conditions are met.) Bit 6: Position counter overflow warning (Alarm 41 conditions are met.) Bit 7: Excess position deviation warning (Alarm 42 conditions are met.) Bit 8: Driver temperature error warning (Alarm 51 conditions are met.) Bit 9: External encoder count error warning (Alarm 67 conditions are met.) Bit 10: External encoder position error warning (Alarm 68 conditions are met.) Bit 11: Excess regenerated volume warning (Alarm 74 conditions are met.)</p> <div style="border: 1px solid black; border-radius: 10px; padding: 2px; display: inline-block;"> Important </div> <p>In case any alarm is issued, Bit 3-11 in ID 29 "Warning Status Display" are fixed at a status corresponding to the alarm. They are cleared by resetting the alarm.</p> |

18. Troubleshooting

| Classification/Trouble | Cause | Check method | Corrective action |
|--|---|--|---|
| Servo Motor Does Not Rotate <Wiring and Installation> | Power is not turned on. | Measure the voltage between power terminals. | Correctly wire the power supply. |
| | CN1 (I/O) is miswired or disconnected. | Check the input/output signal connections (CN1). | Correctly wire the input/output signals (CN1). |
| | The servo motor or sensor wiring is off. | Check the wiring condition. | Correct the wiring. |
| | The servo motor is overloaded. | Run the motor with no load and check the load status. | Reduce the load or replace it with a larger capacity driver or servo motor. |
| | Wrong types of sensors are used. | Check the correct combination. | Use the correct combination of sensors. |
| | The servo ON input of CN1 (I/O) is not turned on. | Check the command from the higher-level device. Check ID 21 "I/O Status Display." | Check the wiring of the servo ON input. |
| | Forward-rotation drive disable input or reverse-rotation drive disable input of CN1 (I/O) is turned on. | Check ID 21 "I/O Status Display." | Turn off the forward-rotation drive disable input/reverse-rotation drive disable input signals. |
| | Deviation reset input of CN1 (I/O) is turned on. | Check ID 21 "I/O Status Display." | Turn off the deviation reset input. |
| | Driver malfunction | Compare with a correctly operating driver. | Replace the driver. |
| | Pulse input disable command of CN1 (I/O) is turned on. | Check ID 21 "I/O Status Display." | Pulse input disable command signal is turned off. |
| | Drive power supply is shut off. | Check if the CHARGE lamp is lit. | Check the wiring and voltage of the power supply of the driver. |
| | The motor shaft drags. The motor does not rotate. | Check that you can turn the motor shaft by hand, after turning off the power of the driver and separating it from the machine. In the case of a motor with an electromagnetic brake, check that you can turn the motor shaft by hand while applying voltage to the brake. | If you cannot turn the motor shaft, replace the motor. |

| Classification/Trouble | Cause | Check method | Corrective action |
|---|--|---|---|
| Servo Motor Does Not Rotate <Parameter> | The control mode and command selection are wrong. | In the monitor mode of the settings panel, check whether the current control mode is wrong. | Again set the parameters related to operation. <ul style="list-style-type: none"> • ID 31 "Control Mode" • ID 74 "Select Position Command" • ID 75 "Select Speed Command" • ID 76 "Select Torque Command" |
| | The settings for I/O inputs are wrong. | Check if there are any errors or superimposed items on the I/O input setting. | Set parameters related to operation again. <ul style="list-style-type: none"> • ID 100-107 "I/O Input 1 (IN1)-8 (IN8) Setting" |
| | Command pulse input setting is wrong. (for position control) | Pulse output setting of a higher-level device and check the setting of ID 120 "Pulse Input Mode." | Check if the command pulse is properly input with a method selected in ID 120 "Pulse Input Mode." |
| | Speed command is invalid. (for speed control) | Check that the speed command input method is correct. | <ul style="list-style-type: none"> • Using external analog command Assign "1" to ID 75 "Select Speed Command" and once again check ID 130 "Analog Input Signal Speed Conversion Scale" and ID 132 "Analog Input Offset." • Using command signal with SV-NET Assign "0" to ID 75 "Select Speed Command" and set ID 37 "Real-time Command Speed." |
| | The command pulse input resolution is wrong. (for position control) | Check that the motor moves the expected distance in response to the input command pulse. | Set parameters related to operation again. <ul style="list-style-type: none"> • ID 74 "Select Position Command" • ID 120 "Pulse Input Mode" • ID 121 "Command Pulse Input Signal Resolution Numerator" • ID 122 "Command Pulse Input Signal Resolution Denominator" |
| | The current command is invalid (for current control). | Check whether the current command input method is wrong. | <ul style="list-style-type: none"> • Using external analog input Assign "1" to ID 76 "Select Torque Command" and once again check ID 131 "Analog Input Current Speed Conversion Scale" and ID 132 "Analog Input Offset." • Using command signal with SV-NET Set the ID 76 "Select Torque Command" to "0" and set the ID 38 "Real-time Command Current." |
| The Motor Rotates Momentarily but Will Not Rotate after That | The servo motor wiring is not correct. | Check the wiring. | Correct the wiring. |
| | The sensor wiring is not correct. | Check the wiring. | Correct the wiring. |
| The Motor Rotation Is Unstable | Wiring connection to the servo motor is defective. | The connection between the motor cable (U, V, and W phases) and the sensor connector may be unstable. Check the wiring. | Correct the wiring by tightening loose terminal blocks and connectors. |
| The Motor Rotates without a Command | Driver malfunction | Compare with a normal drive. | Replace the driver. |

| Classification/Trouble | Cause | Check method | Corrective action |
|---|---|---|---|
| Dynamic Brake (DB) Does Not Operate | Wrong setting for ID 154 "Dynamic Brake Drive Conditions" | Check the setting for ID 154 "Dynamic Brake Drive Conditions." | Correctly set ID 154 "Dynamic Brake Drive Conditions." |
| | DB actuation circuit failure | - | Replace the driver. |
| Abnormal Noise from Servo Motor | Strong motor vibration. | Check the feedback speed waveform of the monitor. | Reduce the load or re-adjust the gain. |
| | Mechanical mounting failure. | Check if the servo motor is mounted securely. | Tighten the mounting screws. |
| | | Check if there is misalignment of couplings. | Align the couplings. |
| | | Check if there are unbalanced couplings. | Balance the couplings. |
| | There is an abnormality in the bearings. | Check the noise and vibration around the bearings. | Replace the servo motor. |
| | The vibration is generated from another machine. | Check if there is any foreign matter, damage, or deformation in the moving parts of the machine. | Consult the machine maker. |
| | Noise is superimposed on the sensor cable. | Check the sensor cable specifications. Review the cable specifications. Use a twisted pair cable or twisted pair common shield cable (core wire: 0.12 mm ² or more, tinned annealed copper twisted wire). | Review the cable specifications. |
| | | Check whether there is any pinching of sensor cable or breakage in the shield. | Replace the sensor cable and alter the sensor cable layout environment. |
| | | Check if a ground is used as both the control power supply ground (safety voltage GND) and the frame ground (FG) by a host system. | Separate the control power supply ground and the frame ground (FG). |
| | | Check the termination of the sensor cable shield. | Change the termination to the control power supply ground when the shield is terminated to the frame ground (FG). |
| Noise is superimposed because the sensor cable is too long. | Check the length of the sensor cable. | Use a sensor cable of 10 m or less. | |

| Classification/Trouble | Cause | Check method | Corrective action |
|--|--|---|--|
| Abnormal Noise from Servo Motor | There is excessive noise interference on the sensor cable. | Check to make sure that the sensor cable is not bundled together with a power line or arranged closed to the line. | Improve the installation environment to avoid application of a surge from a power line. |
| | The FG (frame ground) potential varies because of influence from machines on the servo motor side, such as a welder. | Check the grounding state (non-grounding, incomplete grounding, etc.) of the motor-side machines. | Correctly ground the machines on the motor side. |
| | Failure due to excessive vibration or shocks applied to the sensor | Check that no vibration is generated from the machine. Also check the mounting conditions of the servo motor (mounting surface accuracy, fixing state, core dislocation). | Reduce vibration from the machine. Improve the mounting conditions of the servo motor. |
| | Sensor malfunction | - | Replace the servo motor. |
| Servo Motor Vibrates at a Frequency of Approx. 400 Hz or Less | The servo gain balance is not appropriate. | Check if the servo gain is adjusted. | Re-adjust the servo gain. |
| | The setting value of ID 51 "Speed Loop Proportional Gain 1" is excessively high. | Check the setting value of ID 51 "Speed Loop Proportional Gain 1." Factory setting: $K_v = 200$ | Lower the setting value of ID 51 "Speed Loop Proportional Gain 1" until the servo motor does not vibrate. |
| | The setting value of ID 50 "Position Loop Proportional Gain 1" is excessively high. | Check the setting value of ID 50 "Position Loop Proportional Gain 1." Factory setting: $K_p = 50$ | Configure the setting value of ID 50 "Position Loop Proportional Gain 1" until the servo motor does not vibrate. |
| | The setting value of ID 52 "Speed Loop Integral Gain 1" is incorrect. | Check the setting value of ID 52 "Speed Loop Integral Gain 1." Factory setting: $K_i = 50$ | Configure the setting value of ID 52 "Speed Loop Integral Gain 1" correctly. |
| | The setting value of ID 59 "Load Inertia" is incorrect. | Check the setting value of ID 59 "Load Inertia." | Configure the setting value of ID 59 "Load Inertia" correctly. |
| High Motor Speed Overshoot on Starting and Stopping | The servo gain balance is not appropriate. | Check if the servo gain is adjusted. | Re-adjust the servo gain. |
| | The setting value of ID 51 "Speed Loop Proportional Gain 1" is excessively high. | Check the setting value of ID 51 "Speed Loop Proportional Gain 1." Factory setting: $K_v = 200$ | Reduce the setting value of ID 51 "Speed Loop Proportional Gain 1" to bring the overshoot to a low level. |
| | The setting value of ID 50 "Position Loop Proportional Gain 1" is excessively high. | Check the setting value of ID 50 "Position Loop Proportional Gain 1." Factory setting: $K_p = 50$ | Reduce the setting value of ID 50 "Position Loop Proportional Gain 1" to bring the overshoot to a low level. |
| | The setting value of ID 52 "Speed Loop Integral Gain 1" is incorrect. | Check the setting value of ID 52 "Speed Loop Integral Gain 1." Factory setting: $K_i = 50$ | Configure the setting value of ID 52 "Speed Loop Integral Gain 1" correctly. |
| | The setting value of ID 59 "Load Inertia" is incorrect. | Check the setting value of ID 59 "Load Inertia." | Configure the setting value of ID 59 "Load Inertia" correctly. |

| Classification/Trouble | Cause | Check method | Corrective action |
|---|--|---|---|
| Absolute Encoder Position Error (Difference between the position at the time of power-off held by the host equipment and the position at the time of the next power-on) | Noise is superimposed on the sensor cable. | Check the sensor cable specifications. Review the cable specifications. Use a twisted pair cable or twisted pair common shield cable (core wire: 0.12 mm ² or more, tinned annealed copper twisted wire). | Review the cable specifications. |
| | | Check whether there is any pinching of sensor cable or breakage in shield. | Replace the sensor cable and alter the sensor cable layout environment. |
| | | Check if a ground is used as both the control power supply ground (safety voltage GND) and the frame ground (FG) by a host system. | Separate the control power supply ground and the frame ground (FG). |
| | | Check the termination of the sensor cable shield. | Change the termination to the control power supply ground when the shield is terminated to the frame ground (FG). |
| | Noise is superimposed because the sensor cable is too long. | Check the length of the sensor cable. | Use a sensor cable of 10 m or less. |
| | There is excessive noise interference on the sensor cable. | Check to make sure that the sensor cable is not bundled together with a power line or arranged closed to the line. | Improve the installation environment to avoid application of a surge from a power line. |
| | The FG (frame ground) potential varies because of influence from machines on the servo motor side, such as a welder. | Check the grounding state (non-grounding, incomplete grounding, etc.) of the motor-side machines. | Correctly ground the machines on the motor side. |
| | Driver's pulse counting error due to noise interference | Check if there is noise interference on the signal line from the sensor. | Take countermeasures against noise for the sensor wiring. |
| | Failure due to excessive vibration shocks applied to the sensor | Check that no vibration occurs from the machine. Also check the mounting conditions of the servo motor (mounting surface accuracy, fixing state, core dislocation). | Reduce vibration from the machine. Improve the mounting conditions of the servo motor. |
| | Sensor malfunction | Compare with a normal one. | Replace the servo motor. |
| | Driver malfunction (Pulse count does not change.) | Compare with a normal one. | Replace the driver. |
| | Rotation data read error in the host equipment | Check the error detection part of the host equipment. | Fix the error detection part so that it works properly. |
| | | Check if parity data and other data is checked by the host equipment. | Perform a parity check of rotation data or check other data. |
| Check that there is no noise interference in the cable between the driver and host equipment. | | Take countermeasures against noise and execute a parity check for rotation data or check the other data again. | |

| Classification/Trouble | Cause | Check method | Corrective action | |
|--|---|--|---|---|
| Overtravel function does not work properly | The forward-rotation drive disable input/reverse-rotation drive disable input signals are malfunctioning. | Check the voltage of common power supply (+COM) for digital input. | Correct the voltage of common power supply for digital input (+COM). | |
| | | Make sure that the voltage of common power supply (+COM) for digital input does not fluctuate. | Eliminate fluctuations in the voltage of common power supply for digital input (+COM). | |
| | | Make sure that operation of the limit switch for overtravel is not unstable. | Stabilize the limit switch operation for overtravel. | |
| | | Check the wiring of the limit switch for overtravel (damaged cable, tightening condition of screws). | Properly connect the limit switch for overtravel. | |
| | Erroneous allocation of forward-rotation drive disable input/reverse-rotation drive disable input signals to I/O inputs IN1 to IN8 (data IDs 100 to 107). | Check whether the forward-rotation drive disable input signals are allocated to I/O inputs IN1 to IN8 (data IDs 100 to 107). | If other signals are already assigned, then allocate the forward-rotation drive disable input signals. | |
| | | Check whether the reverse-rotation drive disable input signals are allocated to I/O inputs IN1 to IN8 (data IDs 100 to 107). | If other signals are already assigned, then allocate the reverse-rotation drive disable input signals. | |
| | Inadequate position of the limit switch or dog for overtravel prevention. | - | Install the limit switch or dog for overtravel prevention in an appropriate position. | |
| | Position of the limit switch for overtravel is too limited for coasting distance. | - | Install the limit switch for overtravel prevention in an appropriate position. | |
| | Position Error (Without Alarm) | Noise is superimposed on the sensor cable. | Check the sensor cable specifications. Review the cable specifications. Use a twisted pair cable or twisted pair common shield cable (core wire: 0.12 mm ² or more, tinned annealed copper twisted wire). | Review the cable specifications. |
| | | | Check whether there is any pinching of sensor cable or breakage in shield. | Replace the sensor cable and alter the sensor cable layout environment. |
| Check if a ground is used as both the control power supply ground (safety voltage GND) and the frame ground (FG) by a host system. | | | Separate the control power supply ground and the frame ground (FG). | |
| Check the termination of the sensor cable shield. | | | Change the termination to the control power supply ground when the shield is terminated to the frame ground (FG). | |
| Noise is superimposed because the sensor cable is too long. | | Check the length of the sensor cable. | Use a sensor cable of 10 m or less. | |
| The motor FG line and the frame ground are not connected. | | Check the motor wiring. | Make the right connection. | |

| Classification/Trouble | Cause | Check method | Corrective action |
|---|--|--|---|
| Position Error. (Without Alarm) | There is excessive noise interference on the sensor cable. | Check to make sure that the sensor cable is not bundled together with a power line or arranged closed to the line. | Improve the installation environment to avoid application of a surge from a power line. |
| | The FG (frame ground) potential varies because of influence from machines on the servo motor side, such as the welder. | Check the grounding state (non-grounding, incomplete grounding, etc.) of the motor-side machines. | Properly ground the motor-side machines to prevent shunt currents from flowing into the PG and FG sides. |
| | Driver's pulse counting error due to noise interference | Check if there is noise interference on the signal line from the sensor. | Take countermeasures against noise for the sensor wiring. |
| | Failure due to excessive vibration shocks applied to the sensor | Check that no vibration occurs from the machine. Also check the mounting conditions of the servo motor (mounting surface accuracy, fixing state, core dislocation). | Reduce vibration from the machine. Improve the mounting conditions of the servo motor. |
| | Unsecured coupling between the machine and servo motor | Check if a position error occurs at the coupling between the machine and servo motor. | Secure the coupling between the machine and servo motor. |
| | Noise is superimposed on the I/O cable. | Check the I/O cable specifications. Review the cable specifications. Use a twisted pair cable or twisted pair common shield cable (core wire: 0.12 mm ² or more, tinned annealed copper twisted wire). | Review the cable specifications. |
| | | Check if a ground is used as both the control power supply ground (safety voltage GND) and the frame ground (FG) by a host system. | Separate the control power supply ground and the frame ground (FG). |
| | | Check the termination of the I/O cable shield. | Change the termination to the control power supply ground when the shield is terminated to the frame ground (FG). |
| | Noise is superimposed because of the excessive length of I/O cable. | Check the length of the I/O cable. | Use an I/O cable of 3 m or less. |
| | Encoder malfunction (Pulse count does not change.) | Compare with a normally operating product. | Replace the servo motor. |
| Driver malfunction | Compare with a normally operating product. | Replace the driver. | |
| Overheating of Motor | Ambient temperature too high | Measure the ambient temperature of the servo motor. | Reduce the ambient temperature to 50°C or less. |
| | The servo motor surface is dirty. | Visually check the dirt on the surface. | Clean the dirt, dust, and oil on the surface. |
| | The servo motor is overloaded. | Check the load status with monitor. | If overloaded, reduce the load or replace it with a larger capacity driver or servo motor. |
| Motor Runs Slowly Even with Speed Zero at Speed Control Mode. <Parameter> | The motor is affected by the offset voltage. | Check the ID 31 "Control Mode" and the ID 75 "Select Speed Command." | Set analog input offset. Use the Analog Input Zero Clamp function. |

| Classification/Trouble | Cause | Check method | Corrective action |
|---|--|--|---|
| Unstable Rotation <Adjustment> | Servo gain adjustment is not proper. (Position control) | Check using the graph display function of the monitor or controller. | Increase the setting value of ID 50 "Position Loop Proportional Gain 1." Decrease the ID 53 "Low-pass Filter Cutoff Frequency." Again, increase the setting value of ID 50 "Position Loop Proportional Gain 1." |
| | Speed and position command are not stable. | Check using the graph display function of the monitor or controller. | Check the motor movement. Review the wiring, connector contact failure and controller. |
| Unstable Rotation <Wiring> | Input signals to CN1 (I/O) are chattering. (1) Servo-ON input (2) Forward-direction limit/reverse-direction limit input signal (3) Deviation reset input (4) Pulse input disable command, etc. | Check the waveform of the signals from the host controller via the ID 21 "I/O Status" or an oscilloscope. | Correct the wiring and connection so that each signal turns on and off normally. Check the controller's operation. |
| | Noise is on the speed command. | — | Use a shield cable. Arrange the power line and a signal line in separate ducts at least 30 cm apart. |
| | Slip of offset. (Analog input) | — | Measure the voltage between the analog command input of CN1 (I/O) and GND using a tester and an oscilloscope. |
| | Noise is superimposed onto a command pulse. | — | Use a shield cable. Arrange a power line and a signal line in separate ducts at least 30 cm apart. |
| Positioning Accuracy Is Poor <System> | Erroneous position command. Or erroneous count of command pulse. (command pulse amount) | Repeat reciprocal movement with the same distance to count the feedback pulse in the position monitor of the designated application. | When the count values vary, check the wiring of the controller or the wiring for command pulse. |
| | The in-position signal is captured right at the edge. | - | Make the controller capture the in-position signal not at the edge but with some time allowance. |
| | Shape or width of the command pulse is not per the specifications. (Erroneous count) | Observe the waveform on an oscilloscope. | If the shape of the command pulse is broken or narrowed, review the pulse generating circuit. Review the noise countermeasures. |
| | Noise is superimposed onto the deviation reset input. (Erroneous input) | - | Take noise countermeasures for the digital input power supply or check the I/O cable specifications. |
| Positioning Accuracy Is Poor <Adjustment> | Position loop proportional gain is small. | - | Check the position error amount using the analog monitor or application software. Check the loop gain by increasing the setting value of the ID 50 "Position Loop Proportional Gain 1" within the range where oscillation does not occur. Decrease the ID 53 "Low-pass Filter Cutoff Frequency" and increase the ID 50 "Position Loop Proportional Gain 1." |
| Positioning Accuracy Is Poor <Parameter> | The setting of the positioning completion range is too large. | - | Decrease the setting value of the ID 77 "In-Position Signal Range" to a value in the range free from chattering. |
| | The command pulse frequency exceeded the maximum allowable frequency (500 kHz, 200 kHz). | - | Decrease the command pulse frequency. Change the pulse input resolutions of ID 121 and ID 122. |
| | Pulse Input Signal Resolution Denominator is incorrect | - | Check whether repeatability is the same. |


| Classification/Trouble | Cause | Check method | Corrective action |
|--|--|--|--|
| Positioning Accuracy Is Poor <Wiring> | Input signals to CN1 (I/O) are chattering. (1) Servo-ON input (2) Positive-/ Negative-rotation drive disable input (3) Deviation reset input (4) Pulse input disable command, etc. | Check the signal waveform via the ID 21 "I/O Status" or an oscilloscope. | Correct the wiring and connection so that each signal turns on and off normally. Reexamine the operation of a higher-level device. |
| Positioning Accuracy Is Poor <Installation> | Load inertia is large. | Check operating waveforms with the monitor. | Check the overshoot at stopping using observed waveforms. If no improvement is obtained after adjusting servo gains, increase the driver and motor capacity. |
| Origin Point Slips <System> | The origin return creep rate is high. | - | Reduce the origin return creep rate or extend the detection range of the origin sensor. |
| Origin Point Slips <Wiring> | Chattering of the limit switch and dog output. | - | Check the input signal of the used sensor with an oscilloscope. Review the wiring around the sensor and take noise reduction measures, etc. |
| | Noise is superposed on the I/O cable. | - | Take measures including noise reduction (installation of noise filter, insertion of ferrite core), shielding of I/O cable, use of twist-pair line, and separation of a signal line and a power line. |
| Abnormal Motor Noise or Vibration <Wiring> | Noise is superimposed on the speed command. | - | Using an oscilloscope, measure the noise between the analog command input of CN1 (I/O) and the GND. Take measures including noise reduction (installation of noise filter, insertion of ferrite core), shielding of I/O cable, use of twist-pair line, and separation of a signal line and a power line. |
| Abnormal Motor Noise or Vibration <Adjustment> | Servo gain is set high. | - | Reduce the servo gain. -ID 51 "Speed Loop Proportional Gain 1" -ID 52 "Speed Loop Integral Gain 1" |
| Abnormal Motor Noise or Vibration <Installation> | Resonance between a machine and the motor | Check with the analog monitor or application software. | Perform readjustment by setting the ID 53 "Low-pass Filter Cutoff Frequency." Check for any machine oscillation on the analog monitor or application software. If there is oscillation, then set the ID 54 "Notch Filter Center Frequency 1" and ID 55 "Notch Filter Attenuation 1." |
| | Motor bearing | - | Run the motor with no load and check the noise and vibration around the bearing. Replace the motor and check. |
| | Electromagnetic sound, gear sound, rubbing sound at braking, hub sound, rubbing sound from the encoder | - | Run the motor with no load and check. Replace the motor and check. |

| Classification/Trouble | Cause | Check method | Corrective action |
|---|--|--|--|
| Overshoot/Undershoot Overheating of the Motor (Motor Burn- Out) | Servo gain adjustment is not proper. | Check with the analog monitor or application software. | Re-adjust the servo gain. |
| | Load inertia is large. | Check with the analog monitor or application software. | Increase the driver and motor and lower the inertia ratio. Use a gear reducer. |
| | Looseness or slip of the equipment (machine) | - | Review the mounting of the equipment (machine). |
| | Ambient temperature and environment | - | Install the cooling fan when the operating temperature exceeds a specified value. |
| | The cooling fan stops. The air intake of the fan is dirty. | - | Inspect the cooling fan of the equipment. |
| | Mismatch between the driver and motor | - | Check the type of the driver and the motor. Select a correct combination of driver and motor by referring to the instruction manual or catalogue. |
| | Motor bearing failure | - | Turn the power off and turn the shaft of the motor independently to check if there is any rumbling sound. If there is such a noise, replace the motor. |
| | The electromagnetic brake stays on. | Check the motor cable. | Check if there is an error in the connection. Replace the driver. |
| Overshoot/Undershoot Overheating of the Motor (Motor Burn- Out) | Motor failure (oil, water, etc.) | - | Avoid high temperature, humidity, oil, dust, and iron powders. |
| | Motor has been turned by external force while dynamic brake is active. | - | Check the operating pattern, use conditions, and working conditions, and avoid this kind of operation. |
| Motor Speed Does Not Reach the Set Speed Motor Rotation Quantity (Move Distance) Is Too Large or Small | Analog input scale values such as speed command are incorrect. Speed command input gain is not correct. The main circuit drive power supply voltage decreased. | - | Check the related parameters. •ID 130 "Analog Input Signal Speed Conversion Scale" •ID 131 "Analog Input Current Speed Conversion Scale" |
| | Position loop gain is low. | - | Increase the setting value of ID 50 "Position Loop Proportional Gain 1" little by little. |
| Parameter Returns to the Previous Value | No parameters were saved in nonvolatile memory prior to power-off of the driver. | - | Set "1" to ID 17 "Parameters Save" to save parameters in the nonvolatile memory. |

19. List of Parameters

Parameters are defined on the basis of data ID (hereafter referred to as "ID") numbers. The data length and writable data to save on each parameter are predetermined for each parameter when storing data on a nonvolatile memory so that information is described in a list along with the parameter contents.

| Symbol | Meaning |
|-----------|----------------------------|
| ID | Data ID number |
| L | Data length (bytes) |
| W | Writable or not writable |
| M | Save to nonvolatile memory |


Caution

Parameter values set beyond the setting range may cause trouble during operation and lead to unexpected operation.
Be sure to set values within the setting range.

19.1. Communication Parameters

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|----|---------------------|---|---|---|---|-----------------|-----------------------|-------------|
| 1 | Device Code | 2 | x | o | [Do not change.] 1: Servo Motor Driver | 1 | - | DEC |
| 2 | Product Code | 2 | x | o | [Do not change.] Driver model | 8811 | - | DEC |
| 3 | Software Revision | 2 | x | o | [Do not change.] Driver software revision | - | - | DEC |
| 4 | Serial Number | 4 | x | o | [Do not change.] Serial number | - | - | - |
| 5 | MAC-ID | 1 | o | o | Media access control ID Used for SV-NET communication. Set unique values within the same network. | 63 | 1-63 | DEC |
| 6 | Communication Speed | 2 | o | o | <p>Sets SV-NET/RS232/RS485 communication speed.</p> <p>1. Bit3-0: SV-NET baud rate 0: 125 kbps 2: 500 kbps 1: 250 kbps 4: 1 Mbps (factory initial value)</p> <p>2. Bit7-4: RS232 baud rate (Option manufacturers use.) 0: 115200 bps (factory initial value) 1: 9600 bps 4: 56000 bps 2: 19200 bps 5: 57600 bps 3: 38400 bps 6: 115200 bps</p> <p>3. Bit11-8: RS485(ModbusRTU) baud rate 0: 115200 bps (factory initial value) 1: 9600 bps 4: 56000 bps 2: 19200 bps 5: 57600 bps 3: 38400 bps 6: 115200 bps</p> <p>4. Bit15-12: Set ModbusRTU character. 0: No parity, Stop bit 1 (factory initial value) 1: No parity, Stop bit 2 2: Even parity, Stop bit 1 3: Even parity, Stop bit 2 4: Odd parity, Stop bit 1 5: Odd parity, Stop bit 2</p> <p>Example: When setting SV-NET = 1 Mbps, RS232 = 56000 bps, RS485 = 19200 bps, Modbus to even parity, stop bit 1: 0x2244.</p> <p>When communication errors occur frequently due to the environment or the state of the cables, set a low communication speed. Change the setting, save the parameter, and then turn the power off and then on again to enable the parameter.</p> | 0x0004 | 0x0000 - 0x5664 | HEX |

19.2. Parameters for Initializing and Saving Parameters

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|----|------------------|---|---|---|--|-----------------|---------------|-------------|
| 16 | Parameters init. | 2 | ○ | × | If "1" is set, all parameters are initialized by the initial value table in the driver. And not necessarily set to the factory initial settings. Do not use in non-standard models. | 0 | 0-1 | DEC |
| 17 | Parameters Save | 1 | ○ | × | If "1" is set, all parameters are saved to the nonvolatile memory. Perform this after confirming the servo is OFF. | 0 | 0-1 | DEC |
| 18 | Program Code | 2 | × | × | [Do not change.] Built-in software identification code | - | - | HEX |


19.3. Status Parameters

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|----|--------------------|---|---|---|--|-----------------|---------------|-------------|
| 20 | Servo Status | 4 | × | × | Each Bit becomes ON depending on the driver status. Bit 0: During Servo ON Bit 1: During profile operation Bit 2: In-position Bit 3: Alarm occurring Bit 4: Arrival at forward limit Bit 5: Arrival at reverse limit Bit 6: Torque limit Bit 7: Speed limit Bit 8: Position excessive deviation Bit 9: Servo ready Bit 10: During homing Bit 11: During switching to second gain Bit 12: Backup battery voltage low Bit 13: Drive power cutoff Bit 14: Stop speed status Bit 16: Mechanical brake output signal Bit 20: Alarm bit code 0 signal (Ab0) Bit 21: Alarm bit code 1 signal (Ab1) Bit 22: Alarm bit code 2 signal (Ab2) Bit 24: Arrival at profile command target position | - | - | - |
| 21 | I/O status display | 2 | × | × | When driver's I/O input/output is ON, each Bit becomes ON. Bit 0,1,2 - 7 : Input 1,2 - 8 status Bit 8,9,10,11,12: Output 1,2,3,4,5 status | - | - | - |
| 22 | Alarm Code | 1 | × | × | Displays current alarm code. (Decimal numbers) | - | - | - |
| 23 | Alarm History-1 | 4 | × | ○ | Displays alarm history 1 to 4. (Decimal numbers) Bit 0 to 7: History 1 Bit 8 to 15: History 2 Bit 16 to 23: History 3 Bit 24 to 31: History 4 | - | - | - |
| 24 | Alarm History-2 | 4 | × | ○ | Displays alarm history 5 to 8. (Decimal numbers) Bit 0 to 7: History 5 Bit 8 to 15: History 6 Bit 16 to 23: History 7 Bit 24 to 31: History 8 | - | - | - |

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|----|---|---|---|---|---|-----------------|-----------------------|-------------|
| 25 | Select Alarm Occurrence Information to be Displayed | 2 | ○ | × | <p>Allows checking detailed information from the time the alarm occurred.</p> <p>Setting the history number and information number of the alarm that you want to check will update the content of ID26 "Alarm Occurrence Information."</p> <p>•Bit 7-0 = Alarm information code 00: Alarm code 01: Month and day of occurrence [BCD] Note * The year is not displayed. 02: Hour and minute of occurrence [BCD] Note * The seconds are not displayed. 03: Total driver power ON time [minutes] 04: Servo Status (ID 20) 05: Feedback current [0.01 A] (ID 42) 06: Feedback speed [rpm] (ID 41) 07: Feedback position [pulse] (ID 40) 08: Drive power supply voltage [0.1 V] (ID 161) 09: Driver temperature [0.1°C] (ID 160) 0A: Overload monitor [0.1%] (ID 159) 0B: Command overload monitor [0.1%]</p> <p>•Bit 15-8= Alarm history code 00: History 1(Latest), 01: History 2 - 07: History 8</p> <p>Example: To see the feedback speed when history 4 alarm occurred, set 0x0306.</p> <p>Supplement</p> <p>Set the date (ID240) and time (ID241) in advance.</p> | - | 0x0000 - 0x070B | HEX |
| 26 | Alarm Occurrence Information | 4 | × | × | Displays the data specified with ID 25 "Select Alarm Occurrence Information to be Displayed." | - | - | - |
| 29 | Warning Status Display | 2 | × | × | <p>Bit 0: Drive power supply voltage low warning Bit 1: Backup battery voltage low warning (only for the absolute encoder) Bit 2: (Reserved) Bit 3: Actual current overload warning Bit 4: Command current overload warning Bit 5: Overspeed warning Bit 6: Multi-rotation warning Bit 7: Excess position deviation warning Bit 8: Driver temperature warning Bit 9: External encoder count warning Bit 10: External encoder position error warning Bit 11: Excessive regeneration capacity warning Bit 12 to 15: (Reserved)</p> <p>! Important</p> <p>When an alarm is generated, Bit 3 to Bit 11 for Warning Status Display are fixed at the status they were when the alarm was generated. They are cleared by resetting the alarm.</p> | - | - | - |

19.4. Control Command Parameters

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|----|-----------------|---|---|---|---|-----------------|---------------------------------|-------------|
| 30 | Servo Command | 2 | ○ | × | <p>Sends the control command to the driver by setting each Bit to ON.</p> <ul style="list-style-type: none"> Bit 0: Servo ON Bit 1: Profile Operation Enabled Bit 2: Deviation Reset Bit 3: Reset Alarm Bit 4: Hard Stop Bit 5: Smooth Stop Bit 6: (Reserved) Bit 7: Acceleration/Deceleration Enabled Bit 8: Analog Input 0-point Adjustment Command Bit 9: Switch to second control mode Bit 10: Second Current Limit Switch Bit 11: Second Gain Switch Bit 12: Smart ABS Sensor Alarm Reset Bit 13: Origin Detection Notification Bit 14: Current Position Reset Bit 15: Smart ABS Sensor Alarm & Multi-rotation Reset <div style="border: 1px solid black; padding: 5px; margin-top: 10px; display: inline-block;"> Important </div> <p>Set reserved Bits to "0."</p> | 0x0000 | 0x0000 – 0xFFBF | HEX |
| 31 | Control Mode | 1 | ○ | ○ | <p>Sets driver's control mode.</p> <ul style="list-style-type: none"> 0: No Control Mode (Servo OFF) 1: Position Control Mode 2: Velocity Control Mode 3: Current Control Mode 4: Homing Control Mode 5: Inertia Estimation Mode 6: Friction Correction Torque Estimation Mode 14: Simplified Control Mode | 0 | 0 to 6 or 14 | DEC |
| 32 | Target Position | 4 | ○ | ○ | Sets a target position in profile operation. [pulse] | 0 | -2147483648 to 2147483647 | DEC |
| 33 | Target Velocity | 2 | ○ | ○ | Sets a target velocity in profile operation. [rpm] | 100 | 0–10000 | DEC |
| 34 | Acceleration | 2 | ○ | ○ | Sets acceleration in speed control and profile operation. [10 rpm/sec] | 1000 | 0–65535 | DEC |
| 35 | Deceleration | 2 | ○ | ○ | Sets deceleration at "Smooth Stop" (ID30 Bit5 ON) in speed control and profile operation. [10 rpm/sec] | 1000 | 0–65535 | DEC |



| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|----|----------------------------|---|---|---|--|-----------------|--|-------------|
| 36 | Real-time Command Position | 4 | ○ | ○ | <p>Real-time position command [pulse] Use when giving a direct position command when in position control Control Mode (ID 31=1).</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;">  Caution </div> <p>Updated automatically for position commands generated inside the driver when operating a servo message through profile operation or SV-NET. When giving a position command with this parameter, note that there is the possibility that the motor axis may rapidly accelerate if there is a large deviation.</p> | 0 | -2147483648 – 2147483647 | DEC |
| 37 | Real-time Command Speed | 2 | ○ | ○ | <p>Real-time speed command [rpm] Sets the current command in speed control "Control Mode" (ID31 = 2). When ID76 "Select Torque Command" is "3," this setting becomes the speed limit value. When ID76 "Select Torque Command" is "3," this setting becomes the speed limit value.</p> | 0 | -10000 – 10000 | DEC |
| 38 | Real-time Command Current | 2 | ○ | ○ | <p>Real-time current command [0.01 A] Sets current command in current control "Control Mode" (ID31 = 3).</p> | 0 | - (Motor max. current)to + (Motor max. current) | DEC |
| 39 | Position Reset Value | 4 | ○ | ○ | <p>When "1" is set to Bit 14 "Current Position Reset" in the ID 30 "Servo Command," the ID 40 "Feedback Position" is reset to this value.</p> | 0 | -2147483648 – 2147483647 | DEC |

19.5. Servo Feedback Parameters

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|----|-------------------|---|---|---|--|-----------------|---------------|-------------|
| 40 | Feedback Position | 4 | x | x | Current position [pulse] Outputs the current position used for position control. This value is derived from position data read from the motor sensor and processed using parameters such as ID 140 "Abs Mode" and ID 72 "Reference Direction." In the control by external encoder(ID 73 "Select Position Feedback" =1), this value is a processed value from position information of external encoder. | - | - | - |
| 41 | Feedback Speed | 2 | x | x | Current speed [rpm] Displays the motor axis speed. | - | - | - |
| 42 | Feedback Current | 2 | x | x | Motor current [0.01 A] Displays the motor current sensing value (q-axis current). | - | - | - |
| 43 | Feedback PVC | 6 | x | x | Displays the lower order 16 bits for feedback position [pulse], feedback speed [rpm], and feedback current [0.01 A] in 6 bytes. Cannot be displayed on the setting panel. | - | - | - |
| 44 | Feedback SVC | 6 | x | x | Displays the lower order 16 bits for feedback position [pulse] (however, for data before processing in ID 72, "Reference Direction"), feedback speed [rpm], and feedback current [0.01 A] in 6 bytes. Cannot be displayed on the setting panel. | - | - | - |

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|----|---------------------------|---|---|---|---|-----------------|---------------|-------------|
| 45 | Sensor Position 1 | 4 | x | x | <p>Displays position data captured by the sensor.</p> <p>[Pulse]</p> <p>[Brushless resolver 1X-BRX]</p> <p>The position data per double axial angle 1X of the resolver is displayed at a resolution of 8192 pulses.</p> <p>[Incremental encoder wiring-saving INC]</p> <p>Displays the 16-bit counter (counted multiplied by 4 from the sensor resolution) that counts the sensor A/B phases.</p> <p>[Serial encoder 17, 23Bit-ABS/INC]</p> <p>Displays the one-rotation absolute value position data read from the sensor.</p> | - | - | - |
| 46 | Sensor Position 2 | 4 | x | x | <p>Displays position data captured by the sensor.</p> <p>[Pulse]</p> <p>[Brushless resolver 1X-BRX]</p> <p>The position data per double axial angle 1X of the resolver is displayed at a resolution of 2048 pulses. (Same as ID47 "Sensor Position 3.")</p> <p>[Incremental encoder wiring-saving INC]</p> <p>Displays the value of the ID 45 "Sensor Position 1" at the moment of detection of sensor Z-phase.</p> <p>[Serial encoder 17, 23Bit-ABS]</p> <p>Displays the multi-rotation data read from the sensor.</p> <p>[Serial encoder 17, 23Bit-INC]</p> <p>Displays the one-rotation incremental data read from the sensor.</p> | - | - | - |
| 47 | Sensor Position 3 | 4 | x | x | <p>Motor Sensor Counter [pulse]</p> <p>The value taken from motor sensor is displayed as given in the 32 bit counter.</p> <p>This is the value of ID40 "Feedback Position" before it is processed.</p> | -- | -- | -- |
| 48 | External Encoder Position | 4 | x | x | <p>External encoder counter [pulse]</p> <p>Displays a value captured by external encoder as a 32 bit counter of which "0" is the position when the power is turned on.</p> | -- | -- | -- |
| 49 | Position Deviation | 4 | x | x | <p>Position deviation [pulse]</p> <p>Displays the position deviation during position control.</p> <p>Position deviation = Position command (*1) - Current Position (*2)</p> <p>*1: ID 36 "Real-time Command Position"</p> <p>*2: ID 40 "Feedback Position"</p> | -- | -- | -- |

19.6. Servo Gain Parameters

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|----|-----------------------------------|---|---|---|---|-------------------------------------|-------------------------|-------------|
| 50 | Position Loop Proportional Gain 1 | 2 | ○ | ○ | Position loop proportional gain 1 Kp1 *1 [rad/s] | 50 | 0-799 | DEC |
| 51 | Speed Loop Proportional Gain 1 | 2 | ○ | ○ | Speed loop proportional gain 1 Kv1 *1 [rad/s] | 200 | 0-2000 | DEC |
| 52 | Speed Loop Integral Gain 1 | 2 | ○ | ○ | Speed loop integral gain 1 Ki1 [1/s] *1 | 50 | 0-2000 | DEC |
| 53 | Low-pass Filter Cutoff Frequency | 2 | ○ | ○ | Low-pass Filter Cutoff Frequency [Hz] 0: Low-pass filter disabled 1 to 1000: Cutoff frequency setting | For resolver: 600 Other: 1000 | 0-1000 | DEC |
| 54 | Notch Filter Center Frequency 1 | 2 | ○ | ○ | Notch filter1 • Center Frequency [Hz] 0, 1000: Notch filter 1 disabled 1 to 999: Center Frequency Setting | 0 | 0-1000 | DEC |
| 55 | Notch Filter Attenuation 1 | 2 | ○ | ○ | • Attenuation 0: Notch filter 1 disabled <Attenuation targets> 30: -3 dB, 50: -5 dB, 75: -12 dB, 87: -18 dB  Caution Oscillation may occur if the center frequency is too low. Normally, use it with a setting of 50 or more. If the attenuation is too great, there may be oscillations. It should normally be set to no more than 30. | 0 | 0-100 | DEC |
| 56 | Current Loop Proportional Gain | 2 | ○ | ○ | Current loop proportional gain [rad/s] *2 | 4000 | 0-13000 | DEC |
| 57 | Current Loop Integral Gain | 2 | ○ | ○ | Current loop proportional gain [1/s] *2 | 700 | 0-10000 | DEC |
| 58 | Phase-advance Gain | 2 | ○ | ○ | Phase-advance Gain *2 | 40 | 0-512 | DEC |
| 59 | Load Inertia | 4 | ○ | ○ | [g·cm ²] *3 | 0 | 0-50000 | DEC |
| 60 | Position Loop Proportional Gain 2 | 2 | ○ | ○ | Position loop proportional gain 2 Kp2 *1 [rad/s] | 50 | 0-799 | DEC |
| 61 | Speed Loop Proportional Gain 2 | 2 | ○ | ○ | Speed loop proportional gain 2 Kv1 *1 [rad/s] | 150 | 0-2000 | DEC |
| 62 | Speed Loop Integral Gain 2 | 2 | ○ | ○ | Speed loop integral gain 2 Ki2 [1/s] *1 | 50 | 0-2000 | DEC |
| 63 | Notch Filter Center Frequency 2 | 2 | ○ | ○ | Notch filter 2 • Center frequency [Hz] 0, 1000: Notch filter 2 disabled 1 to 999: Center frequency setting • Attenuation 0: Notch filter 2 disabled | 0 | 0-1000 | DEC |
| 64 | Notch Filter Attenuation 2 | 2 | ○ | ○ | <Attenuation targets> 30: -3 dB, 50: -5 dB, 75: -12 dB, 87: -18 dB  Caution Oscillation may occur if the center frequency is too low. Normally, use it with a setting of 50 or more. If the attenuation is too great, there may be oscillations. It should normally be set to no more than 30. | 0 | 0-100 | DEC |
| 65 | Forward Current Limit 2 | 2 | ○ | ○ | Forward-rotation direction 2nd current limit [0.01 A] Enabled when 2nd current limit is selected by ID 30 Bit 10 or I/O input. | Motor max. current | 0 to Motor max. current | DEC |
| 66 | Reverse Current Limit 2 | 2 | ○ | ○ | Reverse-rotation direction 2nd current limit [0.01 A] Enabled when 2nd current limit is selected by ID 30 Bit 10 or I/O input. Enabled when 2nd current limit is selected by ID30 Bit 10 or I/O input. | Motor max. current | 0 to Motor max. current | DEC |
| 68 | Position Feed-forward Gain | 2 | ○ | ○ | Position Feed-forward Gain [%] | 0 | 0-100 | DEC |

*1 Kp, Kv, and Ki units are the units when the load inertia is set correctly.

*2 These are set automatically by the auto-tuning function of the driver. Normally these should not be changed.

*3 The setting range is 0 to 3000 on software Ver. 4.30 and older versions.

19.7. Parameters for Setting Control Functions

| ID | Name | L | W | M | Description | Factory setting | Setting range | Display |
|----|----------------|---|---|---|---|-----------------|---------------|---------|
| 69 | Control Switch | 2 | ○ | ○ | <p>Bit 0 Resets position deviation when servo OFF. 0: Disabled (Maintains position deviation value.) 1: Enabled (The value is cleared to 0 when servo OFF.)</p> <p>Bit 1 Automatically clears the operation permission flag (ID 30 "Servo Command" Bit 1) when profile operation is completed. 0: Disabled 1: Enabled</p> <p>Bit 2 Selects command status when control mode is changed. 0: Resets command value. (Speed/current control = 0, Position control = Current position) 1: Maintains current command value. When control mode is changed soon after servo ON and during servo ON, you can select either resetting the command or maintaining the current value when switching from 2nd control mode to the 1st. Position control is performed only in profile operation.</p> <p>Bit 3 Speed calculation filter settings This setting only supports 17-bit sensors 0: Speed calculation filter 1 (The setting for fast response during low speed) 1: Speed calculation filter 2 (The setting for high stability during low speed)</p> <p>Bit 4 Analog input resolution switch function 0: Enabled (Switches to the high resolution circuit automatically during low voltage input) 1: Disabled</p> <p>Bit 5 Sets the acceleration/deceleration in speed control mode. 0: Disabled (Follows ID 30 Servo Command Bit 7 setting.) 1: Enabled ID 30 "Servo Command" Bit 7 setting is normally reset when power is turned off. Set this setting to Enabled to maintain the acceleration/deceleration setting.</p> <p>Bit 6 Selects Z signal output style. 0: Hi when both LEAD/LAG are low. 1: Hi by synchronizing with LEAD Hi. Do not change during motor control.</p> <p>Bit 7 Sets Z signal I/O output 0: Disabled 1: Z signal output from I/Ooutput 5 (OUT5). When 1 is set, the value of the ID 114 "I/O output (OUT5) setting" is ignored.</p> | 0x0001 | 0x0000 - | HEX |

| ID | Name | L | W | M | Description | Factory setting | Setting range | Display |
|----|-----------------------------|---|---|---|--|-----------------|---------------|---------|
| 69 | Control Switch (*Continued) | | | | <p>Bit 8 Output 1 (OUT1) output logic setting 0: Positive logic 1: Negative logic</p> <p>Bit 9 Output 2 (OUT2) output logic setting 0: Positive logic 1: Negative logic</p> <p>Bit 10 Output 3 (OUT3) output logic setting 0: Positive logic 1: Negative logic</p> <p>Bit 11 Output 4 (OUT4) output logic setting 0: Positive logic 1: Negative logic</p> <p>Bit 12 Output 5 (OUT5) output logic setting 0: Positive logic 1: Negative logic</p> <p>Bit 13 Outputs the position pulses of encoder received by driver as they are (unchanged): LEAD/LAG/Z all outputs. 0: Disabled 1: Enabled Enabled only when wiring-saving INC encoder is used.</p> <p>Bit 14 Outputs the position pulses of encoder received by driver as they are (unchanged): Z output only. 0: Disabled 1: Enabled Enabled only when the wiring-saving INC encoder is used.</p> <p>Bit 15 Reverses logic of rotation direction in LEAD/LAG/Z output. 0: Disabled 1: Enabled</p> <p>* Disabled when Bit 13 or 14 is set to 1 (enabled).</p> | | | |

| ID | Name | L | W | M | Description | Factory setting | Setting range | Display |
|----|--------------------------|---|---|---|---|-----------------|-------------------------|---------|
| 72 | Reference Direction | 1 | ○ | ○ | Sets the reference direction of the motor axis. 0: CCW, 1: CW | 0 | 0-1 | DEC |
| 73 | Select Position Feedback | 1 | ○ | ○ | Selects the feedback signal to be used for position control. 0x00: Motor encoder 0x01: External encoder (fully closed control) The external encoder is used as the current position for position control "Control Mode" (ID 31 = 1) (the motor encoder is used when calculating the current speed). | 0x00 | 0x00-0x01 | HEX |
| 74 | Select Position Command | 1 | ○ | ○ | Selects a command signal in position control mode. 0x00: Position command by communication 0x01: Position command by pulse input | 0x00 | 0x00-0x01 | HEX |
| 75 | Select Speed Command | 1 | ○ | ○ | Selects the type of command signal in speed control mode. 0x00: Speed command by communication 0x01: Speed command by analog signal input The analog signal polarity is reversed when Bit 7 is "1." 0x02: Use the analog signal input as speed limit during position/speed control(command in speed control mode is speed command via communication).When ID 88 "Speed Limit" is lower than the speed limit set by this function, ID 88 setting supersedes. | 0x00 | 0x00-0x02 or 0x81 | HEX |

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|----|-----------------------|---|---|---|---|-----------------|-------------------------|-------------|
| 76 | Select Torque Command | 1 | ○ | ○ | <p>Selects the type of command signal in current control mode.</p> <p>0x00: Torque command by communication</p> <p>0x01: Torque command by analog signal input The analog signal polarity is reversed when Bit 7 is "1."</p> <p>0x02: In position/speed/current control, the analog signal input is used as the current limit. (Command during current control is torque command via communication.) The current limit set by this function is common to the forward and reverse directions. Analog input signal accepts voltage for forward-rotation direction only. The reverse rotation direction is handled by setting the limit value to 0. When one of the values of ID 86, 87, 65, 66 is lower than the limit value set by this function, the lower value supersedes other values.</p> <p>0x03: Analog signal input is used as the torque command with speed limit. This function uses analog signal input as the current limit in speed control. And when the sign of the analog signal input is negative, the sign of the speed control is automatically reversed. In speed control, this function can be used as a pseudo torque control with speed limit. This function can be used only in speed control. Set the speed command to ID 37 (Real-time command speed). When you do not want ID 37 to be cleared to 0 at servo ON, set Bit 2 of ID 69 (Control Switch) to "1." When one of the values of ID 86, 87, 65, 66 is lower than the limit value set by this function, the lower value supersedes the other values.</p> | 0x00 | 0x00-0x03 or 0x81 | HEX |

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|----|---|---|---|---|--|-----------------|-------------------------|-------------|
| 77 | In-position (Positioning Completion) Signal Range | 2 | ○ | ○ | [Pulse] Outputs in-position if the position deviation (ID 49) is within this setting value. | By Sensor | 1-32767 | DEC |
| 78 | Smoothing Time 1 | 2 | ○ | ○ | Smoothing time for position command [msec] Setting as 0 will disable Smoothing 1 and 2. Do not change the set value when the servo is ON in position control. | 0 | 0-1638 | DEC |
| 79 | Smoothing Time 2 | 2 | ○ | ○ | Smoothing time for position command [msec] Setting as 0 will disable Smoothing 2. Do not change the set value when the servo is ON in position control. | 0 | 0-1638 | DEC |
| 80 | Select Gain-switch Method | 1 | ○ | ○ | Selects the switching method between 1st gain and 2nd gain of servo gain. ⇒ Refer to □13.6 "Gain-switch Function." 0x00: No switching (fixed to Gain 1) 0x01: Switch by speed command value. 0x02: Switch by motor feedback speed. 0x03: Switch by position deviation value. 0x04: Switch by I/O input command. (Set the gain-switch function with I/O input. OFF: 1st Gain, ON: 2nd Gain) 0x05: Switch by ID 30 "Servo Command" Bit 11. ("0" = 1st Gain, "1" = 2nd Gain) 0x06: Switch after a specified time from motor stop command. 0x07: Switch after motor stop command when the current command is not more than the specified range. 0x09: No switching (fixed to Gain 2) | 0x00 | 0x00-0x07 or 0x09 | HEX |
| 81 | GainChangePoint_H | 2 | ○ | ○ | Gain-switch Point H/L When ID 80 = 1 to 3: When this is equal to or larger than the GainChangePoint_H (*1), Gain 1 is selected, and when this is equal to or lower than GainChangePoint_L (*1), Gain 2 is selected, and when this is in between, the value is interpolated by Gain 1 and Gain 2, and changes smoothly. When ID 80 = 6: When Motor Stop Command (*2) continues for GainSwitchPoint_H [msec], switch to Gain 2, otherwise, Gain 1. | 100 | 0 to 32767 | DEC |
| 82 | GainChangePoint_L | 2 | ○ | ○ | When ID 80 = 7: When Motor Stop Command (*2) continues for GainSwitchPoint_H [msec], and Current Command is equal to or lower than GainSwitchPoint_L [0.01 A], switch to Gain 2, otherwise, Gain 1. *1. ID 80 = 1 to 2 ... Speed [rpm] ID 80 = 3 Position deviation [pulse] *2. In Position Control ... No change in command value In Speed Control ... Speed 0 command | 50 | 0 to 32767 | DEC |

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|----|--------------------------------|---|---|---|--|------------------------------|--------------------------------|-------------|
| 83 | Select Soft Limit | 1 | ○ | ○ | Selects whether to enable or disable the soft limit. 0: Soft limit disabled 1: Soft limit enabled | 0 | 0-1 | DEC |
| 84 | Positive-side Soft Limit | 4 | ○ | ○ | [Pulse] When the current position is beyond the set value in the reverse direction, sets the reverse speed command to 0. This function does not use the position control to manage the stop position. The stop position might be a little beyond the limit position depending on the speed and the gain when it reaches there. | 1073741824 | -2147483648 - 2147483647 | DEC |
| 85 | Reverse-side Soft Limit | 4 | ○ | ○ | [Pulse] When the current position is beyond the set value in the reverse direction, sets the reverse speed command to 0. This function does not use the position control to manage the stop position. The stop position might be a little beyond the limit position depending on the speed and gain when it reaches there. | -1073741824 | -2147483648 - 2147483647 | DEC |
| 86 | Forward-Rotation Current Limit | 2 | ○ | ○ | [0.01 A] Sets the limit value for the current command for the forward-rotation direction. | Motor max. current | 0 to Motor max. current | DEC |
| 87 | Reverse-Rotation Current Limit | 2 | ○ | ○ | [0.01 A] Sets the limit value for the current command for the reverse-rotation direction. | Motor max. current | 0 to Motor max. current | DEC |
| 88 | Speed Limit | 2 | ○ | ○ | [rpm] Sets the limit value for the speed command. Common for both forward and reverse-rotation directions. | Motor maximum rotation speed | 0-10000 | DEC |
| 89 | Speed Limit 2 | 2 | ○ | ○ | [rpm] Sets the limit value for the speed command switched by the gain switch function. Common to both forward and reverse-rotation directions. To add a speed limit switch to the gain switch function, set ID 256 (Special Function Switching 2) Bit 11 to "1." | Motor maximum rotation speed | 0-10000 | DEC |

19.8. Parameters for Setting Homing Operation

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|----|------------------------|---|---|---|---|-----------------|--------------------------------|-------------|
| 90 | Homing Mode | 1 | ○ | ○ | <p>Selects homing method</p> <p>⇒ Refer to □13.4 "Homing Mode."</p> <p>0: Decelerates to stop when detecting origin signal. Then moves to the Z signal detection position and presets the position.</p> <p>1: Stops when detecting thrust, and presets the position there.</p> <p>2: Stops immediately when detecting origin signal, and presets the position there.</p> <p>3: Decelerates to stop when detecting origin signal. Then moves back until the origin signal is released and presets the position.</p> <p>4: Stops when detecting thrust. Then moves to the Z signal detection position and presets the position.</p> | 0 | 0-4 | DEC |
| 91 | Homing Preset Value | 4 | ○ | ○ | <p>Sets position data to be set after homing operation. [pulse]</p> <p>When Bit 3 of ID 209 "Alarm Mask" is not set to 1, set the data to 0x70000000 (1,879,048,192) or smaller by considering the alarm 41 (counter overflow) detection threshold value.</p> | 0 | -2147483648 - 2147483647 | DEC |
| 92 | Homing Start Direction | 1 | ○ | ○ | <p>Sets the rotation direction of the homing operation.</p> <p>0: Forward direction; 1: Reverse direction</p> | 0 | 0-1 | DEC |
| 93 | Homing Speed | 2 | ○ | ○ | Sets the speed from the start of homing to the detection of origin signal. [rpm] | 500 | 0-10000 | DEC |
| 94 | Homing Creep Speed | 2 | ○ | ○ | Sets the speed from the detection of origin signal until stopping at the origin position. [rpm] | 50 | 0-10000 | DEC |
| 95 | Homing Thrust Time | 2 | ○ | ○ | Sets the thrust time in thrust-type homing. [msec] | 1000 | 0-10000 | DEC |
| 96 | Homing Thrust Torque | 2 | ○ | ○ | Sets the thrust torque in thrust-type homing. [0.01 A] | 100 | 0 to Motor max. current | DEC |

19.9. Control Mode Switching Parameters

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|----|---------------------|---|---|---|--|-----------------|-----------------------|-------------|
| 99 | Second Control Mode | 2 | ○ | ○ | <p>Sets the second control mode in control mode switching.</p> <p>⇒ Refer to □15.6 "Control Mode Switching Function."</p> <p>Bit 3 to 0: second control mode</p> <p>0: Disable control mode switch</p> <p>1: Position control</p> <p>2: Speed control</p> <p>3: Current control</p> <p>Bit 15 to 12: Selection of command when switched to second control mode</p> <p>0: Resets command value. (speed and current controls = 0, position control = current position)</p> <p>1: Maintains command value before switching. Position control is performed only in profile operation.</p> <p>Example: When 0x1002 is set, the second control mode is speed control, and for the speed command at the moment the mode is switched to the second control mode, the command value that is set before the switch is continuously used.</p> | 0x0000 | 0x0000 - 0x1003 | HEX |

19.10. Parameters for Setting I/O

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|---------------------------|---|---|---|---|-----------------|--|-------------|
| 100 | I/O Input 1 (IN1) Setting | 1 | ○ | ○ | Sets the function of each I/O input terminal. The factory setting (standard function) varies depending on the input terminal. | 0x00 | 0x00-0x13 or 0x80-0x93 or 0x63 | HEX |
| 101 | I/O Input 2 (IN2) Setting | 1 | ○ | ○ | 0x00: (standard function) - IN1: Servo ON command - IN2: Forward-rotation drive disable command - IN3: Reverse-rotation drive disable command - IN4: Alarm reset command - IN5: Deviation reset command - IN6: External alarm input - IN7: Origin sensor input - IN8: Command pulse count disable command | | | |
| 102 | I/O Input 3 (IN3) Setting | 1 | ○ | ○ | 0x01: Servo ON command 0x02: Forward-rotation drive disable command | | | |
| 103 | I/O Input 4 (IN4) Setting | 1 | ○ | ○ | 0x03: Reverse-rotation drive disable command 0x04: Alarm reset command 0x05: Deviation reset command 0x06: Profile operation permission command 0x07: Origin sensor input | | | |
| 104 | I/O Input 5 (IN5) Setting | 1 | ○ | ○ | 0x08: External alarm input 0x09: Gain-switch command 0x0A (10): Analog input 0-point adjustment command When I/O input changes from ON to OFF, starts 0 point adjustment. | | | |
| 105 | I/O Input 6 (IN6) Setting | 1 | ○ | ○ | 0x0B (11) : Second current limit switch input 0x0C (12): Pulse input disable command 0x0D (13): Homing start command 0x0E (14): Analog input forced-0 command 0x0F (15): Simplified control mode input 1 to 8 0x10 (16): Control mode switch input | | | |
| 106 | I/O Input 7 (IN7) Setting | 1 | ○ | ○ | 0x11 (17): Hard stop 0x12 (18): Smooth stop 0x13 (19): Emergency stop input Normally ON when Bit 7=1 (negative logic) | | | |
| 107 | I/O Input 8 (IN8) Setting | 1 | ○ | ○ | 0x63 (99): Ignore input | | | |

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|-----------------------------|---|---|---|--|---|---|---|
| 110 | I/O Output 1 (OUT1) Setting | 4 | ○ | ○ | <p>Sets the function of each I/O output terminal.</p> <p>The output corresponds to each bit of ID 20 "Servo Status." ⇒Refer to □19.3 "Status Display Parameters."</p> <p>When there is more than one bit at "1" then it is output as OR. And when this is set to 0xFFFFFFFF, any program in the simplified control mode (ID 31 = 14) can use these I/O outputs.</p> | 0x00000008 (Alarm status) | 0x00000000 - 0x01717FFF or 0xFFFFFFFF | <div style="border: 1px solid black; padding: 2px;">HEX</div> |
| 111 | I/O Output 2 (OUT2) Setting | 4 | ○ | ○ | | 0x00000004 (In-position) | | |
| 112 | I/O Output 3 (OUT3) Setting | 4 | ○ | ○ | | 0x00000200 (Servo ready) | | |
| 113 | I/O Output 4 (OUT4) Setting | 4 | ○ | ○ | | 0x00010000 (Mechanical brake output) | | |
| 114 | I/O Output 5 (OUT5) Setting | 4 | ○ | ○ | | 0x00004000 (Stop speed status) | | |
| 117 | I/O filter time | 2 | ○ | ○ | <p>Sets filter time for I/O input (IN1 to IN8). [Setting unit: 200 us]</p> <p>When an input status continues for a specified time or longer, that status will be used.</p> <p>E.g. If the default setting is "5" then the filter time will be 1 ms.</p> <p>Supplement This function works to cancel instantaneous noise, but detection of normal signals will also be delayed. In particular, when an immediate stop or similar is made using the origin signal (I/O input) in a homing operation, you will need to check that there are no changes in the origin point following changes to these parameters. There may also be effects on the stop operation due to the limit signal (I/O input).</p> | 5 | 5 - 32767 | <div style="border: 1px solid black; padding: 2px;">DEC</div> |

19.11. Parameters for Setting Analog Monitor

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|-------------------|---|---|---|---------------------------------|--------------------------|---------------|-------------|
| 118 | Monitor 1 Setting | 2 | ○ | ○ | Analog monitor output 1 setting | 42 (Feedback current) | 1-511 | DEC |
| 119 | Monitor 2 Setting | 2 | ○ | ○ | Analog monitor output 2 setting | 41 (Feedback speed) | 1-511 | DEC |

Outputs the value of the specified parameter ID.

The digital value of specified parameter ID: +32767 to 0 to -32767 corresponds to the monitor output: +10 V to 0 V to -10 V.

Sets monitor gain (magnification) in ID 185 "Monitor 1 Gain", ID186 "Monitor 2 Gain."

[Analog monitor output settings]

ID 118, ID 119: Sets the parameter ID to be monitored. [Setting value: 1–511]

ID 185, ID 186: Sets the monitor voltage magnification. [Setting value: -32767 to 32767]

1 = 1x, 10 = 10x, -10 = 1/10x, -20 = 1/20x (0, -1 are 1x)

[Analog monitor voltage output value calculation]

Analog monitor voltage = [magnification] × (digital value of the specified parameter ID) / 32768 × 10 (V)

[Example of analog monitor settings]

Example: Output ID 41 "Feedback Speed" to Monitor Output 1 with 8x magnification

Set "41" in ID 118 "Monitor 1 Setting" and set "8" in ID 185 "Monitor 1 Gain."

The monitor voltage will be displayed as ±10 V centered around 0 V.


The monitor voltage when ID 41 "Feedback Speed" is 2000 rpm is $8 \times 2000 \times 10 \text{ (V)} / 32768 \approx 4.88 \text{ (V)}$

The monitor voltage when ID 41 "Feedback Speed" is -3000 rpm is $8 \times -3000 \times 10 \text{ (V)} / 32768 \approx -7.32 \text{ (V)}$

19.12. Parameters for Setting Pulses

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|------------------|---|---|---|--|-----------------|--------------------------------------|-------------|
| 120 | Pulse Input Mode | 2 | ○ | ○ | <p>Selects an input type of pulse command input. Enabled when ID 74 "Select Position Command" is set to "1" (pulse input).</p> <div style="border: 1px solid black; border-radius: 10px; padding: 5px; display: inline-block; margin-bottom: 10px;"> Important </div> <p>To reflect changes, turn the power off and then on again after saving the changed settings and parameters.</p> <p>Bit 1, Bit 0: Pulse command mode 00: Forward-rotation pulse/Reverse-rotation pulse 01: Pulse/Rotation direction 02: 90° phase difference 2 phase pulse mode (Used by option manufacturers)</p> <p>Bit 5, Bit 4: Pulse command software filter 00: No filter 01: 500 kHz (allowable frequency) 10: 250 kHz (allowable frequency) 11: 125 kHz (allowable frequency)</p> <p>Bit 7: Pulse command polarity 0: Forward direction 1: Reverse direction</p> | 0x0000 | 0x0000-0x0032 or 0x0080-0x00B2 | HEX |




| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|---|---|---|---|---|-----------------|---------------|-------------|
| 121 | Command Pulse Input Signal Resolution Numerator | 4 | ○ | ○ | <p>When the numerator is n and the denominator is m, the resolution of the command pulse can be calculated as n/m pulses per motor rotation. Example: When ID 121 = 2000 and ID 122 = 3, the motor rotates 3 times at 2000 pulses.</p> <p>Important</p> | 2048 | 1-1073741824 | DEC |
| 122 | Command Pulse Input Signal Resolution Denominator | 2 | ○ | ○ | <p>To reflect changes, turn the power off and then on again after saving the changed settings and parameters.</p> <p>Important</p> <p>When using a high resolution motor sensor such as a 23 bit encoder, set so that the value of [ID 122 x sensor resolution] is no greater than 0x70000000.</p> <p>Supplement</p> <p>Enabled when ID 74 "Select Position Command" is set to "1" for pulse input.</p> | 1 | 1-16384 | DEC |
| 123 | External Encoder Direction | 1 | ○ | ○ | <p>Sets the count direction for the motor sensor in the external encoder.</p> <p>0: Forward-rotation (Motor sensor and count are in the same direction.) 1: Reverse-rotation (Motor sensor and count are in the opposite direction.)</p> <p>Caution</p> <p>Operation in a wrong setting may lead to unexpected behavior such as motor runaway.</p> <p>Important</p> <p>To reflect changes, turn the power off and then on again after saving the changed settings and parameters.</p> | 0 | 0-1 | DEC |
| 124 | External Encoder Resolution | 4 | ○ | ○ | <p>Sets the number of the pulse count for the external encoder for each revolution of the motor. [pulse/rev]</p> <p>Sets the resolution for the external encoder LEAD phase to 4x.</p> <p>This parameter will be used to detect if the external encoder is out of position (alarm code = 68) and for calculating the unit of position loop gain.</p> <p>Important</p> <p>Enabled when "0x01" (external encoder) is assigned to ID 73 "Select Position Feedback".</p> <p>Important</p> <p>To reflect changes, turn the power off and then on again after saving the changed settings and parameters.</p> | 2048 | 1-131072 | DEC |





| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|--------------------------------|---|---|---|---|------------------------------|---|-------------|
| 126 | Sensor Output Division Setting | 2 | ○ | ○ | <p>Set the output resolution of the sensor signal output (pins CN1-44 to 49) in the number of pulses per motor rotation (number of rising edges in LEAD phase). (*1)</p> <p>The maximum possible setting value and factory setting vary depending on the sensor.</p> <p>[Brushless resolver] [1X-BRX (Z signal is output once per motor rotation.)] ⇒ Factory setting 512, max. value 512</p> <p>[Incremental encoder wire-saving INC] ⇒ Maximum value & factory setting, depending on the resolution of the combined sensor.</p> <p>[Serial encoder 17-/23-bit ABS/INC] ⇒ Factory setting 2048, max. value 2048</p> <p>*1. Note that there may be an unstable pulse output from the sensor output signal at the instant this setting changes.</p> <p>* When Bit 13 or 14 of ID 69 "Control Switch" is set to 1 (enabled), this setting is disabled.</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;">  Important </div> <p>To reflect changes, turn the power off and then on again after saving the changed settings and parameters.</p> | See description on the left. | 1 to the maximum value of each sensor (See description in the left.) | DEC |


19.13. Parameters for Setting Analog Input

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|--|---|---|---|---|-----------------|---------------|-------------|
| 130 | Analog Input Speed Conversion Scale Value | 2 | ○ | ○ | <p>Sets speed conversion scale for an analog input value of +10 V. [rpm]</p> <p>Example: When this is set to 6000, the command speed for analog input of +5 V is 3000 rpm.</p> | 6000 | 0-10000 | DEC |
| 131 | Analog input signal current conversion scale value | 2 | ○ | ○ | <p>Sets current conversion scale for an analog input value of 10 V. [0.01 A]</p> <p>Example: When this is set to 500, the command current for analog input of +5 V is 2.5 Arms.</p> | 500 | 0-2400 | DEC |
| 132 | Analog Input Offset | 2 | ○ | ○ | <p>Set automatically by analog input 0 point adjustment command. This should not normally be changed directly.</p> | - | 0-32767 | DEC |
| 133 | Analog Input Zero Clamp | 2 | ○ | ○ | <p>Sets the dead band for analog inputs after zero point adjustment. [0.01 V]</p> <p>Analog input commands within ± of this set value are treated as 0.</p> <p>This setting is effective when analog input signal is unstable due to noise or other factors when the motor stops.</p> | 0 | 0-1000 | DEC |
| 134 | Analog Input Filter | 2 | ○ | ○ | <p>Sets filter (moving average) for analog input signal.</p> <p>0: No averaging 3: Eight averagings 1: Two averagings 4: Sixteen averagings 2: Four averagings</p> <p>Analog inputs are read on a 50 μs cycle.</p> <p>This setting is effective when analog input signal is unstable due to noise or other factors.</p> | 0 | 0-4 | DEC |






19.14. Special Servo Parameters

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|----------------------------|---|---|---|--|-----------------|--------------------------------|-------------|
| 140 | Abs Mode | 2 | ○ | ○ | <p>Sets the absolute value display mode for using the ABS sensor.</p> <p>0: Incremental mode The position where the power was turned ON is counted from "0" and backup battery-related alarms are ignored.</p> <p>1: Absolute mode The ABS sensor controls the absolute position. The current position information is maintained after the power is turned OFF.</p> <p>[Factory settings] [17/23 Bit ABS] ⇒ 1 [Brushless resolver] [17/23 Bit INC] [Wiring-saving INC] ⇒ 0</p> <div style="border: 1px solid black; padding: 2px; display: inline-block; text-align: center;">  Caution </div> <p>"1" is not allowed except for the ABS sensor.</p> | - | 0-1 | DEC |
| 141 | Special Function Switching | 2 | ○ | ○ | <p>Makes special setting of servo functions. Do not change these settings during normal use.</p> <p>Bit 2/Bit 1: Sets the communication protocol for CN5 and CN6. 00: SV-NET enabled 01: RS485 (Tamagawa Format) enabled 10: RS485 (ModbusRTU Format) enabled Example: ModbusRTU Format is enabled, 0x0004</p> <p>Bit 12: PWM carrier frequency setting 0: 10 kHz 1: 13.3 kHz</p> <div style="border: 1px solid black; padding: 2px; display: inline-block; text-align: center;">  Important </div> <p>After the setting is changed and parameter is saved, this function is enabled when the driver was turned off and then on.</p> <div style="border: 1px solid black; padding: 2px; display: inline-block; text-align: center;">  Important </div> <p>Be sure to set "0" to those bits to which no function is allocated.</p> | - | 0x0000 - 0x1004 | HEX |
| 143 | Servo OFF Delay | 2 | ○ | ○ | <p>Sets the time delay between receiving a servo off command and the time the servo is turned OFF. [msec]</p> <p>The servo will remain ON for the set period of time when the servo is switched from ON to OFF. Refer to the operation time for the brake to be used when setting this time.</p> <p>This setting has the effect of preventing a drop when operation is stopped using the mechanical brake after a vertical up and down movement, by delaying servo OFF until the brake has been enabled.</p> | 0 | 0-10000 | DEC |
| 144 | Abs-Offset | 4 | ○ | ○ | <p>Internal data changed by presets, etc., using encoder reset or homing. This should not normally be changed directly.</p> | - | -2147483648 - 2147483647 | DEC |

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|---|---|---|---|---|-----------------|---------------|-------------|
| 145 | Speed Loop Proportional Gain During Inertia Estimate Mode | 2 | ○ | ○ | <p>Sets the speed loop proportional gain during Inertia Estimate Mode.</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;">  Important </div> <p>When the device inertia is large enough, make temporary setting before starting inertia estimation.</p> <p>The temporary setting depends on the ratio of the rough device inertia to the rotor inertia as follows:</p> <p style="margin-left: 20px;">2x or less: 500</p> <p style="margin-left: 20px;">2 to 3x: 1000</p> <p style="margin-left: 20px;">3x or more: 1500</p> | 200 | 0-2000 | DEC |
| 146 | Speed Loop Integral Gain During Inertia Estimate Mode | 2 | ○ | ○ | <p>Sets the speed loop integral gain during Inertia Estimate Mode.</p> <p>This should normally be used with the factory settings.</p> | 125 | 0-2000 | DEC |
| 147 | Brake Release Delay Time | 2 | ○ | ○ | <p>Sets the delay time for brake control signal output when servo is ON. [msec]</p> <p>When a mechanical brake is used on a vertical axis, adjusting the timing of servo ON and brake release can prevent falling.</p> <p>Set this value by referring to the brake start-up time.</p> | 0 | 0-10000 | DEC |
| 148 | Enable Off Timer | 2 | ○ | ○ | <p>Sets the communication time-out time of USB or SV-NET during servo-ON. [msec]</p> <p>If communication commands are absent for an interval longer than this setting during servo-ON, the servo is automatically turned OFF.</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;">  Caution </div> <p>Setting this to "0" disables the function; even if communication stops, the servo will not be turned OFF.</p> | 1000 | 0-10000 | DEC |
| 149 | Mechanical Brake Setting | 2 | ○ | × | <p>Sets the operation for the break control signal.</p> <p>1: Forced release (Output signal = always 1) 99: Forced brake (Output signal = always 0) 0: Released with servo ON (Output signal = 1) Brake ON with servo OFF (Output signal = 0)</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;">  Caution </div> <p>When set to 99, take care not to run the motor while the brake is applied.</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;">  Caution </div> <p>To operate a brake, you need to separately prepare a brake release circuit.</p> | 0 | 0,1,99 | DEC |
| 154 | Dynamic Brake Actuation Conditions | 1 | ○ | ○ | <p>Set the condition(s) for triggering the dynamic brake.</p> <p>0: Only when the power is shut off 1: When the power is shut off and an alarm is detected 2: When the power is shut off, an alarm is detected and the servo is turned off</p> | 0 | 0-2 | DEC |

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|---|---|---|---|---|----------------------------------|----------------------|-------------|
| 158 | Command Current Overload Factor Monitor | 2 | x | x | Command current overload factor monitor [0.1%] Displays the overload calculation value calculated from the command current in % with reference to ID 200 (overload alarm detection current). When this value reaches 100% (1000), the Command Current Overload Alarm (22) occurs. | - | - | DEC |
| 159 | Actual Current Overload Factor Monitor | 2 | x | x | Actual current overload factor monitor [0.1%] Displays the overload calculation value calculated from the motor actual current in % with reference to ID 200 (overload alarm detection current). When this value reaches 100% (1000), the Actual Current Overload Alarm (21) occurs. | - | - | DEC |
| 160 | Driver Temperature | 2 | x | x | Displays the board temperature inside the driver. [0.1°C] When this value reaches ID 204 (Overheat Error Detection Temperature) or more, the driver Overheat (51) occurs. | - | - | DEC |
| 161 | Drive Power Supply Voltage | 2 | x | x | Displays the driver power supply (P-N) voltage. [0.1 V] When this value reaches the ID 205 (Overvoltage Error Detection Voltage) setting value or higher, then Over Voltage (71) occurs. When it falls below the setting value of ID 206 "Low Voltage Detection," then Voltage Down (72) occurs. | - | - | DEC |
| 166 | Simple Control Execution Step Monitor | 2 | x | x | When Simple Control is working, the currently-running step number and status can be checked. Bit 7 to 0: Currently running step number Bit 12: "1" finishes the program. (Executes END.) | - | - | - |
| 182 | Stop Speed Judgement Speed | 2 | o | o | Sets the speed threshold value to judge ID 20 Bit 14 (Stop Speed Status). [rpm]  Important Set this value to 50 or higher when using a resolver. | For resolver: 50 Other: 10 | 0-10000 | DEC |
| 185 | Monitor 1 Gain | 2 | o | o | Sets the monitor gain (magnification) for analog monitor output 1. Examples: 1 = 1x, 10 = 10x, -10 = 1/10x, -20 = 1/20x (0, -1 are 1x) | 1 | -32767 - 32767 | DEC |
| 186 | Monitor 2 Gain | 2 | o | o | Sets the monitor gain (magnification) for analog monitor output 2. Examples: 1 = 1x, 10 = 10x, -10 = 1/10x, -20 = 1/20x (0, -1 are 1x) | 1 | -32767 - 32767 | DEC |

19.15. Parameters for Setting Error Detection

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|--|---|---|---|---|--------------------------------------|--|-------------|
| 200 | Overload Alarm Detection Current | 2 | ○ | ○ | Sets the threshold level for Overload Alarm (21 and 22). [0.01 A] Monitors Overload Alarm by comparing the motor current command with the detection level. ⇒ Refer to □17.9 "Characteristics of Overload Alarm Detection." | 105% of the motor rating current | Up to 105% of the motor rating current | DEC |
| 201 | Over-Speed Alarm Detection Speed | 2 | ○ | ○ | Sets the threshold level for Over-Speed Alarm (31). [rpm] When ID 41 "Feedback Speed" reaches this setting value, the Over-Speed Alarm occurs. | 8000 | 0-10000 | DEC |
| 202 | Position Deviation Error Detection Pulse Count | 4 | ○ | ○ | Sets the threshold level for the Position Excessive Deviation Alarm (42). [pulse] When ID 49 "Position Deviation" reaches this setting value or higher, a Position Excessive Deviation Alarm occurs. This setting uses no sign.  Caution If set to 2147483648 or larger, the alarm monitoring is disabled. | Depends on the sensor | 0 - 4294967295 | DEC |
| 204 | Overheat Error Detection Temperature | 2 | ○ | ○ | Sets the threshold level for Overheat Alarm (51). [°C] When ID 160 "Driver Temperature" reaches this setting value or higher, the Overheat Alarm occurs.  Caution Do not set more than the upper bound value. | 850 | 0-850 | DEC |
| 205 | Overvoltage Error Detection Voltage | 2 | ○ | ○ | Sets the threshold level for Over Voltage (71). [0.1 V] When ID 161 "Drive Power Supply Voltage" reaches this setting value or higher, the Over Voltage Alarm occurs.  Caution Do not set more than the upper bound value. | VAC 200: 4100 VAC 100: 2100 | 0-4100 0-2100 | DEC |
| 206 | Power Supply Shutoff Detection Voltage (low voltage detection) | 2 | ○ | ○ | Sets the threshold level for Voltage Down (72). [0.1 V] When ID 161 "Drive Power Supply Voltage" reaches this setting value or lower, the Voltage Down Alarm occurs. | VAC 200: 1000 VAC 100: 500 | 0-1000 0-500 | DEC |
| 207 | Regeneration Alarm Detection Capacity | 2 | ○ | ○ | Sets the threshold level for Regeneration Alarm (73 and 74). [W] When regeneration protection works continuously and the generated power reaches this setting value or higher, the Regeneration Error Alarm occurs.  Caution You need to set ID 208 "Regenerative Resistance Value" correctly according to the regenerative resistor you are using. | 60 | 0-6000 | DEC |
| 208 | Regeneration Resistance Value | 2 | ○ | ○ | Set the resistance value of the regenerative resistor you use. [0.01 Ω]  Caution Unless the correct value is set the regeneration alarm will not be able to detect it. | 4700 | 4700 | DEC |



| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|----------------------------|---|---|---|--|-----------------|---------------------------|-------------|
| 209 | Alarm Mask | 2 | ○ | ○ | <p>Disables detection of some alarms. Setting the specified bit to "1" disables the issuance of an alarm.</p> <p>Bit 0: 1 = Disable Actual Current Overload Alarm (21) Detection Bit 1: 1 = Disable Command Current Overload Alarm (22) Detection Bit 2: 1 = Disable Overspeed Alarm (31) Detection Bit 3: 1 = Disable Multi-rotation Alarm (41) Detection Bit 4: 1 = Disable Position Excessive Deviation Alarm (42) Detection Bit 5: 1 = Disable Driver Temperature Alarm (51) Detection Bit 6: 1 = Disable External Encoder Count Alarm (67) Detection Bit 7: 1 = Disable External Encoder Position Error Alarm (68) Detection Bit 8: 1 = Disable Regeneration Capacity Over Alarm (74) Detection Bit 9 to 11: (Reserved) Bit 12: 1 = Disable Drive Power Low Alarm (72) Detection Bit 13 to 15: (Reserved)</p> <p>Example: Set 0x0030 when disabling Excessive Deviation Alarm (42) and Driver Overheat Alarm (51).</p> <p>Important Set the reserved bit to "0."</p> <p>Caution Even when the alarm detection is set to disabled, continuing operation when the alarm conditions are met has the risk of damaging the driver or motor. When using the driver with the alarm detection disabled, constantly monitor the ID 29 "Warning Status Display." Take safety measures such as quickly stopping at the safe side upon detecting a warning.</p> | 0x0000 | 0x0000 - 0x11FF | HEX |
| 240 | Current Date | 4 | ○ | ○ | <p>Displays the date registered in the driver in binary coded decimal form. Example 1: November 23, 2013 → 0x00131123 Example 2: To change the current date to March 5, 2014 → 0x881440305 In this setting, data are set and saved at the same time. (No need for parameter saving operation) Year cannot be set to 00. If an abnormality occurs, this set value is registered in the alarm history as its date.</p> | - | 0x010101 - 0x991231 | HEX |
| 241 | Current Time | 4 | ○ | ○ | <p>Displays the present time registered in the driver in binary-coded decimal (BCD). To change the current time, set new values by adding 0x88 to the most significant 1 byte. Example 1: Display of 23h 12m 05sec → 0x00231205 Example 2: To change the current time to 11h 32m 01sec → 0x88113201 In this setting, data are set and saved at the same time. (No need for parameter saving operation) If an abnormality occurs, this set value is registered in the alarm history as its date.</p> | - | 0x000000 - 0x235959 | HEX |
| 242 | Total Power Supply ON Time | 4 | × | × | <p>Displays the time duration of the driver power being ON up to the present time since the product was shipped. [min] Example: For 130 hours (= 7800 [min]) of operation: 7800 This parameter is saved in non-volatile memory when the power is OFF, but numbers smaller than one minute are not saved. For example, if the power is turned OFF less than a minute after it is turned ON, the total time does not increase.</p> | - | 0 - 200000000 | DEC |


19.16. Parameters for Internal Monitoring





| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|--------------------------------|---|---|---|---|-----------------|---------------|-------------|
| 246 | Analog Input Monitor | 2 | x | x | Displays the analog input voltage in the scale and direction that the driver uses for internal control. [no unit] (Values after switching the analog input resolution) ±10 V is displayed as ±32767. Example: +10 V → 32767 | - | - | - |
| 247 | Real-time Command Current | 2 | x | x | Displays the current command value in the scale and direction that the driver uses for internal control. [no unit] [Model-specific full-scale value] N**1: ±4.13 A is displayed as ±16384 N**2: ±8.26 A is displayed as ±16384 N**3: ±16.53 A is displayed as ±16384 N**4: ±24.79 A is displayed as ±16384 | - | - | - |
| 248 | Speed Command | 2 | x | x | Displays the speed command value in the scale and direction that the driver uses for internal control. [no unit] ±10000 rpm is displayed as ±32767 Example: +10000 rpm → 32767 | - | - | - |
| 249 | Position Command | 4 | x | x | Displays the position command value in the scale and direction that the driver uses for internal control. [pulse] | - | - | - |
| 250 | q-Axis Current | 2 | x | x | Displays the current feedback value that the driver uses for internal control. [no unit] [Model-specific full-scale value] N**1: ±4.13 A is displayed as ±16384 N**2: ±8.26 A is displayed as ±16384 N**3: ±16.53 A is displayed as ±16384 N**4: ±24.79 A is displayed as ±16384 | - | - | - |
| 251 | Driver Internal Speed | 2 | x | x | Displays the speed feedback value in the scale and direction that the driver uses for internal control. [no unit] ±10000 rpm is displayed as ±32767 Example: +10000 rpm → 32767 | - | - | - |
| 252 | Driver Internal Position Error | 4 | x | x | Displays the position deviation in the scale and direction that the driver uses for internal control. [pulse] | - | - | - |




19.17. Extension Parameters


| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|----------------------------------|---|---|---|---|-----------------|-----------------------|-------------|
| 256 | Switching Special Functions 2 | 2 | ○ | ○ | <p>Makes special settings for the servo functions.</p> <p>Bit 0: Position loop operation method (Only for 17- and 23-bit encoders) 0 = High resolution operation 1 = Standard resolution operation</p> <p>Bit 1: Speed carry operation method (Only for 17- and 23-bit encoders) 0 = Method 1 (Standard) 1 = Method 2</p> <p>Bit 2: Friction compensation switching 0 = Friction compensation disabled 1 = Friction compensation enabled</p> <p>Bit 3: Weight compensation switching 0 = Weight compensation disabled 1 = Weight compensation enabled</p> <p>Bit 4: Quasi friction control switching 0 = Quasi friction control disabled 1 = Quasi friction control enabled (Friction compensation enabled; when Bit 2 = 1, it is disabled.)</p> <p>Bit 5: Wire-saving INC speed calculation method switching Switches among feedback speed calculation methods for the wire- saving INC. Switching sometimes can reduce vibrations or hunting. 0 = Speed calculation method 1 1 = Speed calculation method 2</p> <p>Bit 6: Load inertia setting unit switching Switches setting units of ID 59 (Load Inertia) 0 = Absolute unit [g·cm²] 1 = Relative unit [motor inertia magnification/100] (Example: For 3 times, 300) When this setting is changed, the value for ID 59 is automatically converted.</p> <p>Bit 7: Acceleration/deceleration setting unit switching Switches setting units of ID 34 (acceleration) and ID 35 (deceleration). 0 = [10 × rpm/s] 1 = [100 × rpm/s]</p> <p>Bit 8, Bit 9: Overload Alarm detection time constant switching Making the Overload Alarm (21 and 22) detection time constant smaller than the standard can shorten the alarm detection time. Bit 9/Bit 8 = 0/0: Standard Bit 9/Bit 8 = 0/1: Twice Bit 9/Bit 8 = 1/0: Quadruple Bit 9/Bit 8 = 1/1: Octuple</p> <p>Bit 10: (Reserved)</p> <p>Bit 11: Speed Limit switching 0 = Gain switching does not include Speed Limit switching. 1 = Gain switching includes Speed Limit switching.</p> <p>Bit 12: Tuning-free function response setting automatic switching 0 = When oscillation is detected, response setting automatic setting is enabled. 1 = When oscillation is detected, response setting automatic setting is disabled.</p> <p>Bit 13 to 15: (Reserved)</p> <div style="border: 1px solid black; border-radius: 10px; padding: 5px; display: inline-block; margin-top: 10px;"> Important </div> <p style="margin-top: 5px;">Be sure to set reserved Bits to "0."</p> | 0x0000 | 0x0000 - 0x1BFF | HEX |

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|-------------------------------------|---|---|---|--|-----------------|-----------------------|-------------|
| 257 | Switching observer | 2 | ○ | ○ | <p>Sets various observer functions.</p> <p>Bit 0: Disturbance Observer 0 = Disable 1 = Enable ⇒ Refer to □14.4 "Disturbance Observer"</p> <p>Bit 1: (Reserved) Bit 2: (Reserved) Bit 3: (Reserved) Bit 4: Speed Stabilizing Control 0 = Disable 1 = Enable ⇒ Refer to □14.2 "Speed Stabilizing Control"</p> <p>Bit 5: Disturbance suppression function in Speed Stabilizing Control 0 = Disable 1 = Enable</p> <p>Bit 6 to 15: (Reserved)</p> <div style="border: 1px solid black; padding: 2px; display: inline-block; margin: 5px 0;">  Caution </div> <p>Speed stabilizing control is permitted to be enabled only with the finite rotation axis.</p> <div style="border: 1px solid black; padding: 2px; display: inline-block; margin: 5px 0;">  Important </div> <p>Be sure to set reserved Bits to "0."</p> | 0x0000 | 0x0000 - 0x0031 | HEX |
| 260 | Low-pass Filter cut-off frequency 2 | 2 | ○ | ○ | <p>Sets the cut-off frequency of Low-pass Filter 2. [Hz]</p> <p>Low-pass Filter 2 is an IIR-type LP filter that is switchable between first and second order.</p> <p>0 or less, 5001 or more: Low-pass Filter 2 is disabled. 1 to 5000: Sets the cut-off frequency.</p> | 0 | 0-5000 | DEC |
| 261 | Order of Low-pass Filter 2 | 2 | ○ | ○ | <p>Sets the order of Low-pass Filter 2.</p> <p>0: Second order 1: First order</p> | 0 | 0-1 | DEC |
| 265 | Speed Command filter | 2 | ○ | ○ | <p>Set the cut-off frequency of the low-pass filter that applies to Speed Command. [Hz]</p> <p>0 or less, 2100 or more: Speed command filter is disabled. 1 to 2099: Sets the cut-off frequency.</p> | 0 | 0-2099 | DEC |
| 268 | Speed Feedback filter | 2 | ○ | ○ | <p>Set the number of points of the moving average filter that applies to Speed Feedback. (Up to 100)</p> | 0 | 0-100 | DEC |

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|---|---|---|---|---|-----------------|-----------------------|-------------|
| 270 | Center frequency of Notch Filer 3 | 2 | ○ | ○ | Notch Filters 3 to 7 • Center frequency [Hz] 0 or less, 5001 or more: Notch Filter is disabled. 1 to 5000: Sets Center frequency. • Attenuation [dB] The smaller the value, the larger the attenuation • Guidelines for attenuation: 100: 0 dB, 70: -3 dB, 40: -8 dB, 20: -15 dB, 10: -20 dB, and 0: -75 dB • Bandwidth [Hz] The smaller the value, the narrower the attenuation width and the steeper the attenuation curve Use the default value in normal use. Using a notch filter attenuates particular frequency components to suppress mechanical resonance without disrupting the system response. Note that the method for setting Notch Filters 3 to 7 differs from that for Notch Filters 1 and 2. ⇒ Refer to □13.4 "Filter Adjustment"  Caution Oscillation may occur if the center frequency is too low. Normally, use it with a setting of 50 or more. | 0 | 0-5000 | DEC |
| 271 | Attenuation of Notch Filer 3 | 2 | ○ | ○ | | 0 | 0-100 | DEC |
| 272 | Bandwidth of Notch Filer 3 | 2 | ○ | ○ | | 50 | 1-100 | DEC |
| 273 | Center frequency of Notch Filer 4 | 2 | ○ | ○ | | 0 | 0-5000 | DEC |
| 274 | Attenuation of Notch Filer 4 | 2 | ○ | ○ | | 0 | 0-100 | DEC |
| 275 | Bandwidth of Notch Filer 4 | 2 | ○ | ○ | | 50 | 1-100 | DEC |
| 276 | Center frequency of Notch Filer 5 | 2 | ○ | ○ | | 0 | 0-5000 | DEC |
| 277 | Attenuation of Notch Filer 5 | 2 | ○ | ○ | 0 | 0-100 | DEC | |
| 278 | Bandwidth of Notch Filer 5 | 2 | ○ | ○ | 50 | 1-100 | DEC | |
| 279 | Center frequency of Notch Filer 6 | 2 | ○ | ○ | 0 | 0-5000 | DEC | |
| 280 | Attenuation of Notch Filer 6 | 2 | ○ | ○ | 0 | 0-100 | DEC | |
| 281 | Bandwidth of Notch Filer 6 | 2 | ○ | ○ | 50 | 1-100 | DEC | |
| 282 | Center frequency of Notch Filer 7 | 2 | ○ | ○ | 0 | 0-5000 | DEC | |
| 283 | Attenuation of Notch Filer 7 | 2 | ○ | ○ | 0 | 0-100 | DEC | |
| 284 | Bandwidth of Notch Filer 7 | 2 | ○ | ○ | 50 | 1-100 | DEC | |
| 290 | Speed Feedforward Gain | 2 | ○ | ○ | Sets Speed Feedforward Gain. [%] This function applies feedforward to the torque command using the change in speed command value. This reduces speed deviation at the time of acceleration/deceleration. 0 or less: Speed Feedforward is disabled. 1 to 500: Feedforward Gain [%] ⇒ Refer to □14.3 "Feed-forward Function" | 0 | 0-500 | DEC |
| 291 | The number of Speed Feedforward Filters | 2 | ○ | ○ | Sets the number of filters for Speed Feedforward. This setting is effective when there is a large amount of noise at the speed command values in analog speed commands. Bit 3-0: Speed command acceleration calculation cycle 0: Speed control cycle (high speed) 1: Speed control cycle x 2 2: Speed control cycle x 3 3: Speed control cycle x 4 (low speed) Bit 7-4: Averaged number of feedforward commands 0: Not averaged 1: Averaged twice 2: Averaged four times ⇒ Refer to □14.3 "Feed-forward Function" | 0x0000 | 0x0000 - 0x0023 | HEX |

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|--|---|---|---|---|-----------------|----------------------------------|-------------|
| 300 | Friction Compensation Torque in the CW direction | 2 | ○ | ○ | <p>Torque in the CW direction with Friction Compensation [0.01 A]</p> <p>Sets the current value for the static friction torque in the CW direction with Friction Compensation enabled.</p> <p>It can be automatically set with Control Mode (ID 31) = 6.</p> <p> Caution</p> <p>Setting a value that is extremely larger than practical friction torques or weight torques may make the motor uncontrollable or cause large vibrations. When changing the value that was set confirm safety and then increase the value gradually.</p> <p>⇒ Refer to □14.5 "Correction for Friction and Gravity"</p> | 0 | 0 to Rated current | DEC |
| 301 | Friction Compensation Torque in the CCW direction | 2 | ○ | ○ | <p>Torque in the CCW direction with Friction Compensation [0.01 A]</p> <p>Sets the current value for the static friction torque in the CCW direction with Friction Compensation enabled.</p> <p>It can be automatically set with Control Mode (ID 31) = 6.</p> <p> Caution</p> <p>Setting a value that is extremely larger than practical friction torques or weight torques may make the motor uncontrollable or cause large vibrations. When changing the value that was set confirm safety and then increase the value gradually.</p> <p>⇒ Refer to □14.5 "Correction for Friction and Gravity"</p> | 0 | 0 to Rated current | DEC |
| 302 | Friction Compensation Viscous friction coefficient | 2 | ○ | ○ | <p>Friction Compensation; Viscous friction coefficient</p> <p>Sets the compensation value for a viscous friction component with Friction Compensation enabled.</p> <p>The larger the value, the larger the compensation at a high speed</p> <p>0: Viscous friction coefficient is zero</p> <p> Caution</p> <p>Setting a value that is extremely larger than practical friction torques or weight torques may make the motor uncontrollable or cause large vibrations. When changing the value that was set confirm safety and then increase the value gradually.</p> <p>⇒ Refer to □14.5 "Correction for Friction and Gravity"</p> | 0 | 0-32767 | DEC |
| 303 | Weight Compensation Torque | 2 | ○ | ○ | <p>Weight Compensation Torque [0.01 A]</p> <p>Sets the compensation current value for a static weight torque component with Weight Compensation enabled.</p> <p>When the CW direction is the ascending side, the value is positive.</p> <p>It can be automatically set with Control Mode (ID 31) = 6.</p> <p> Caution</p> <p>Setting a value that is extremely larger than practical friction torques or weight torques may make the motor uncontrollable or cause large vibrations. When changing the value that was set confirm safety and then increase the value gradually.</p> <p>⇒ Refer to □14.5 "Correction for Friction and Gravity"</p> | 0 | -Rated current to +Rated current | DEC |

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|--|---|---|---|--|-----------------|-----------------|-------------|
| 310 | Disturbance Observer Gain | 2 | ○ | ○ | Sets Disturbance Observer Gain. [%] 0: Disturbance Observer is disabled. 1 to 500: Disturbance Observer Gain [%] ⇒ Refer to □14.4 "Disturbance Observer" | 0 | 0-500 | DEC |
| 311 | Disturbance Observer LPF cut-off frequency | 2 | ○ | ○ | Sets the LPF cut-off frequency in Disturbance Observer. [Hz] Decreasing the set value reduces the response performance. ⇒ Refer to □14.4 "Disturbance Observer" | 1000 | 1-3000 | DEC |
| 320 | Speed Stabilizing Control Time estimation | 2 | ○ | ○ | Sets the estimated time in Speed Stabilizing Control. [msec] Setting this value to 0 or less disables Speed Stabilizing Control. The large the value, the more the stabilization.  Caution Do not use Speed Stabilizing Control in systems where the inertia change is large or the inertia is unknown, or for infinite rotation axes. ⇒ Refer to □14.2 "Speed Stabilizing Control" | 0 | 0-100 | DEC |
| 321 | Speed Stabilizing Control Gain 1 | 2 | ○ | ○ | Sets Gain 1 for Speed Stabilizing Control.  Caution Do not use Speed Stabilizing Control in systems where the inertia change is large or the inertia is unknown, or for infinite rotation axes. ⇒ Refer to □14.2 "Speed Stabilizing Control" | 0 | 0-1000 | DEC |
| 322 | Speed Stabilizing Control Gain 2 | 2 | ○ | ○ | Sets Gain 2 for Speed Stabilizing Control.  Caution Do not use Speed Stabilizing Control in systems where the inertia change is large or the inertia is unknown, or for infinite rotation axes. ⇒ Refer to □14.2 "Speed Stabilizing Control" | 0 | 0-1000 | DEC |
| 330 | ModbusRTU latency for return | 2 | ○ | ○ | Sets the delay time it takes for the slave to start returning the response after receiving a query from the master in the ModbusRTU communication. [msec] When this setting value is smaller than the response time (T_res), the response time (T_res) is the latency for return. This is enabled by restarting the power after setting and saving the parameters. | 0 | 0-1000 | DEC |
| 331 | ModbusRTU communication time-out | 2 | ○ | ○ | In the ModbusRTU communication, and with servo-ON, if the time duration of the absence of query from the master or of absence of broadcast query exceeds the time set by this parameter, the servo is automatically turned OFF. [msec] Setting it to "0" disables this function. | 0 | 0 - 32767 | DEC |

| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|--|---|---|---|--|-----------------|---------------|-------------|
| 360 | Tuning-free Function Mode | 2 | ○ | ○ | Sets Tuning-free Function Mode. 0: Tuning-free Function Mode disabled. 1: Only load inertia is set. Automatically estimates and sets ID59 "load inertia." 2: Estimates load inertia and friction compensation value. Automatically estimates and sets ID59 "Load Inertia," ID300 "Friction Compensation Torque in the CW Direction," ID301 "Friction Compensation Torque in the CCW Direction," and ID302 "Friction Compensation Viscous Friction Coefficient." *Parameters for friction compensation (ID300 to 302) are not used in control unless otherwise Bit 2 of ID256 "Special Function Switching 2" is set to "1." | 0 | 0~2 | DEC |
| 361 | Tuning-free Function Response Setting | 2 | ○ | ○ | Sets the targeted servo response when Tuning-free function is enabled. The greater the value is, the higher the response tuning becomes, but oscillation could be caused if the set value is too large. Uses it within the range not to cause oscillation. | 14 | 0~29 | DEC |
| 390 | Position Command Damping Filter 1 Center frequency | 2 | ○ | ○ | Position Command Damping Filter 1 This function suppresses low-frequency vibrations at the mechanical edge when the position is controlled. • Center frequency [0.1 Hz] 9 or less, 1001 or more: Damping Filter is disabled. | 0 | 0 or 10-1000 | DEC |
| 391 | Position Command Damping Filter 1 Attenuation | 2 | ○ | ○ | 10 to 1000: Setting the center frequency • Attenuation [dB] The smaller the value, the larger the attenuation Guidelines for attenuation: 100: 0 dB, 70: -3 dB, 40: -8 dB, 20: -15 dB, 10: -20 dB, and 0: -75 dB | 0 | 0-100 | DEC |
| 392 | Position Command Damping Filter 1 Width | 2 | ○ | ○ | • Width [Hz] The smaller the value, the narrower the attenuation width and the steeper the attenuation curve Use the default value in normal use.  Caution • Do not use the Position Command Damping Filter for infinite rotation axes. | 50 | 1-100 | DEC |
| 450 | Pulse Count Monitor | 4 | x | x | Displays input pulse count value for Position Command. [pulse] | - | - | - |
| 451 | Analog Input Voltage Monitor | 2 | x | x | Displays Analog Input Voltage monitoring value. (Value before switching Analog Input Resolution) "±12 V" is displayed as "±2048." | - | - | - |
| 452 | External Encoder Input Monitor | 2 | x | x | Displays the input pulse count of the External Encoder. [pulse] | - | - | - |
| 453 | Regeneration Monitor | 2 | x | x | Displays Regeneration Power. [W] If this value exceeds ID 207 "Regeneration Alarm Detection Capacity," Regeneration Error Alarm (74) occurs. | - | - | - |
| 454 | Drive Power Supply Voltage Monitor | 2 | x | x | Displays the monitoring value of the non-averaged Drive Power Supply Voltage. [0.1 V] | - | - | - |
| 455 | Monitor Torque | 2 | x | x | Displays the theoretical value of motor output torque calculated by the operation: Motor Current x Motor Torque Constant (Kt). [0.01 N·m] This is only a reference value, which differs from the real torque at the motor shaft end. | - | - | - |


| ID | Name | L | W | M | Description | Factory setting | Setting range | Designation |
|-----|-------------------------------------|---|---|---|---|-----------------|---------------|-------------|
| 459 | Internal Position Command Monitor 1 | 4 | x | x | Displays the Internal Position Command value. [pulse] Monitor 1: Before the smoothing process | - | - | - |
| 460 | Internal Position Command Monitor 2 | 4 | x | x | Monitor 2: After the smoothing process | - | - | - |
| 461 | Internal Speed Command Monitor 1 | 2 | x | x | Displays the Internal Speed Command value. [no unit] Monitor 1: Before Speed Command Filter | - | - | - |
| 462 | Internal Speed Command Monitor 2 | 2 | x | x | Monitor 2: After Speed Command Filter ±10000 rpm is displayed as ±32767. Example: +10000 rpm = 32767 | - | - | - |
| 465 | Internal Current Command Monitor 1 | 2 | x | x | Displays the Internal Current Command value. [no unit] Monitor 1: Before the filtering of current command | - | - | - |
| 466 | Internal Current Command Monitor 2 | 2 | x | x | Monitor 2: (Process order 1) After Disturbance Observer | - | - | - |
| 467 | Internal Current Command Monitor 3 | 2 | x | x | Monitor 3: (Process order 2) After the LPF and Notch Filter | - | - | - |
| 468 | Internal Current Command Monitor 4 | 2 | x | x | Monitor 4: (Process order 3) After Speed Feedforward | - | - | - |
| 469 | Internal Current Command Monitor 5 | 2 | x | x | Monitor 5: (Process order 4) After Friction Compensation [Model-specific full-scale value] N**1: ±4.13 A is displayed as ±16384. N**2: ±8.26 A is displayed as ±16384. N**3: ±16.53 A is displayed as ±16384. N**4: ±24.79 A is displayed as ±16384. | - | - | - |
| 470 | Speed Integration Monitor | 2 | x | x | Displays the integrated value of the Speed Integration Gain within a range of ±32768. [no unit] | - | - | - |
| 471 | Current Integration Monitor 1 | 2 | x | x | Displays the integrated value of the Current Integration Gain within a range of ±32768. [no unit] | - | - | - |
| 473 | Speed Command Monitor | 2 | x | x | Displays the Internal Speed Command value before Speed Command Filter. [rpm] ID 461 "Internal Speed Command Monitor 1" is converted into this value in rpm. | - | - | - |
| 474 | Current Command Monitor | 2 | x | x | Displays the Internal Current Command value before all processes. [0.01 A] ID 465 "Internal Current Command Monitor 1" is converted into this value in A. | - | - | - |
| 476 | Driver Internal Position Deviation | 4 | x | x | Displays the Position Deviation in the scale and direction that the driver uses for internal control. [pulse] | - | - | - |

20. Settings Panel Operation

The settings panel allows you to change parameters, run Jog, display statuses, and so on. The following provides explanations of how to operate the settings panel.

20.1. Settings Panel Names and Functions

The names and functions of each display and button are shown below.




| Button | Function |
|--------|---|
| MODE | <p>MODE button</p> <p>Switches between the various modes.</p> <ul style="list-style-type: none"> Status Display → Parameter Operations → Parameter Save → Alarm Display → Supplementary Functions <p>Used when returning from operating in each mode.</p> |
| ◀ | <p>SHIFT button</p> <p>This lets you select which digits you want to change when changing data. Pressing this button will shift the selected (blinking) row digit to the left. It will also change the mode if pressed and held.</p> |
| ▲ | <p>UP button</p> <p>Pressing this button increases the setting value of the data.</p> <p>During JOG operation, this becomes the forwards rotation operation (CCW) button.</p> |
| ▼ | <p>DOWN button</p> <p>Pressing this button decreases the setting value of the data.</p> <p>During JOG operation, this becomes the reverse rotation operation (CW) button.</p> |

Pressing more than one button at the same time can cause the display to become unstable. Do not press multiple buttons at the same time.

20.2. Display Mode Functions and Selection

Pressing the MODE button switches between Display Modes.

Status Display mode is used immediately after power is supplied. The default setting (factory setting) is "Servo Status" display.



20.3. Operations in Status Display Mode

In Status Display mode, the signals, motor speed, etc. input to the driver are displayed in the LED.

Select the status with the UP button and display the details with the SHIFT button.

While the details are displayed, the MODE button will return you to the selection screen, but you can also use the UP button to return to the selection screen.

If the SHIFT button is not pressed, the details display screen will be selected automatically in about three seconds.

When the power is turned ON, the device starts up with the Status Display mode that was running the last time power was turned OFF. (Ver. 4.65 or later)






Table. How to Read Servo Status Displays

| | Sign | SEG5 | SEG4 | SEG3 | SEG2 | SEG1 |
|----------|--------------|--|------------------|---|------|---|
| Normal | (Turned OFF) | Displays the ID 31 "control mode". 0: Servo OFF mode 1: Position control mode 2: Speed control mode 3: Current control mode 4: Zero return control mode 5: Inertia estimation mode 6: Friction correction torque estimation mode E: Simple control | Displays hyphens | Displays servo ON or OFF : Servo OFF : Servo ON | |  Input signal status Lit with photocoupler ON (1) IN1 (2) IN2 (3) IN3 (4) IN4 (5) IN5 (6) IN6 (7) IN7 * IN8 cannot be displayed. |
| Alarm ON | | Displays "AL". | | | | |

20.4. Operations in Parameter Operations Mode

Display and editing are always available but some data cannot be changed or the values are restricted. (For details, refer to □19. "List of Parameters.")

Parameters with a notation of **DEC** are displayed in decimal numbers; those with **HEX** are displayed in hexadecimal numbers.



(1) ID selection screen.

Select the ID of parameter that is to be displayed and edited.

Change the value using the ▲ or ▼ buttons.

Press the ◀ button once (no more than half a second) to change the digit you can operate (the flashing digit).

When the parameter ID is set, press and hold the ◀ button (for one second or longer) to move to (2) Data display screen.

(2) Data display screen

The data of the selected parameter is displayed. The value cannot be edited.

For a 4-byte parameter, press ◀ to change displayed digits.

To edit values, press and hold the ◀ button (for one second or longer) to move to (3) Data editing screen.

When you do not need to edit anything, press the MODE button to return to (1) ID selection screen.

(3) Edit data screen

Edit the parameter data of selected ID.

Change the value using the ▲ or ▼ buttons.

Press the ◀ button once (no more than half a second) to change the digit you can operate (the flashing digit).

Once you have selected the figure, press and hold the ◀ button (for over one second). The data will be updated and you will be returned to (2) the data display screen.

If editing is possible, the values will be updated and reflected in the results.

To return to the data display screen without updating the values, press the MODE button.

20.5. Parameter Value Display Examples

■ 1-byte data/2-byte data

- Hexadecimal notation (HEX)

Example: "0x0123"



Its first character is displayed as "h."

- Decimal notation (DEC)

Example 1: "123"



Example 2: "-1000"



Displays the negative sign (-) at the left end.


■ 4-byte data

- Hexadecimal notation (HEX)

Example: "0x00123456"



Higher




Lower

Displays "H" (higher digits) or "L" (lower digits) at the left.

- Decimal notation (DEC)

Supplement


This function applies to software revision 4.44 or later.



Example 1: "2147483647"



Higher



Middle



Lower


Example 2: "6543210"



Higher



Middle




Lower


Example 3: "-43210"



Higher



Middle




Lower

The negative sign (-) is displayed at the immediate left of the highest digit.

20.6. Operations in Parameter Save Mode

Servo parameters can be edited in Parameter Operations mode, but the changed data is saved in this mode. All parameters are saved in EEPROM.
Parameters should be saved with the servo OFF.



Use the MODE button to select Parameter Save mode (EEPro).

Press the ◀ button.

Once you are on the Parameter Save screen, release the ◀ button.

Next, pressing and holding the ◀ button will increase the "-."

Releasing the button before "- -" is displayed means that no processing will be done.

When processing is finished, the screen will change to the completion screen.

"End": Completed without errors

"Error": Completed with errors (save processing was done when operation cannot be accepted, so it could not be saved)

The "Error" display shows the "Completed with errors" for button operation, and does not affect servo operation.

Press the MODE button in the completion screen to return to the Parameter Save mode screen.

20.7. Operations in Alarm Display Mode


The current alarm and the alarm history are shown on the LED display in Alarm Display mode.

In the alarm history, the larger the number, the older the alarm.

Use the ▲ button to display the next alarm and the ▼ button to display the previous alarm.

With "Current alarms" displayed, pressing the ◀ button will move you to the Clear Alarm screen.

Removing the cause of the alarm and holding and pressing the ◀ button lets you clear the alarm.
(Some alarms cannot be cleared.)




((Clear Alarm screen))

Pressing and holding the ◀ button in the Clear Alarm screen will increase the "-" Releasing the button before "- -" is displayed means that no processing will be done.

When processing is finished, the screen will change to the completion screen.

Press the MODE button in the completion screen to return to the Alarm Display mode screen.



"End": Cleared successfully

"Error": Failed to clear (reset operation was not performed since there were no alarms or clear operation was performed without eliminating the cause of alarm.)

* The "Error" display shows the "Completed with errors" for button operation, and does not affect servo operation.

* When the sensor is a SmartABS sensor, such as 17/23 Bit-ABS, the alarms recorded on the encoder side are alarm codes 61, 63, 64, and 66, and alarms cannot be cleared using the above setting alone.


In this event, first use parameter operations to set B15 " SmartABS sensor alarm & multi-rotation reset" in ID 30, "Servo Commands," then clear the alarm.

⇒ Refer to □17.5 "Clearing a Sensor Alarm"

20.8. Operations in Supplementary Functions Mode

In Supplementary Functions mode, you can make various adjustments to the driver. Supplementary mode is made up of a range of function screens, with the operation changing for each function.

Select the function with the ▲ button and move to the execution screen with the ◀ button.




20.9. Operations in JOG Operation Mode

Entering JOG operation in Supplementary Functions mode lets you run the motor in JOG mode from the settings panel.

JOG operation should be done with the servo OFF and alarm reset OFF.

List of JOG Operations

| JOG number | Description |
|------------|--|
| JOG-0 | Speed step operations You can use the ▲ button while "ON-0" is displayed for forwards direction speed step operation and the ▼ button for reverse direction speed step operation. (Default value: 0 rpm) |
| JOG-1 | Current step operations You can use the ▲ button while "ON-1" is displayed for forwards direction current step operation and the ▼ button for reverse direction current step operation. (Default value: 0 Arms) |



20.10. List of Status Display Mode

| Item | Example | Description |
|------|---------|---|
| | | Displays Servo Status. To read, refer to □Table "How to Read Servo Status Displays" in 20.3. Display example: Mode 0, Servo OFF, IN2 and IN4 input ON |
| | | Displays the value of ID 40 "Feedback Position." Unit: pulse; Display example: Middle digits of -567890 pulses |
| | | Displays the value of ID 41 "Feedback Speed." Unit: rpm; Display example: -1000 rpm |
| | | Displays the value of ID 42 "Feedback Current." Unit: 0.01A; Display example: -1.05 A |
| | | Displays the value of ID 455 "Monitor Torque." Unit: 0.001 N•m, Display example: 0213 N•m * The Monitor Torque value is calculated by Motor Current x Motor Torque Constant (Kt). This is only a reference value, which differs from the real torque at the motor shaft end. |
| | | Displays the value of ID 49 "Position Deviation." Unit: pulse, Display example: Lower order digits of -123 pulse. |
| | | Displays the value of ID 459 "Internal Position Command Monitor 1." Unit: pulse, Display example: Middle digits of -2345678 pulse. |
| | | Displays the value of ID 473 "Speed Command Monitor." Unit: rpm, Display example: 3000 rpm |
| | | Displays the value of ID 474 "Current Command Monitor." Unit: 0.01 A, Display example: -3.12 A |
| | | Displays the value of ID 159 "Actual Current Overload Factor Monitor." Unit: 0.1%, Display example: 81.5% |
| | | Displays the value of ID 158 "Command Current Overload Factor Monitor." Unit: 0.1%, Display example: 50.1% |
| | | Displays the value of ID 450 "Pulse Count Monitor." Unit: pulse, Display example: Lower order digits of 1234 pulse |
| | | Displays the value of ID 452 "External Encoder Input Monitor." Unit: pulse, Display example: Lower order digits of -5555 pulse |
| | | Displays the value of ID 451 "Analog Input Voltage Monitor." Range: ±2048 (=±12V) Display example: 512 (=3 V) |
| | | Displays the value of ID 453 "Regeneration Monitor." Unit: W, Display example: 20 W |
| | | Displays the value of ID 454 "Drive Power Supply Voltage Monitor." Unit: 0.1 V, Display example: 245.0 V |
| | | Displays the value of ID 160 "Driver Temperature." Unit: 0.1°C, Display example: 45.6°C |
| | | Displays the value of ID 45 "Sensor Position 1." Unit: pulse, Display example: Lower order digits of 1234 pulse |
| | | Displays the value of ID 46 "Sensor Position 2." Unit: pulse, Display example: Lower order digits of 1234 pulse |

21. After-Sales Service

21.1. Repair and Inquiry

For repair or inquiry, please contact the dealer from whom you purchased the product. We offer a software upgrade service. Please consult with us about this (charges may apply).

21.2. Guarantee

■ Free Guarantee Period

The free guarantee period is valid for the shorter of the following: within one year of the product being installed at your site or your customer's site or within 18 months (from the manufacturing month) of the product being delivered from our plant.

■ Guarantee Scope

Failure diagnosis

We request that, as a rule, your company should perform the initial diagnosis of the failure.

However, this diagnosis can be performed instead by us or our service network if you so request. In this case, following discussions with your company, repairs will be provided free of charge if the failure is attributable to us.

Failure repair

Repair, replacement, and on-site visits for failures incur charges for the four cases below, but are free in other cases.

1. If the failure is due to improper storage or handling, negligence on the part of you or your customer, the nature of your software or hardware design, or any other such reason.
2. If the failure is attributable to modifications and changes you have made to our products without our approval.
3. If the failure is attributable to use of a product beyond the specified range.
4. Other failures that you acknowledge as being outside our responsibility.

21.3. Exemption from Responsibility for Compensation for Opportunity Loss, Etc.

Whether within the free guarantee period or not, our guarantee does not provide compensation for the following items attributable to the failure of our products: any loss of opportunity you or your customers may suffer, any damage to a product other than our own, or damage attributable to another's responsibility.

21.4. Period of Repair after Production Discontinuation

We will repair discontinued products for seven years after the last shipment date. For some products, substitutes may be recommended.

21.5. Delivery Conditions

For standard products which do not include application setting and adjustment, delivery of the product to you is deemed as acceptance of the product, and we assume no responsibility for operations such as on-site adjustment or trial runs.


21.6. Appropriate Use of This Product

- This product is not designed or manufactured for use with equipment and systems used in situations where there is a risk to life.
- If you are considering using this product with medical, aerospace, nuclear power, electric power, marine, manned transportation, or other special systems, please consult with our sales office.
- This product is manufactured under strict quality control. However, if failure of the product may result in serious accident or loss, safety devices must be installed on the equipment and systems on which our product is installed.

22. Appendices

22.1. Optional Parts

SV-NET Cable



Controller-Driver Connection

| Model | Length (L) |
|---------------|------------|
| EUA1354 N0010 | 1 m |
| N0030 | 3 m |
| N0050 | 5 m |
| N0100 | 10 m |


Driver-Driver Connection

| Model | Length (L) |
|---------------|------------|
| EUA1287 N0010 | 1 m |
| N0030 | 3 m |
| N0050 | 5 m |
| N0100 | 10 m |

Termination Connector


| Model | Length (L) |
|---------------|------------|
| EUA1294 N0000 | - |

Motor Cable (brakeless)




| Model | Length (L) |
|---------------|------------|
| EUA1280 N0010 | 1 m |
| N0030 | 3 m |
| N0050 | 5 m |
| N0100 | 10 m |

■ Motor Cable (braked)




| Model | Length (L) |
|---------------|------------|
| EUA1292 N0010 | 1 m |
| N0030 | 3 m |
| N0050 | 5 m |
| N0100 | 10 m |

■ Sensor Cable (wire-saving INC, 17bit-INC, 23bit-INC, resolvers)




| Model | Length (L) |
|---------------|------------|
| EUA1281 N0010 | 1 m |
| N0030 | 3 m |
| N0050 | 5 m |
| N0100 | 10 m |

■ Sensor Cable (built-in 17bit-ABS, 23bit-ABS battery)




| Model | Length (L) |
|---------------|------------|
| EUA1283 N0010 | 1 m |
| N0030 | 3 m |
| N0050 | 5 m |
| N0100 | 10 m |

■ i4s Motor Cable




| Model | Length (L) |
|---------------|------------|
| EUA9201 N0010 | 1 m |
| N0030 | 3 m |
| N0050 | 5 m |
| N0100 | 10 m |

■ i4s Braked Cable




| Model | Length (L) |
|---------------|------------|
| EUA9202 N0010 | 1 m |
| N0030 | 3 m |
| N0050 | 5 m |
| N0100 | 10 m |

■ i4s Sensor Cable (serial-ABS)




| Model | Length (L) |
|---------------|------------|
| EUA9203 N0010 | 1 m |
| N0030 | 3 m |
| N0050 | 5 m |
| N0100 | 10 m |

■ i4s Sensor Cable (serial-INC)




| Model | Length (L) |
|---------------|------------|
| EUA9204 N0010 | 1 m |
| N0030 | 3 m |
| N0050 | 5 m |
| N0100 | 10 m |

■ i4s Sensor Cable (resolvers)



| Model | Length (L) |
|---------------|------------|
| EUA9205 N0010 | 1 m |
| N0030 | 3 m |
| N0050 | 5 m |
| N0100 | 10 m |

I/O Cable




Command pulse input: Line driver

| Model | Length (L) |
|---------------|------------|
| EUA1424 N0003 | 0.3 m |
| N0010 | 1 m |
| N0030 | 3 m |
| N0050 | 5 m |

Command pulse input: Open collector


| Model | Length (L) |
|---------------|------------|
| EUA1425 N0003 | 0.3 m |
| N0010 | 1 m |
| N0030 | 3 m |
| N0050 | 5 m |

USB Cable



| Model | Length (L) |
|---------------|------------|
| EUA1459 N0010 | 0.8 m |
| N0015 | 1.3 m |
| N0020 | 1.8 m |
| N0030 | 2.8 m |

Regenerative Resistor




| Model | Resistance/Capacity |
|---------|---------------------|
| EUA1290 | 47 Ω 80 W |

Accessories


Power supply connector

0134-32-6588-03 (DINKLE)





Motor connector

0134-1105 (DINKLE)




22.2. External Connection Diagram

TAD 8811Series






- *1 The power supply can be connected to either single-phase or three-phase.
- *2 The power supply voltage and the I/F voltage differ by N-number model. Combinations are as follows.



- *3 We recommend that the sensor should be connected to DG. However, connecting to CN2-CASE1 can increase the noise resistance level.

Sensor Connection Diagram



22.3. Usable Parameters by Software Revision

Product refinements may enable parameters to be added. Use the table below to check usable parameters. See ID 3 "Revision" to check software revision details.

EN- and UL-compliant products are equipped with Software Revision 6.00 or later.

| ID | Parameter name | Read value |
|----|-------------------|------------|
| 3 | Software Revision | DEC |

Example: The number "316" means the Revision is "3.16."

| ID | Parameter symbol | Revision | | | | | | | | |
|----|---|----------|------|------|------|------|------|------|------|---|
| | | 3.16 | 3.22 | 4.11 | 4.31 | 4.44 | 4.77 | 6.00 | 6.20 | |
| 1 | Device Code | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 2 | Product Code | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 3 | Software Revision | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 4 | Serial Number | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 5 | MAC-ID | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 6 | Baud Rate | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 16 | Parameters init. | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 17 | Parameters Save | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 18 | Program Code | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 20 | Servo Status | Bit 0 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 1 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 2 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 3 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 4 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 5 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 6 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 7 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 8 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 9 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 10 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 11 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 12 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 13 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 14 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 21 | I/O Status | Bit 16 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | | Bit 20 | - | - | - | - | - | ○ | ○ | |
| | | Bit 21 | - | - | - | - | - | ○ | ○ | |
| | | Bit 22 | - | - | - | - | - | ○ | ○ | |
| 22 | Alarm Code | Bit 24 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | | Bit 24 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 23 | Alarm History-1 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | | |
| 24 | Alarm History-2 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | | |
| 25 | Select Alarm Occurrence Information to be Displayed | ○ | ○ | ○ | ○ | ○ | ○ | ○ | | |
| 26 | Alarm Occurrence Information | ○ | ○ | ○ | ○ | ○ | ○ | ○ | | |
| 29 | Warning Status Display | ○ | ○ | ○ | ○ | ○ | ○ | ○ | | |

| ID | Parameter symbol | | Revision | | | | | | | | |
|--------|----------------------------|--------|----------|------|------|------|------|------|------|------|---|
| | | | 3.16 | 3.22 | 4.11 | 4.31 | 4.44 | 4.77 | 6.00 | 6.20 | |
| 30 | Servo Command Control Mode | Bit 0 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 1 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 2 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 3 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 4 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 5 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 7 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 8 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 9 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 10 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 11 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 12 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 13 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 14 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| Bit 15 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | | |
| 31 | Control Mode | 0 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 1 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 2 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 3 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 4 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 5 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 14 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 32 | Target Position | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 33 | Target Velocity | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 34 | Acceleration | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 35 | Deceleration | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 36 | Real-time Command Position | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 37 | Real-time Command Speed | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 38 | Real-time Command Current | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 39 | Position Reset Value | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 40 | Feedback Position | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 41 | Feedback Speed | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 42 | Feedback Current | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 43 | Feedback PVC | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 44 | Feedback SVC | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 45 | Sensor Position 1 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 46 | Sensor Position 2 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 47 | ECD Position | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 48 | External Encoder Position | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| 49 | Position Deviation | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |

| ID | Parameter symbol | | Revision | | | | | | | |
|----|-----------------------------------|-------------|----------|------|------|------|------|------|------|------|
| | | | 3.16 | 3.22 | 4.11 | 4.31 | 4.44 | 4.77 | 6.00 | 6.20 |
| 50 | Position Loop Proportional Gain 1 | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 51 | Speed Loop Proportional Gain 1 | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 52 | Speed Loop Integral Gain 1 | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 53 | Low-pass Filter Cutoff Frequency | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 54 | Notch Filter Center Frequency 1 | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 55 | Notch Filter Attenuation 1 | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 56 | Current Loop Proportional Gain | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 57 | Current Loop Integral Gain | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 58 | Phase-advance Gain | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 59 | Load Inertia | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 60 | Position Loop Proportional Gain 2 | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 61 | Speed Loop Proportional Gain 2 | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 62 | Speed Loop Integral Gain 2 | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 63 | Notch Filter Center Frequency 2 | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 64 | Notch Filter Attenuation 2 | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 65 | Forward Current Limit 2 | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 66 | Reverse Current Limit 2 | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 68 | Position Feedforward Gain | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 69 | Control Switch | Bit 0 to 4 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | Bit 5 | - | - | - | - | - | ○ | ○ | ○ |
| | | Bit 6 to 15 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 72 | Reference Direction | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 73 | Select Position Feedback | 0 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 1 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 74 | Select Position Command | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 75 | Select Speed Command | 0, 1, Bit 7 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 2 | - | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 76 | Select Torque Command | 0, 1, Bit 7 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 2 | - | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 3 | - | - | - | - | - | ○ | ○ | ○ |
| 77 | In-Position Signal Range | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 78 | Smoothing Time 1 | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 79 | Smoothing Time 2 | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 80 | Select Gain-switch Method | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 81 | Gain-switch Point H | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 82 | Gain-switch Point L | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 83 | Select Soft Limit | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 84 | Positive-side Soft Limit | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 85 | Reverse-side Soft Limit | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 86 | Forward-rotation Current Limit | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 87 | Reverse-rotation Current Limit | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 88 | Speed Limit | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 89 | In-Position Signal Range | | - | - | - | - | - | ○ | ○ | ○ |
| 90 | Homing Mode | 0 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 1 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 2 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 3 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 4 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 91 | Homing Preset Value | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 92 | Homing Start Direction | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 93 | Homing Speed | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 94 | Homing Creep Speed | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 95 | Homing Thrust Time | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 96 | Homing Thrust Torque | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |

| ID | Parameter symbol | | Revision | | | | | | | |
|------------------|---|----|----------|------|------|------|------|------|------|------|
| | | | 3.16 | 3.22 | 4.11 | 4.31 | 4.44 | 4.77 | 6.00 | 6.20 |
| 99 | Control Mode 2 | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 100 to 107 | I/O Setting Parameter Input 1 (IN1) – Input 8 (IN8) Setting | 0 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 1 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 2 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 3 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 4 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 5 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 6 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 7 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 8 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 9 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 10 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 11 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 12 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 13 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 14 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 15 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 16 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 17 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 18 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | | |
| 99 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | | |
| 110 to 114 | I/O Setting Parameter Output 1 (OUT1) – Output 5 (OUT5) Setting | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 117 | I/O filter time | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 118 | Monitor 1 Setting | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 119 | Monitor 2 Setting | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 120 | Pulse Input Mode | 0 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 1 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| | | 2 | - | - | ○ | ○ | ○ | ○ | ○ | ○ |
| 121 | Command Pulse Input Signal Resolution Numerator | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 122 | Command Pulse Input Signal Resolution Denominator | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 123 | External Encoder Direction | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 124 | External Encoder Resolution | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 126 | Sensor Output Division Setting | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 130 | Analog Input Signal Speed Conversion Scale | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 131 | Analog Input Current Speed Conversion Scale | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 132 | Analog Input Offset | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 133 | Analog Input Zero Clamp | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 134 | Analog Input Filter | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |

| ID | Parameter symbol | Revision | | | | | | | |
|-----|---|----------|------|------|------|------|------|------|------|
| | | 3.16 | 3.22 | 4.11 | 4.31 | 4.44 | 4.77 | 6.00 | 6.20 |
| 140 | Abs Mode | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 141 | Special Function Switching | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 143 | Servo OFF Delay | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 144 | Abs-Offset | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 145 | Speed Loop Proportional Gain in Inertia Estimate Mode | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 146 | Speed Loop Integral Gain in Inertia Estimate Mode | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 147 | Brake Release Delay Time | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 148 | Enabled Time for Servo During Communication Shutoff | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 149 | Input Brake Setting | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 154 | Dynamic Brake Actuation Conditions | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 158 | Command Current Overload Factor Monitor | - | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 159 | Actual Current Overload Factor Monitor | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 160 | Driver Temperature | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 161 | Drive Power Supply Voltage | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 166 | Simple Control Execution Step Monitor | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 182 | Stop Speed Judgment Speed | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 185 | Monitor 1 Gain | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 186 | Monitor 2 Gain | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 200 | Overload Alarm Detection Current | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 201 | Over-Speed Alarm Detection Speed | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 202 | Position Deviation Error Detection Pulse Count | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 204 | Overheat Error Detection Temperature | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 205 | Overvoltage Error Detection Voltage | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 206 | Power Shutoff Detection Voltage (low voltage detection) | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 207 | Regeneration Alarm Detection Capacity | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 208 | Regeneration Resistance Value | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 209 | Alarm Mask | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 240 | Current Date | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 241 | Current Time | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 242 | Total Power Supply ON Time | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 246 | Analog Input Monitor | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 247 | Real-time Command Current | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 248 | Speed Command | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 249 | Position Command | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 250 | Q-Axis Current | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 251 | Driver Internal Speed | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |
| 252 | Driver Internal Position Error | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ |

| ID | Parameter symbol | | Revision | | | | | | | |
|-----|--|------------|----------|------|------|------|------|------|------|------|
| | | | 3.16 | 3.22 | 4.11 | 4.31 | 4.44 | 4.77 | 6.00 | 6.20 |
| 256 | Special Function Switching 2 | Bit 0 to 6 | - | - | - | ○ | ○ | ○ | ○ | ○ |
| | | Bit 7 | - | - | - | - | - | ○ | ○ | ○ |
| | | Bit 8, 9 | - | - | - | ○ | ○ | ○ | ○ | ○ |
| | | Bit 11 | - | - | - | - | - | ○ | ○ | ○ |
| | | Bit 12 | - | - | - | - | - | - | ○ | ○ |
| 257 | Observer Switching | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 260 | Low-pass Filter Cutoff Frequency 2 | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 261 | Low-pass Filter Order 2 | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 265 | Speed Command Filter | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 268 | Speed Feedback Filter | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 270 | Notch Filter Center Frequency 3 | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 271 | Notch Filter Attenuation 3 | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 272 | Notch Filter Bandwidth 3 | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 273 | Notch Filter Center Frequency 4 | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 274 | Notch Filter Attenuation 4 | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 275 | Notch Filter Bandwidth 4 | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 276 | Notch Filter Center Frequency 5 | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 277 | Notch Filter Attenuation 5 | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 278 | Notch Filter Bandwidth 5 | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 279 | Notch Filter Center Frequency 6 | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 280 | Notch Filter Attenuation 6 | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 281 | Notch Filter Bandwidth 6 | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 282 | Notch Filter Center Frequency 7 | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 283 | Notch Filter Attenuation 7 | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 284 | Notch Filter Bandwidth 7 | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 290 | Speed Feedforward Gain | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 291 | Number of Speed Feedforward Filters | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 300 | Friction Compensation Torque in the CW Direction | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 301 | Friction Compensation Torque in the CCW Direction | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 302 | Friction Compensation Viscous Friction Coefficient | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 303 | Weight Compensation Torque | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 310 | Disturbance Observer Gain | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 311 | Disturbance Observer LPF Frequency | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 320 | Speed Stabilizing Control Time Estimation | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 321 | Speed Stabilizing Control Gain 1 | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 322 | Speed Stabilizing Control Gain 2 | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 330 | ModbusRTU Latency for Return | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 331 | ModbusRTU Communication Time-out | | - | - | - | ○ | ○ | ○ | ○ | ○ |
| 360 | Tuning-free Function Mode | | - | - | - | - | - | - | ○ | ○ |
| 361 | Tuning-free Function Response Setting | | - | - | - | - | - | - | ○ | ○ |

| ID | Parameter symbol | Revision | | | | | | | |
|-----|--|----------|------|------|------|------|------|------|------|
| | | 3.16 | 3.22 | 4.11 | 4.31 | 4.44 | 4.77 | 6.00 | 6.20 |
| 390 | Position Command Damping Filter 1 Center Frequency | - | - | - | - | - | ○ | ○ | ○ |
| 391 | Position Command Damping Filter 1 Attenuation | - | - | - | - | - | ○ | ○ | ○ |
| 392 | Position Command Damping Filter 1 Width | - | - | - | - | - | ○ | ○ | ○ |
| 450 | Pulse Count Monitor | - | - | - | - | - | ○ | ○ | ○ |
| 451 | Analog Input Voltage Monitor | - | - | - | - | - | ○ | ○ | ○ |
| 452 | External Encoder Input Monitor | - | - | - | - | - | ○ | ○ | ○ |
| 453 | Regeneration Monitor | - | - | - | - | - | ○ | ○ | ○ |
| 454 | Drive Power Supply Voltage Monitor | - | - | - | - | - | ○ | ○ | ○ |
| 455 | Monitor Torque | - | - | - | - | - | ○ | ○ | ○ |
| 459 | Internal Position Command Monitor 1 | - | - | - | - | - | ○ | ○ | ○ |
| 460 | Internal Position Command Monitor 2 | - | - | - | - | - | ○ | ○ | ○ |
| 461 | Internal Speed Command Monitor 1 | - | - | - | - | - | ○ | ○ | ○ |
| 462 | Internal Speed Command Monitor 2 | - | - | - | - | - | ○ | ○ | ○ |
| 465 | Internal Current Command Monitor 1 | - | - | - | - | - | ○ | ○ | ○ |
| 466 | Internal Current Command Monitor 2 | - | - | - | - | - | ○ | ○ | ○ |
| 467 | Internal Current Command Monitor 3 | - | - | - | - | - | ○ | ○ | ○ |
| 468 | Internal Current Command Monitor 4 | - | - | - | - | - | ○ | ○ | ○ |
| 469 | Internal Current Command Monitor 5 | - | - | - | - | - | ○ | ○ | ○ |
| 470 | Speed Integration Monitor | - | - | - | - | - | ○ | ○ | ○ |
| 471 | Current Integration Monitor 1 | - | - | - | - | - | ○ | ○ | ○ |
| 473 | Speed Command Monitor | - | - | - | - | - | ○ | ○ | ○ |
| 474 | Current Command Monitor | - | - | - | - | - | ○ | ○ | ○ |
| 476 | Driver Internal Position Error | - | - | - | - | - | ○ | ○ | ○ |

To use the parameters that have been newly added to the driver side, you also need to update the dedicated applications. Use applications of the latest available revisions.

| Software Revision | 3.16 | 3.22 | 4.11 | 4.31 | 4.44 | 4.77 | 6.00 | 6.20 |
|-----------------------|------|---------|---------|---------|---------|------|------|------|
| Motion Adjuster | ○ | 1.5.0.5 | 1.5.0.5 | 1.6.0.0 | 1.6.0.0 | × | × | × |
| Motion Designer Drive | ○ | ○ | ○ | ○ | 0.30 | 1.00 | 1.00 | 1.10 |

22.4. Settings Panel Function Extension

Since the products are continually improved, settings panel functions are sometimes extended. When using an old driver, please be aware of this.

| Software Revision | 3.16 | 3.22 | 4.11 | 4.31 | 4.44 | 4.77 | 6.00 | 6.20 |
|--|------|------|------|------|------|------|------|------|
| 4-byte parameter in the decimal notation | - | - | - | - | ○ | ○ | ○ | ○ |
| Status Display Monitor additional items | - | - | - | - | - | ○ | ○ | ○ |

Revision History

| Date of revision | Rev. No. | Description/reason |
|------------------|----------|--|
| 17/03/06 | 0000 | First version |
| 17/06/15 | 0001 | Addition of a new combination motor type (TBL-i4s series) Revision of descriptions in 9. Establishing Communication with Host Equipment, 11. Servo Gain Adjustment, and 15.4 Homing Mode Update of the software revision (revision of the homing mode and enhancement of the gain adjustment function) |
| | | |